



358...H03
359...C03
365...D03
365...E03
366...F03
367...G03
368...H03
368...I03
368...J03
369...K03
369...L03
375...H03
377...H03
385...D03

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q/A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
358AB	358AB 354-B	CONE CUP		00 00		1 2AF 1 1BH	90050	00		7BA ASSEMBLY		90 120
358-B	358-B 354	CONE CUP		00 00		1 2AF 1 1BF	90051	00		7BA ASSEMBLY		90 120
	358-B 354A	CONE CUP		00 00		1 2AF 1 1BF	90082	00		7BA ASSEMBLY		90 120
	358-B 354-B	CONE CUP		00 00		1 2AF 1 1BH	90085	00		7BA ASSEMBLY		90 120
358D	358D 352	CONE CUP		0 0		1 2AG 2 1BF	90111	0		6AP ASSEMBLY		
	358D 352 Y15-352	CONE CUP CUP SPCR	Q	20024 20024 20000		1 2AB 2 1BA 1 04B	90083	20024		5AP ASSEMBLY	EP .0060	
	358D 352 Y15-352	CONE CUP CUP SPCR	Q	40024 40024 20000		1 2AB 2 1BA 1 04B	90125 90118	40024 40024		5AP ASSEMBLY 5AP ASSEMBLY	EP .0080 EP .0120	
	358D 354A	CONE CUP		0 0		1 2AG 2 1BF	90122	0		6AP ASSEMBLY		
	358D 354A Y15-354A	CONE CUP CUP SPCR	S	20024 20024 20000		1 2AB 2 1BP 1 04B	902A1	20024		5AP ASSEMBLY	EP .0020	
	358D 354A Y15-354A	CONE CUP CUP SPCR	S	40024 40024 20000		1 2AB 2 1BP 1 04B	90137	40024		5AP ASSEMBLY	EP .0060	
	358D 354A Y4S-354A	CONE CUP CUP SPCR		40024 40024 20000		1 2AB 2 1BP 1 04B	90110	40024		5AP ASSEMBLY	EP .0160	77 189
359A	359A 352	CONE CUP		0 0		1 2AF 1 1BF	90053	0		6BA ASSEMBLY		
	359A 354A	CONE CUP		0 0		1 2AF 1 1BF	90054	0		6BA ASSEMBLY		
	359A 354-B	CONE CUP		0 0		1 2AF 1 1BH	90055	0		6BA ASSEMBLY		
	359A 354-B	CONE CUP		0-30 0		1 2AF 1 1BH	90056	0-30		6BA ASSEMBLY		
359AB	359AB 354	CONE CUP		00 00		1 2AF 1 1BF	90119	00		7BA ASSEMBLY		90 120
	359AB 354-B	CONE CUP		00 00		1 2AF 1 1BH	90057	00		7BA ASSEMBLY		90 120
359-S	359-S 352	CONE CUP		0 0		1 2AF 1 1BF	90058	0		6BA ASSEMBLY		
	359-S 353	CONE CUP		0 0		1 2AF 1 1BF	90076	0		6BA ASSEMBLY		
	359-S 353D X15-359-S	CONE CUP CONE SPCR	A	20024 20024 20000		2 2AA 1 1BB 1 04A	90084 90071	20024 20024		5BB ASSEMBLY 5BB ASSEMBLY	EP .0080 EP .0100	
	359-S 353D X15-359-S	CONE CUP CONE SPCR	A	30000 30000 0		2 2AF 1 1BG 1 04A	90059 90113	30000 30000		6BB ASSEMBLY 6BB ASSEMBLY	EP .0040 EP .0060	

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	DR	OBSOLETE DATE
	359-S	CONE		40024		2 2AA	90087	40024	5BB	ASSEMBLY	EP .0080		
	353D	CUP		40024		1 1BB	90128	40024	5BB	ASSEMBLY	EP .0100		
	X15-359-S	CONE SPCR A		20000		1 04A							
	359-S	CONE		0		1 2AF	90060	0	6BA	ASSEMBLY			
	354A	CUP		0		1 1BF							
	359-S	CONE		0-30		1 2AF	90133	0-33	6BA	ASSEMBLY			
	354A	CUP		0-39		1 1BF							
	359-S	CONE		00		1 2AF	906A2	00	7BA	ASSEMBLY			
	354A	CUP		00		1 1BF							
	359-S	CONE		0		1 2AF	90061	0	6BA	ASSEMBLY			
	354-B	CUP		0		1 1BH							
	359-S	CONE		0		1 2AF	9G5A1	0-G000	6BA	ASSEMBLY			
	354X	CUP		0-H000		1 1BF							
	359-S	CONE		0		1 2AF	90062	0	6BA	ASSEMBLY			
	3520	CUP		0		1 1BF							
	359-S	CONE		0		1 2AF	90063	0	6BA	ASSEMBLY			
	3525	CUP		0		1 1BF							
359-SB	359-SB	CONE		00		1 2AF	90064	00	7BA	ASSEMBLY			90 120
	354A	CUP		00		1 1BF							
	359-SB	CONE		00		1 2AF	90065	00	7BA	ASSEMBLY			90 120
	354-B	CUP		00		1 1BH							
359TD	359TD	CONE		20000		1 2AB	90066	20000	5AP	ASSEMBLY	EP .0160		
	352	CUP		20024		2 1BA							
	Y15-352	CUP SPCR Q		20000		1 04B							
	359TD	CONE		40000		1 2AB	90067	40000	5AP	ASSEMBLY	EP .0160		
	352	CUP		40024		2 1BA							
	Y15-352	CUP SPCR Q		20000		1 04B							
	359TD	CONE		0		1 2AG	90093	0	6AP	ASSEMBLY			
	354A	CUP		0		2 1BF							
	359TD	CONE		0		1 2AG	90092	0	6AP	ASSEMBLY	EP .0100		
	354A	CUP		0		2 1BF							
	Y15-354A	CUP SPCR S		0		1 04B							
	359TD	CONE		0		1 2AG	90136	0	6AP	ASSEMBLY	EP .0100		
	354A	CUP		0		2 1BF							
	Y55-354A	CUP SPCR Q		0		1 04B							
359TDB	359TDB	CONE		00		1 2AG	90068	00	7AP	ASSEMBLY	EP .0100		90 120
	354A	CUP		00		2 1BF							
	Y15-354A	CUP SPCR S		00		1 04B							
	359TDB	CONE		00		1 2AG	90134	00	7AP	ASSEMBLY	EP .0100		90 120
	354A	CUP		00		2 1BF							
	Y55-354A	CUP SPCR Q		00		1 04B							
365	365	CONE		0		1 2BF	90010	0	6BA	ASSEMBLY			
	362	CUP		0		1 1BF							
	365	CONE		0-30		1 2BF	905A3	0-30	6BA	ASSEMBLY			
	362	CUP		0		1 1BF							
	365	CONE		40024		2 2BP	9E4A4	4E024	5BA	ASSEMBLY	EP .0120		
	362	CUP		4E024		2 1BL							
	Y45-362	CUP SPCR Q		2E000		1 04B							
	X15-366	CONE SPCR A		2E000		1 04P							
	365	CONE		0		1 2BF	90230	0	6BA	ASSEMBLY			
	362A	CUP		0		1 1BF							

ASSEMBLY
PART NUMBER

COMPONENT
PART NUMBER

DESC

SP
TY

COMP
INSP

Q-A

COMP
SGC

ASSY
CODE

ASSY
INSP

SGC

ASSY
DESC

END PLAY OR
PRELOAD

OBSOLETE
DATE

	365 362-B	CONE CUP		0 0		1 1	2BF 1BH	90087	0	6BA	ASSEMBLY		
	365 362-B	CONE CUP		0-30 0		1 1	2BF 1BH	90223	0-30	6BA	ASSEMBLY		
	365 362-B	CONE CUP		0-4000 0-4000		1 1	2BF 1BH	94087	0-4000	6BA	ASSEMBLY		
	365 363	CONE CUP		0 0		1 1	2BF 1BF	90011	0	6BA	ASSEMBLY		
	365 363D	CONE CUP		0 0		2 1	2BF 1BG	90012	0	6BB	ASSEMBLY		
	365 363D XIS-366	CONE CUP CONE SPCR A		20024 20024 20000		2 1 1	2BP 1BB 04P	90201 90229 90013	20024 20024 20024	5BB 5BB 5BB	ASSEMBLY ASSEMBLY ASSEMBLY	EP .0010 EP .0040 EP .0080	
	365 363D XIS-366	CONE CUP CONE SPCR A		30000 30000 0		2 1 1	2BF 1BG 04P	90199 90151 90154	30000 30000 30000	6BB 6BB 6BB	ASSEMBLY ASSEMBLY ASSEMBLY	EP .0030 EP .0060 EP .0080	
	365 363D XIS-366	CONE CUP CONE SPCR A		30434 30039 0		2 1 1	2BF 1BG 04P	903A1 90226	30434 30434	6BB 6BB	ASSEMBLY ASSEMBLY	EP .0000 EP .0010	
	365 363D XIS-366	CONE CUP CONE SPCR A		40024 40024 20000		2 1 1	2BP 1BB 04P	90193 90114 90014 90142	40024 40024 40024 40024	5BB 5BB 5BB 5BB	ASSEMBLY ASSEMBLY ASSEMBLY ASSEMBLY	EP .0080 EP .0120 EP .0160 EP .0200	
	365 363D XIS-366	CONE CUP CONE SPCR A		0 0 0		2 1 1	2BF 1BG 04P	90227 90198	0 0	6BB 6BB	ASSEMBLY ASSEMBLY	EP .0020 EP .0060	
	365 363D XIS-366	CONE CUP CONE SPCR A		0 30 0 39 0		2 1 1	2BF 1BG 04P	90173	0 33	6BB	ASSEMBLY	EP .0040	
	365 363DC XIS-366	CONE CUP CONE SPCR A		20024 20024 20000		2 1 1	2BP 1BB 04P	90231	20024	5BB	ASSEMBLY	EP .0080	
	365 363DC XIS-366	CONE CUP CONE SPCR A		40024 40024 20000		2 1 1	2BP 1BB 04P	90174	40024	5BB	ASSEMBLY	EP .0120	
365A	365A 362A	CONE CUP		0 0		1 1	2BF 1BF	90146	0	6BA	ASSEMBLY		
	365A 362-B	CONE CUP		0 174 0		1 1	2BF 1BH	90216	0 174	6BA	ASSEMBLY		
	365A 363D XIS-365A	CONE CUP CONE SPCR A		20024 20024 20000		2 1 1	2BP 1BB 04A	90206 90128 902A5	20024 20024 20024	5BB 5BB 5BB	ASSEMBLY ASSEMBLY ASSEMBLY	EP .0060 EP .0080 EP .0120	
	365A 363D XIS-365A	CONE CUP CONE SPCR A		40024 40024 20000		2 1 1	2BP 1BB 04A	90144	40024	5BB	ASSEMBLY	EP .0080	
365AB	365AB 362A	CONE CUP		00 00		1 1	2BF 1BF	90156	00	7BA	ASSEMBLY		82 307
365-B	365-B 362	CONE CUP		00 00		1 1	2BF 1BF	90015	00	7BA	ASSEMBLY		90 082
	365-B 362-B	CONE CUP		00 00		1 1	2BF 1BH	90160	00	7BA	ASSEMBLY		90 082

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	ORSOLETE DATE
	365-B 363	CONE CUP		00 00		1 2BF 1 1BF	90096	00		7BA ASSEMBLY		90 082
	365-B 363D	CONE CUP		00 00		2 2BF 1 1BG	90207	00		7BB ASSEMBLY		90 082
	365-B 363D X15-366	CONE CUP CONE SPCR A		00 00 00		2 2BF 1 1BG 1 04P	90164	00		7BB ASSEMBLY	EP .0050	90 082
365-S	365-S 362	CONE CUP		0 0		1 2BF 1 1BF	90126	0		6BA ASSEMBLY		
	365-S 362A	CONE CUP		0 0		1 2BF 1 1BF	90016	0		6BA ASSEMBLY		
	365-S 362-B	CONE CUP		0 0		1 2BF 1 1BH	90127	0		6BA ASSEMBLY		
	365-S 363D X15-365-S	CONE CUP CONE SPCR		20024 20024 20000		2 2BP 1 1BB 1 04A	90090 90139	20024 20024		5BB ASSEMBLY 5BB ASSEMBLY	EP .0060 EP .0100	77 189 77 189
	365-S 363D X15-365-S	CONE CUP CONE SPCR		30000 30000 0		2 2BF 1 1BG 1 04A	90169	30000		6BB ASSEMBLY	EP .0020	77 189
	365-S 363D X15-365-S	CONE CUP CONE SPCR		40024 40024 20000		2 2BP 1 1BB 1 04A	90138 90134	40024 40024		5BB ASSEMBLY 5BB ASSEMBLY	EP .0080 EP .0120	77 189 77 189
	365-S 363D X15-365-S	CONE CUP CONE SPCR		0 0 0		2 2BF 1 1BG 1 04A	90168	0		6BB ASSEMBLY	EP .0060	77 189
	365-S 363D X15-65390	CONE CUP CONE SPCR A		20024 20024 20000		2 2BP 1 1BB 1 04P	902A2	20024		5BB ASSEMBLY	EP .0100	
	365-S 363DC X15-365-S	CONE CUP CONE SPCR		30000 30000 0		2 2BF 1 1BG 1 04A	90170	30000		6BB ASSEMBLY	EP .0020	77 189
366	366 362	CONE CUP		0 0		1 2BF 1 1BF	90018	0		6BA ASSEMBLY		
	366 362A	CONE CUP		0 0		1 2BF 1 1BF	90019	0		6BA ASSEMBLY		
	366 362A Y15-362A	CONE CUP CUP SPCR		40024 40024 20000		2 2BP 2 1BP 1 04B	90107	40024		5BA ASSEMBLY	EP .0060	77 189
	366 362-B	CONE CUP		0 0		1 2BF 1 1BH	90020	0		6BA ASSEMBLY		
	366 362-B	CONE CUP		00 00		1 2BF 1 1BH	90222	00		7BA ASSEMBLY		
	366 363	CONE CUP		0 0		1 2BF 1 1BF	90021	0		6BA ASSEMBLY		
	366 363D	CONE CUP		0 0		2 2BF 1 1BG	90023	0		6BB ASSEMBLY		
	366 363D X15-366	CONE CUP CONE SPCR A		20024 20024 20000		2 2BP 1 1BB 1 04P	90102 90122 902A2	20024 20024 20024		5BB ASSEMBLY 5BB ASSEMBLY 5BB ASSEMBLY	EP .0080 EP .0100 EP .0120	

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY- DESC	END PLAY OR PRELOAD	OR OBSOLETE DATE
	366	CONE		30000	2	2BF	90211	30000	6BB	ASSEMBLY	EP .0010	
	363D	CUP		30000	1	1BG	90092	30000	6BB	ASSEMBLY	EP .0020	
	X15-366	CONE SPCR A		0	1	04P	90121	30000	6BB	ASSEMBLY	EP .0030	
							90024	30000	6BB	ASSEMBLY	EP .0060	
							90025	30000	6BB	ASSEMBLY	EP .0080	
							90226	30000	6BB	ASSEMBLY	PL .0005	
							903A1	30000	6BB	ASSEMBLY	PL .0010	
							90220	30000	6BB	ASSEMBLY	PL .0015	
	366	CONE		30434	2	2BF	90219	30434	6BB	ASSEMBLY	EP .0000	
	363D	CUP		30039	1	1BG						
	X15-366	CONE SPCR A		0	1	04P						
	366	CONE		40024	2	2BP	90C26	40024	5BB	ASSEMBLY	EP .0080	
	363D	CUP		40024	1	1BB	90105	40024	5BB	ASSEMBLY	EP .0160	
	X15-366	CONE SPCR A		20000	1	04P						
	366	CONE		0	2	2BF	90123	0	6BB	ASSEMBLY	EP .0020	
	363D	CUP		0	1	1BG	90120	0	6BB	ASSEMBLY	EP .0030	
	X15-366	CONE SPCR A		0	1	04P	90181	0	6BB	ASSEMBLY	EP .0040	
							90119	0	6BB	ASSEMBLY	EP .0050	
							90155	0	6BB	ASSEMBLY	EP .0060	
							90158	0	6BB	ASSEMBLY	EP .0070	
	366	CONE		0-30	2	2BF	90182	0-30	6BB	ASSEMBLY	EP .0020	
	363D	CUP		0	1	1BG						
	X15-366	CONE SPCR A		0	1	04P						
	366	CONE		40024	2	2BP	90225	40024	5BB	ASSEMBLY	EP .0080	
	363D	CUP		40024	1	1BB						
	X35-368	CONE SPCR BB		20000	1	04A						
	366	CONE		30000	2	2BF	90153	30000	6BB	ASSEMBLY	EP .0050	
	363DC	CUP		30000	1	1BG	903A3	30000	6BB	ASSEMBLY	PL .0005	
	X15-366	CONE SPCR A		0	1	04P						
366-B	366-B	CONE		00	1	2BF	90027	00	7BA	ASSEMBLY		82 307
	362	CUP		00	1	1BF						
	366-B	CONE		00	1	2BF	90028	00	7BA	ASSEMBLY		82 307
	362A	CUP		00	1	1BF						
	366-B	CONE		00	2	2BF	90204	00	7BB	ASSEMBLY	EP .0010	82 307
	363D	CUP		00	1	1BG						
	X15-366	CONE SPCR A		00	1	04P						
NA366	NA366	CONE		20194	2	2BA	90030	20194	5BB	ASSEMBLY	EP .0150	
	363D	CUP		20081	1	1BB						
	NA366	CONE		20199	2	2BA	90031	20199	5BB	ASSEMBLY	EP .0000	
	363D	CUP		20081	1	1BB						
	NA366	CONE		30000	2	2BF	90029	30000	6BB	ASSEMBLY	EP .0060	
	363D	CUP		30001	1	1BG						
	NA366	CONE		30000	2	2BF	90171	30000	6BB	ASSEMBLY	EP .0060	
	363DC	CUP		30001	1	1BG						
367	367	CONE		0	1	2BF	90215	0	6BA	ASSEMBLY		
	362	CUP		0	1	1BF						
	367	CONE		0	1	2BF	90032	0	6BA	ASSEMBLY		
	362A	CUP		0	1	1BF						
	367	CONE		0	1	2BF	90140	0	6BA	ASSEMBLY		
	362-B	CUP		0	1	1BH						
	367	CONE		0	1	2BF	90089	0	6BA	ASSEMBLY		
	363	CUP		0	1	1BF						

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	ASSY SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
	367	CONE		20016	2	2BP	90022	20089	5BB	ASSEMBLY	EP .0100	82 130
	363D	CUP		20081	1	1BB						
	X15-367	CONE	SPCR A	20000	1	04P						
	367	CONE		20024	2	2BP	90214	20024	5BB	ASSEMBLY	EP .0020	
	363D	CUP		20024	1	1BB						
	X15-367	CONE	SPCR A	20000	1	04P						
	367	CONE		30000	2	2BF	90100	30000	6BB	ASSEMBLY	EP .0060	
	363D	CUP		30000	1	1BG						
	X15-367	CONE	SPCR A	0	1	04P						
	367	CONE		40024	2	2BP	90129	40024	5BB	ASSEMBLY	EP .0080	
	363D	CUP		40024	1	1BB	90125	40024	5BB	ASSEMBLY	EP .0100	
	X15-367	CONE	SPCR A	20000	1	04P						
	367	CONE		40024	2	2BP	90179	40157	5BB	ASSEMBLY	EP .0100	
	363D	CUP		40157	1	1BB						
	X15-367	CONE	SPCR B	20000	1	04P						
368	368	CONE		0	1	2BF	90033	0	6BA	ASSEMBLY		
	362	CUP		0	1	1BF						
	368	CONE		0-30	1	2BF	90034	0-30	6BA	ASSEMBLY		
	362	CUP		0	1	1BF						
	368	CONE		0-30	1	2BF	90035	0-33	6BA	ASSEMBLY		
	362	CUP		0-39	1	1BF						
	368	CONE		0	1	2BF	90036	0	6BA	ASSEMBLY		
	362A	CUP		0	1	1BF						
	368	CONE		0-174	1	2BF	90229	0-174	6BA	ASSEMBLY		
	362A	CUP		0	1	1BF						
	368	CONE		40024	2	2BE	90084	40024	5BA	ASSEMBLY	EP .0100	77 189
	362A	CUP		40024	2	1BP						
	Y25-362A	CUP	SPCR	20000	1	04B						
	X15-368	CONE	SPCR	20000	1	04A						
	368	CONE		0	1	2BF	90037	0	6BA	ASSEMBLY		
	362-B	CUP		0	1	1BH						
	368	CONE		00	1	2BF	90334	00	7BA	ASSEMBLY		
	362-B	CUP		00	1	1BH						
	368	CONE		0	1	2BF	90038	0	6BA	ASSEMBLY		
	363	CUP		0	1	1BF						
	368	CONE		0	2	2BF	90039	0	6BB	ASSEMBLY		
	363	CUP		0	1	1BG						
	368	CONE		20024	2	2BE	9E2A2	2E024	5BB	ASSEMBLY	EP .0080	
	363D	CUP		20024	1	1BB						
	X15-368A	CONE	SPCR A	2E000	1	04P						
	368	CONE		20024	2	2BE	90157	20024	5BB	ASSEMBLY	EP .0050	
	363D	CUP		20024	1	1BB	90130	20024	5BB	ASSEMBLY	EP .0080	
	X15-368A	CONE	SPCR A	20000	1	04P	90083	20024	5BB	ASSEMBLY	EP .0100	
	368	CONE		30000	2	2BF	90095	30000	6BB	ASSEMBLY	EP .0040	
	363D	CUP		30000	1	1BG	90112	30000	6BB	ASSEMBLY	EP .0050	
	X15-368A	CONE	SPCR A	0	1	04P	90106	30000	6BB	ASSEMBLY	EP .0080	
	368	CONE		30434	2	2BF	90228	30434	6BB	ASSEMBLY	EP .0000	
	363D	CUP		30039	1	1BG	90212	30434	6BB	ASSEMBLY	EP .0020	
	X15-368A	CONE	SPCR A	0	1	04P						
	368	CONE		40024	2	2BE	9U043	4U024	5BB	ASSEMBLY	EP .0160	
	363D	CUP		40024	1	1BB						
	X15-368A	CONE	SPCR A	20000	1	04P						

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
368A	368	CONE		40024	2	2BF	90040	40024	5BB	ASSEMBLY	EP .0060	90 180
	363D	CUP		40024	1	1BB	90118	40024	5BB	ASSEMBLY	EP .0080	
	X15-368A	CONE SPCR A		20000	1	04P	90041	40024	5BB	ASSEMBLY	EP .0100	
							90042	40024	5BB	ASSEMBLY	EP .0120	
							90043	40024	5BB	ASSEMBLY	EP .0160	
	368	CONE		0	2	2BF	90131	0	6BB	ASSEMBLY	EP .0050	
	363D	CUP		0	1	1BG						
	X15-368A	CONE SPCR A		0	1	04P						
	368	CONE		30000	2	2BF	90203	30000	6BB	ASSEMBLY	EP .0000	
	363D	CUP		30000	1	1BG	90197	30000	6BB	ASSEMBLY	EP .0020	
	X35-368	CONE SPCR BB		0	1	04A						
	368	CONE		40024	2	2BE	90219	40024	5BB	ASSEMBLY	EP .0080	
	363D	CUP		40024	1	1BB	90183	40024	5BB	ASSEMBLY	EP .0160	
	X35-368	CONE SPCR BB		20000	1	04A	90117	40024	5BB	ASSEMBLY	EP .0200	
	368	CONE		30000	2	2BF	90172	30000	6BB	ASSEMBLY	EP .0020	
363DC	CUP		30000	1	1BG	90152	30000	6BB	ASSEMBLY	EP .0060		
X15-368A	CONE SPCR A		0	1	04P	90145	30000	6BB	ASSEMBLY	EP .0030		
368	CONE		40024	2	2BE	90184	40024	5BB	ASSEMBLY	EP .0080		
363DC	CUP		40024	1	1BB							
X15-368A	CONE SPCR A		20000	1	04P							
368	CONE		40024	2	2RE	90143	40000	5BB	ASSEMBLY	EP .0120		
364XD	CUP		40000	1	1BB							
X45-368	CONE SPCR A		20000	1	04A							
368A	CONE		4F024	1	2BE	9F499	4F024	5BA	ASSEMBLY			
362	CUP		40024	1	1BL							
368A	CONE		0	1	2BF	90044	0	6BA	ASSEMBLY			
362	CUP		0	1	1BF							
368A	CONE		0	1	2BF	90045	0	6BA	ASSEMBLY			
362A	CUP		0	1	1BF							
368A	CONE		3E223	2	2BF	9E695	3E223	6BA	ASSEMBLY	EP .0080	88 195	
362A	CUP		3E223	2	1BF							
Y105-362A	CUP SPCR		0	1	04B							
K426882	CONE SPCR		0	1	04A							
368A	CONE		30000	2	2BF	9G333	3E223	6BA	ASSEMBLY	EP .0080	88 195	
362A	CUP		30000	2	1BF							
Y105-362A	CUP SPCR		0-E000	1	04B							
K426882	CONE SPCR		0-E000	1	04A							
368A	CONE		30000	2	2BF	98333	38223	6BA	ASSEMBLY	EP .0080	86 037	
362A	CUP		30000	2	1BF							
Y105-362A	CUP SPCR		0-8000	1	04B							
K426882	CONE SPCR		0-8000	1	04A							
368A	CONE		38223	2	2BF	98695	38223	6BA	ASSEMBLY	EP .0080	86 042	
362A	CUP		38223	2	1BF							
Y105-362A	CUP SPCR		0	1	04B							
K426882	CONE SPCR		0	1	04A							
368A	CONE		0	1	2BF	90046	0	6BA	ASSEMBLY			
362-B	CUP		0	1	1BH							
368A	CONE		00	1	2BF	90213	00	7BA	ASSEMBLY			
362-B	CUP		00	1	1BH							
368A	CONE		0	2	2BF	90149	0	6BB	ASSEMBLY			
363D	CUP		0	1	1BG							
368A	CONE		0-30	2	2BF	90048	0-30	5BB	ASSEMBLY			
363D	CUP		0	1	1BG							

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OR	OBSOLETE DATE
	368A	CONE		20024	2	2BE	90189	20024	5BB	ASSEMBLY	EP .0030		
	363D	CUP		20024	1	1BB	90136	20024	5BB	ASSEMBLY	EP .0060		
	X1S-368A	CONE	SPCR A	20000	1	04P	90050	20024	5BB	ASSEMBLY	EP .0080		
							90051	20024	5BB	ASSEMBLY	EP .0090		
							90097	20024	5BB	ASSEMBLY	EP .0160		
	368A	CONE		20024	2	2BE	90332	20157	5BB	ASSEMBLY	EP .0030		
	363D	CUP		20157	1	1BB							
	X1S-368A	CONE	SPCR A	20000	1	04P							
	368A	CONE		30000	2	2BF	90085	30000	6BB	ASSEMBLY	EP .0030		
	363D	CUP		30000	1	1BG	90049	30000	6BB	ASSEMBLY	EP .0040		
	X1S-368A	CONE	SPCR A	0	1	04P	90111	30000	6BB	ASSEMBLY	EP .0050		
							90217	30000	6BB	ASSEMBLY	EP .0060		
							90159	30000	6BB	ASSEMBLY	EP .0060		76 062
	368A	CONE		30434	2	2BF	90210	30434	6BB	ASSEMBLY	EP .0010		
	363D	CUP		30039	1	1BG	90224	30434	6BB	ASSEMBLY	EP .0020		
	X1S-368A	CONE	SPCR A	0	1	04P							
	368A	CONE		40024	2	2BE	90196	40024	5BB	ASSEMBLY	EP .0030		
	363D	CUP		40024	1	1BB	90052	40024	5BB	ASSEMBLY	EP .0080		
	X1S-368A	CONE	SPCR A	20000	1	04P	90094	40024	5BB	ASSEMBLY	EP .0120		
	368A	CONE		0	2	2BF	90180	0	6BB	ASSEMBLY	EP .0050		
	363D	CUP		0	1	1BG							
	X1S-368A	CONE	SPCR A	0	1	04P							
	368A	CONE		40024	2	2BE	90191	40024	5BB	ASSEMBLY	EP .0160		
	363D	CUP		40024	1	1BB							
	X2S-368A	CONE	SPCR A1	20000	1	04A							
	368A	CONE		0	2	2BF	90163	0	6BB	ASSEMBLY			
	363DC	CUP		0	1	1BG							
	368A	CONE		20024	2	2BE	90161	20024	5BB	ASSEMBLY	EP .0120		
	363DC	CUP		20024	1	1BB							
	X1S-368A	CONE	SPCR A	20000	1	04P							
	368A	CONE		40024	2	2BE	90330	40024	5BB	ASSEMBLY	EP .0160		
	363DC	CUP		40024	1	1BB							
	X1S-368A	CONE	SPCR A	20000	1	04P							
	368A	CONE		40024	2	2BE	90331	40024	5BB	ASSEMBLY	EP .0080		
	363DC	CUP		40024	1	1BB							
	X2S-368A	CONE	SPCR A1	20000	1	04A							
	368A	CONE		40024	2	2BE	90192	40000	5BB	ASSEMBLY	EP .0100		
	364XD	CUP		40000	1	1BB							
	X4S-368	CONE	SPCR A	20000	1	04A							
368AB	368AB	CONE		00	1	2BF	90188	00	7BA	ASSEMBLY			82 307
	362A	CUP		00	1	1BF							
368 B	368 B	CONE		0	1	2BF	90115	0	6BA	ASSEMBLY			82 307
	362	CUP		0	1	1BF							
368 B	368 B	CONE		00	1	2BF	90176	00	7BA	ASSEMBLY			82 307
	362	CUP		00	1	1BF							
368 B	368 B	CONE		00	1	2BF	90053	00	7BA	ASSEMBLY			82 307
	362A	CUP		00	1	1BF							
368 B	368 B	CONE		00	1	2BF	90054	00	7BA	ASSEMBLY			82 307
	362 B	CUP		00	1	1BH							
368 B	368 B	CONE		00	1	2BF	90148	00	7BA	ASSEMBLY			82 307
	353	CUP		00	1	1BF							
368 B	368 B	CONE		00	2	2BF	90055	00	7BB	ASSEMBLY			82 307
	363D	CUP		00	1	1BG							

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	SGC DESC--	END PLAY OR PRELOAD	OR	OBSOLETE DATE
368 S	368 S	CONE		0		1 2BF	90209	0	6BA ASSEMBLY			
	362	CUP		0		1 1BF						
368-S	362A	CONE		0		1 2BF	90056	0	6BA ASSEMBLY			
		CUP		0		1 1BF						
368-S	362A	CONE		0-30		1 2BF	90099	0-30	6BA ASSEMBLY			
		CUP		0		1 1BF						
368-S	362-B	CONE		0		1 2BF	90057	0	6BA ASSEMBLY			
		CUP		0		1 1BH						
368-S	362-B	CONE		0-174		1 2BF	90215	0-174	6BA ASSEMBLY			
		CUP		0		1 1BH						
368-S	363D	CONE		0		2 2BF	90058	0	6BB ASSEMBLY			
		CUP		0		1 1BG						
368-S	363D	CONE		20024		4 2BP	90165	20024	5BC ASSEMBLY	EP .0120		
	Y23 362	CUP		20024		2 1BB						
X15-368-S	368-S	CONE SPCR R		20000		1 04Q						
		CONE SPCR A		20000		2 04A						
368-S	363D	CONE		20024		2 2BP	90093	20024	5BK ASSEMBLY	EP .0010		
	X15-368-S	CUP		20024		1 1BB	90086	20024	5BB ASSEMBLY	EP .0100		
368-S	363D	CONE SPCR A		20000		1 04A						
	X15-368-S	CONE SPCR A		30000		2 2BF	90101	30000	6BB ASSEMBLY	EP .0070		
368-S	363D	CLP		30000		1 1BG	90218	30000	6BB ASSEMBLY	EP .0100		
	X15-368-S	CONE SPCR A		0		1 04A						
368-S	363D	CONE		30030		2 2BF	90200	30030	6BB ASSEMBLY	EP .0010		
	X15-368-S	CUP		30000		1 1BG						
368-S	363D	CONE SPCR A		0		1 04A						
	X15-368-S	CONE SPCR A		30434		2 2BF	903A1	30434	6BB ASSEMBLY	EP .0000		
368-S	363D	CUP		30039		1 1BG						
	X15-368-S	CONE SPCR A		0		1 04A						
368-S	363D	CONE		40024		2 2BP	90059	40024	5BB ASSEMBLY	EP .0120		
	X15-368-S	CUP		40024		1 1BB	90141	40024	5BB ASSEMBLY	EP .0280		
368-S	363D	CONE SPCR A		20000		1 04A						
	X15-368-S	CONE SPCR A		0		2 2BF	90178	0	6BB ASSEMBLY	EP .0050		
368-S	363D	CUP		0		1 1BG	90186	0	6BB ASSEMBLY	EP .0060		
	X15-368-S	CONE SPCR A		0		1 04A						
368-S	363DC	CONE		40024		2 2BP	90175	40024	5BB ASSEMBLY	EP .0120		
	X15-368-S	CUP		40024		1 1BB						
368-SB	362-B	CONE SPCR A		20000		1 04A						
	368-SB	CONE		00		1 2BF	90124	00	7BA ASSEMBLY			90 082
368H	362	CUP		00		1 1BH						
	368H	CONE		0		1 2BF	90060	0	6BA ASSEMBLY			
368H	362A	CUP		0		1 1BF						
	362A	CONE		0		1 2BF	90137	0	6BA ASSEMBLY			
368H	362-B	CUP		0		1 1BF						
	362-B	CONE		0		1 2BF	90061	0	6BA ASSEMBLY			
369A	362	CUP		0		1 1BF						
	369A	CONE		0		1 2BF	90062	0	6BA ASSEMBLY			
369A	362A	CUP		0		1 1BF						
	362A	CONE		0		1 2BF	90063	0	6BA ASSEMBLY			

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	COMP Q-A SGC	ASSY CODE	ASSY INSP	ASSY SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
	369A 362A Y15-362A	CONE CUP CUP SPCR		30000 30000 0	2 2BF 2 1BF 1 04B	90064	30000	6BA	ASSEMBLY	PI .0020	77 189
	369A 362-B	CONE CUP		0 0	1 2BF 1 1BH	90065	0	6BA	ASSEMBLY		
	369A 363	CONE CUP		0 0	1 2BF 1 1BF	90066	0	6BA	ASSEMBLY		
	369A 363	CONE CUP		0.39 0.39	1 2BF 1 1BF	90067	0.33	6BA	ASSEMBLY		
	369A 363D	CONE CUP		0 0	2 2BF 1 1EG	90105	0	6BB	ASSEMBLY		
	369A 363D X15-369A	CONE CUP CONE SPCR A		20024 20024 20000	2 2BP 1 1BB 1 04P	90221	20024	5BB	ASSEMBLY	EP .0080	
	369A 363D X15-369A	CONE CUP CONE SPCR A		30000 30000 0	2 2BF 1 1EG 1 04P	90103	30000	6BB	ASSEMBLY	EP .0050	
	369A 363D X15-369A	CONE CUP CONE SPCR A		40024 40024 20000	2 2BP 1 1BB 1 04P	90150 90205 90068	40024 40024 40024	5BB 5BB 5BB	ASSEMBLY ASSEMBLY ASSEMBLY	EP .0080 EP .0120 EP .0120	
	369A 363D X15-369A	CONE CUP CONE SPCR A		0 0 0	2 2BF 1 1EG 1 04P	90104	0	6BB	ASSEMBLY	EP .0050	
	369A 363DC X15-369A	CONE CUP CONE SPCR A		40024 40024 20000	2 2BP 1 1BB 1 04P	90137	40024	5BB	ASSEMBLY	EP .0080	
	369A 364XD	CONE CUP		0-174 0	2 2BF 1 1EG	90116	0-174	6BB	ASSEMBLY		
	369A 364XD X25-369A	CONE CUP CONE SPCR A		40024 40000 20000	2 2BP 1 1BB 1 04A	90187	40000	5BB	ASSEMBLY	EP .0080	
369AS	369AS 362 Y25-362	CONE CUP CUP SPCR R		40024 40024 20000	2 2BP 2 1BL 1 04Q	90070	40024	5BA	ASSEMBLY	EP .0100	
369AHB	369AHB 363	CONE CUP		00 00	1 2BF 1 1BF	90071	00	7BA	ASSEMBLY		74 149
369-S	369-S 362	CONE CUP		0 0	1 2BF 1 1BF	90072	0	6BA	ASSEMBLY		
	369-S 362A	CONE CUP		0 0	1 2BF 1 1BF	90073	0	6BA	ASSEMBLY		
	369-S 362-B	CONE CUP		0 0	1 2BF 1 1BH	90074	0	6BA	ASSEMBLY		
	369-S 363	CONE CUP		0 0	1 2BF 1 1BF	90220	0	6BA	ASSEMBLY		
	369-S 363	CONE CUP		0.39 0.39	1 2BF 1 1BF	90113	0.33	6BA	ASSEMBLY		
	369-S 363D	CONE CUP		0 0	2 2BF 1 1EG	90108	0	6BB	ASSEMBLY		
	369-S 363D X15-369A	CONE CUP CONE SPCR A		30000 30000 0	2 2BF 1 1EG 1 04P	90194 90091 90075	30000 30000 30000	6BB 6BB 6BB	ASSEMBLY ASSEMBLY ASSEMBLY	EP .0030 EP .0060 EP .0080	

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY- DESC	END PLAY OR PRELOAD	OBSOLETE DATE
	369-S	CONE		40024		2 2BF	90088	40024	5BB	ASSEMBLY	EP .0080	
	363D	CUP		40024		1 1BF	90076	40024	5BB	ASSEMBLY	EP .0160	
	X15-369A	CONE SPCR A		20000		1 04P						
	369-S	CONE		0-362		2 2BF	90177	0-362	6BB	ASSEMBLY		
	363D	CUP		0		1 1BF						
	X15-369A	CONE SPCR A		0		1 04P						
	369-S	CONE		40024		2 2BF	90147	40024	5BB	ASSEMBLY	EP .0080	
	363DC	CUP		40024		1 1BF						
	X15-369A	CONE SPCR A		20000		1 04P						
	369-S	CONE		0		2 2BF	90077	0	6BB	ASSEMBLY		
	364XD	CUP		0		1 1BF						
	369-S	CONE		30000		2 2BF	90079	30000	6BB	ASSEMBLY	EP .0050	
	364XD	CUP		30000		1 1BF						
	X25-369A	CONE SPCR A		0		1 04A						
	369-S	CONE		40024		2 2BF	90110	40000	5BB	ASSEMBLY	EP .0080	
	364XD	CUP		40000		1 1BF	90078	40000	5BB	ASSEMBLY	EP .0120	
	X25-369A	CONE SPCR A		20000		1 04A	90082	40000	5BB	ASSEMBLY	EP .0140	
	369-S	CONE		40024		2 2BF	90202	40000	5BB	ASSEMBLY	EP .0160	
	364XD	CUP		40000		1 1BF						
	X25-369-S	CONE SPCR A1		20000		1 04A						
369-SB	369-SB	CONE		00		1 2BF	90080	00	7BA	ASSEMBLY		90 082
	362	CUP		00		1 1BF						
	369-SB	CONE		00		1 2BF	90081	00	7BA	ASSEMBLY		90 082
	362-B	CUP		00		1 1BF						
370A	370A	CONE		40024		2 2BF	90185	40024	5BA	ASSEMBLY	EP .0160	
	362	CUP		40024		2 1BF						
	Y55-362	CUP SPCR R		20000		1 04B						
	X15-370A	CONE SPCR A		20000		1 04A						
	370A	CONE		40024		2 2BF	90133	40024	5BB	ASSEMBLY	EP .0040	
	363D	CUP		40024		1 1BF	20162	40024	5BB	ASSEMBLY	EP .0100	
	X15-368A	CONE SPCR A		20000		1 04P						
	370A	CONE		40024		2 2BF	90202	40000	5BB	ASSEMBLY	EP .0080	
	364XD	CUP		40000		1 1BF						
	X45-368	CONE SPCR A		20000		1 04A						
375	375	CONE		0		2 2BF	90050	0	6BB	ASSEMBLY		78 011
	375	CONE		0		1 2BF	90010	0	6BA	ASSEMBLY		
	372	CUP		0		1 1BF						
	375	CONE		0-30		1 2BF	90011	0-33	6BA	ASSEMBLY		
	372	CUP		0-39		1 1BF						
	375	CONE		0		1 2BF	90012	0	6BA	ASSEMBLY		
	372A	CUP		0		1 1BF						
	375	CONE		0		1 2BF	90034	0	6BA	ASSEMBLY		
	373	CUP		0		1 1BF						
	375	CONE		0		1 2BF	90013	0	6BA	ASSEMBLY		
	374	CUP		0		1 1BF						
	375	CONE		30000		2 2BF	90023	30000	6BA	ASSEMBLY	EP .0050	77 189
	374	CUP		30000		2 1BF						
	Y25-374	CUP SPCR		0		1 04B						
	375	CONE		0		1 2BF	90014	0	6BA	ASSEMBLY		
	3720	CUP		0		1 1BF						

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q/A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OR	OBSOLETE DATE
	375	CONE		0-30		1 2BF	90043	0-30	6BA	ASSEMBLY			
	3720	CUP		0		1 1BF							
375-B	375-B	CONE		00		1 2BF	90015	00	7BA	ASSEMBLY			90 094
	372	CUP		00		1 1BF							
	375-B	CONE		00		1 2BF	90047	00	7BA	ASSEMBLY			90 094
	374	CUP		00		1 1BF							
375D	375D	CONE		40024		1 2BB	90036	40024	5BP	ASSEMBLY	EP .0040		
	372A	CUP		40024		2 1BA							
	Y15-372A	CUP SPCR	Q	20000		1 04B							
	375D	CONE		0		1 2BG	90045	0	5BP	ASSEMBLY	EP .0000		
	372A	CUP		0		2 1BF							
	Y15-372A	CUP SPCR	Q	0		1 04B							
	375D	CONE		0		1 2BG	90016	0	6BP	ASSEMBLY			
	374	CUP		0		2 1BF							
	375D	CONE		30000		1 2BG	90051	30000	6BP	ASSEMBLY	EP .0000		
	374	CUP		30000		2 1BF							
	Y15 374	CUP SPCR	Q	0		1 04Q							
	375D	CONE		40024		1 2BB	90018	40024	5BP	ASSEMBLY	EP .0080		
	374	CUP		40024		2 1BA							
	Y15 374	CUP SPCR	Q	20000		1 04Q							
375-S	375-S	CONE		0		1 2BF	90019	0	6BA	ASSEMBLY			
	372A	CUP		0		1 1BF							
375H	375H	CONE		0		1 2BF	90020	0	6BA	ASSEMBLY			
	372	CUP		0		1 1BF							
376	376	CONE		0		1 2BF	90021	0	6BA	ASSEMBLY			
	372	CUP		0		1 1BF							
	376	CONE		20024		2 2BA	90033	20024	5BA	ASSEMBLY	EP .0070	.0080	77 189
	372	CUP		20024		2 1BA							
	X25-376	CONE SPCR		20000		1 04A							
	376	CONE		20024		2 2BA	90049	20024	5BB	ASSEMBLY	EP .0080		81 343
	372XD	CUP		20024		1 1BB							
	X35-376	CONE SPCR	A	20000		1 04P							
	376	CONE		0		1 2BF	90022	0	6BA	ASSEMBLY			
	374	CUP		0		1 1BF							
376A	376A	CONE		40082		1 2BA	90024	40082	5BA	ASSEMBLY	EP .0050		
	3782	CONE		40082		1 2BE							
	3726	CUP		40082		2 1BA							
	X15-376	CONE SPCR	A	20000		1 04P							
376DE	376DE	CONE		40024		1 2BB	90048	40024	5BP	ASSEMBLY	EP .0080		
	374	CUP		40024		2 1BA							
	Y15-374	CUP SPCR	Q	20000		1 04Q							
376X	376X	CONE		20024		2 2BA	90037	20024	5BB	ASSEMBLY	EP .0020		81 342
	372XD	CUP		20024		1 1BB							
	X35-376	CONE SPCR	A	20000		1 04P							
	376X	CONE		40024		2 2BA	90035	40024	5BB	ASSEMBLY	EP .0080		81 342
	372XD	CUP		40024		1 1BB							
	X35-376	CONE SPCR	A	20000		1 04P							
377	377	CONE		0		1 2BF	90025	0	6BA	ASSEMBLY			
	372	CUP		0		1 1BF							
	377	CONE		0		1 2BF	90026	0	6BA	ASSEMBLY			
	372A	CUP		0		1 1BF							

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
	377	CONE		0		1 2BF	90027	0		6BA ASSEMBLY		
	374	CUP		0		1 1BF						
377A	377A	CONE		0		1 2BF	90041	0		6BA ASSEMBLY		
	374	CUP		0		1 1BF						
377AB	377AB	CONE		00		1 2BF	90038	00		7BA ASSEMBLY		90 094
	374	CUP		00		1 1BF						
3771D	3771D	CONE		40000		1 2BF	90031	40000		5BP ASSEMBLY	EP .0080	
	374	CUP		40024		2 1BA						
	Y15-374	CUP SPCR Q		20000		1 04Q						
377W	377W	CONE		0		1 2BF	90028	0		6BA ASSEMBLY		75 302
	3720	CUP		0		1 1BF						
	377W	CONE		0-30		1 2BF	90029	0-30		6BA ASSEMBLY		75 302
	3720	CUP		0		1 1BF						
378DE	378DE	CONE		0		1 2BG	90030	0		6BP ASSEMBLY		
	374	CUP		0		2 1BF						
378DW	378DW	CONE		0		1 2BG	90040	0		6BP ASSEMBLY		
	374	CUP		0		2 1BF						
385	382	CONE		0		1 2BF	90010	0		6BA ASSEMBLY		
	382	CUP		0		1 1BF						
	385	CONE		0-227		1 2BF	90333	0-227		6BA ASSEMBLY		
	382	CUP		0-227		1 1BF						
	385	CONE		0		1 2BF	90011	0		6BA ASSEMBLY		
	382A	CUP		0		1 1BF						
	385	CONE		40024		2 2BL	90305	40024		5BA ASSEMBLY	EP .0080	
	382A	CUP		40024		2 1BE						
	Y15-382A	CUP SPCR R		20000		1 04Q						
	385	CONE		0		1 2BF	90012	0		6BA ASSEMBLY		
	382-B	CUP		0		1 1BH						
	385	CONE		0		1 2BF	90013	0		6BA ASSEMBLY		
	383	CUP		0		1 1BF						
	385	CONE		0-30		1 2BF	90014	0-33		6BA ASSEMBLY		
	383	CUP		0-39		1 1BF						
	385	CONE		0		1 2BF	90015	0		6BA ASSEMBLY		
	383A	CUP		0		1 1BF						
	385	CONE		0-30		1 2BF	90016	0-33		6BA ASSEMBLY		
	383A	CUP		0-39		1 1BF						
	385	CONE		0-580		1 2BF	90349	0-580		6BA ASSEMBLY		
	383A	CUP		0		1 1BF						
	385	CONE		0-4000		1 2BF	94015	0-4000		6BA ASSEMBLY		
	383A	CUP		0-4000		1 1BF						
	385	CONE		00		1 2BF	906A5	00		7BA ASSEMBLY		
	383A	CUP		00		1 1BF						
	385	CONE		0		1 2BF	90017	0		6BA ASSEMBLY		
	383X	CUP		0		1 1BF						
	385	CONE		0-30		1 2BF	905A4	0-33		6BA ASSEMBLY		
	383X	CUP		0-39		1 1BF						
	385	CONE		0		2 2BF	90018	0		6BB ASSEMBLY		
	384D	CUP		0		1 1BG						

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q/A	COMP SGC	ASSY CODE	ASSY INSP	SGC ASSY DESC	END PLAY PRELOAD	OR	OBSOLETE DATE
	385	CONE		40024	4	2BL	90104	40024	5BC ASSEMBLY	EP .0160		77 189
	384D	CUP		40024	2	1BB						
	Y15-384	CUP SPCR R		20000	1	04B						
	X25-385	CONE SPCR		20000	2	04A						
	385	CONE		20024	2	2BL	90021	20024	5BB ASSEMBLY	EP .0080		
	384D	CUP		20024	1	1BB	90156	20024	5BB ASSEMBLY	EP .0100		
	X15-385	CONE SPCR A		20000	1	04A						
	385	CONE		20024	2	2BL	90022	20157	5BB ASSEMBLY	EP .0070		
	384D	CUP		20157	1	1BB						
	X15-385	CONE SPCR A		20000	1	04A						
	385	CONE		30000	2	2BF	90323	30000	6BB ASSEMBLY	EP .0020		
	384D	CUP		30000	1	1BG	90019	30000	6BB ASSEMBLY	EP .0040		
	X15-385	CONE SPCR A		0	1	04A	90020	30000	6BB ASSEMBLY	EP .0050		
							90184	30000	6BB ASSEMBLY	EP .0060		
							90214	30000	6BB ASSEMBLY	EP .0070		
	385	CONE		30434	2	2BF	90350	30434	6BB ASSEMBLY	EP .0000		
	384D	CUP		30039	1	1BG						
	X15-385	CONE SPCR A		0	1	04A						
	385	CONE		0	2	2BF	90198	0	6BB ASSEMBLY	EP .0040		
	384D	CUP		0	1	1BG	90331	0	6BB ASSEMBLY	EP .0050		
	X15-385	CONE SPCR A		0	1	04A						
	385	CONE		40024	2	2BL	90337	40024	5BB ASSEMBLY	EP .0120		
	384DC	CUP		40024	1	1BB						
	X15-385	CONE SPCR A		20000	1	04A						
	385	CONE		0	2	2BF	90148	0	6BB ASSEMBLY			
	384ED	CUP		0	1	1BG						
	385	CONE		0-30	2	2BF	90276	0-33	6BB ASSEMBLY			
	384ED	CUP		0-39	1	1BG						
	385	CONE		40024	4	2BL	90147	40024	5BC ASSEMBLY	EP .0160		
	384ED	CUP		40024	2	1BB						
	Y15-384	CUP SPCR R		20000	1	04B						
	X35-385	CONE SPCR BB		20000	2	04A						
	385	CONE		20024	4	2BL	90339	20024	5BC ASSEMBLY	EP .0080		
	384ED	CUP		20024	2	1BB						
	Y15-384	CUP SPCR R		20000	1	04B						
	X45-385	CONE SPCR A		20000	2	04P						
	385	CONE		20016	2	2BL	90023	20089	5BB ASSEMBLY	EP .0050		
	384ED	CUP		20081	1	1BB						
	X35-385	CONE SPCR BB		20000	1	04A						
	385	CONE		20016	2	2BL	90023	20089	5BB ASSEMBLY	EP .0050		
	384ED	CUP		20081	1	1BB						
	X35-385	CONE SPCR BB		20000	1	04A						
	385	CONE		20024	2	2BL	90274	20024	5BB ASSEMBLY	EP .0010		
	384ED	CUP		20024	1	1BB	90118	20024	5BB ASSEMBLY	EP .0080		
	X35-385	CONE SPCR BB		20000	1	04A						
	385	CONE		20024	2	2BL	90141	20024	5BB ASSEMBLY	EP .0040		
	384ED	CUP		20024	1	1BB	90129	20024	5BB ASSEMBLY	EP .0080		
	X45-385	CONE SPCR A		20000	1	04P						
	385	CONE		30000	2	2BF	90200	30000	6BB ASSEMBLY	EP .0050		
	384ED	CUP		30000	1	1BG	90244	30000	6BB ASSEMBLY	EP .0060		
	X45-385	CONE SPCR A		0	1	04P						
	385	CONE		30030	2	2BF	90201	30030	6BB ASSEMBLY	EP .0050		
	384ED	CUP		30000	1	1BG						
	X45-385	CONE SPCR A		0	1	04P						