



445...BOB
495...COB
495...DOB
495...EOB
496...FOB
496...GOB
497...HOB
497...IOB
497...JOB
498...KOB
498...LOB
511...MOB
536...NOB
539...OOB

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q/A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OR	OBSOLETE DATE
	495A 493D XIS-495A	CONE CUP CONE SPCR A		40024 40024 20000	2	2CE 1 ICB 1 04Q	91031	411024	5CB	ASSEMBLY	EP .0120		
	495A 493D XIS-495A	CONE CUP CONE SPCR A		40024 40024 20000	2	2CE 1 ICB 1 04Q	90030 90031 90177	40024 40024 40024	5CB 5CB 5CB	ASSEMBLY ASSEMBLY ASSEMBLY	EP .0080 EP .0120 EP .0200		
	495A 493D XIS-495A	CONE CUP CONE SPCR A		40024 40286 20000	2	2CE 1 ICB 1 04Q	90289	40286	5CB	ASSEMBLY	EP .0040		
	495A 493D XIS-495A	CONE CUP CONE SPCR A		40081 40075 20000	2	2CA 1 ICB 1 04Q	90199	40075	5CB	ASSEMBLY	EP .0070		
	495A 493D XIS-495A	CONE CUP CONE SPCR A		0 0 0	2	2CF 1 ICG 1 04Q	90149 90111	0 0	6CB 6CB	ASSEMBLY ASSEMBLY	EP .0030 EP .0050		
	495A 493D XIS-495A	CONE CUP CONE SPCR A		0-30 0 0	2	2CF 1 ICG 1 04Q	90109	0-30	6CB	ASSEMBLY	EP .0030		
	495A 493D XIS-495A	CONE CUP CONE SPCR A		70000 20024 20000	2	2CE 1 ICB 1 04Q	90211	70000	5CB	ASSEMBLY	EP .0080		77 206
	495A 493D X25-495A	CONE CUP CONE SPCR A1		20024 20024 20000	2	2CE 1 ICB 1 04B	90201	20024	5CB	ASSEMBLY	EP .0120		
	495A 493D X25-495A	CONE CUP CONE SPCR A1		40024 40024 20000	2	2CE 1 ICB 1 04B	90032	40024	5CB	ASSEMBLY	EP .0080		
	495A 493D X25-495A	CONE CUP CONE SPCR A1		40024 40024 20000	2	2CE 1 ICB 1 04B	90032 90084	40024 40024	5CB 5CB	ASSEMBLY ASSEMBLY	EP .0080 EP .0120		
	495A 493DC	CONE CUP		0 0	2	2CF 1 ICG	90284	0	6CB	ASSEMBLY			
	495A 493DC XIS-495A	CONE CUP CONE SPCR A		20024 20024 20000	2	2CE 1 ICB 1 04Q	90218 90181	20024 20024	5CB 5CB	ASSEMBLY ASSEMBLY	EP .0060 EP .0080		
	495A 493DC XIS-495A	CONE CUP CONE SPCR A		30000 30000 0	2	2CF 1 ICG 1 04Q	90277 90121 90166 90178 90229 90252 90321	30000 30000 30000 30000 30000 30000 30000	6CB 6CB 6CB 6CB 6CB 6CB 6CB	ASSEMBLY ASSEMBLY ASSEMBLY ASSEMBLY ASSEMBLY ASSEMBLY ASSEMBLY	EP .0020 EP .0030 EP .0040 EP .0050 EP .0060 EP .0070 PI .0020		
	495A 493DC XIS-495A	CONE CUP CONE SPCR A		40024 40024 20000	2	2CE 1 ICB 1 04Q	90176 90128 90257 90159 90139	40024 40024 40024 40024 40024	5CB 5CB 5CB 5CB 5CB	ASSEMBLY ASSEMBLY ASSEMBLY ASSEMBLY ASSEMBLY	EP .0060 EP .0080 EP .0100 EP .0120 EP .0160		
	495A 493DC XIS-495A	CONE CUP CONE SPCR A		0 0 0	2	2CF 1 ICG 1 04Q	90283	0	6CB	ASSEMBLY	EP .0040		
	495A 493DCA XIS-495A	CONE CUP CONE SPCR A		20024 20024 20000	2	2CE 1 ICB 1 04Q	902A4	20024	5CB	ASSEMBLY	EP .0060		
	495A 493X	CONE CUP		0 0	1	2CF 1 ICF	90155	0	6CA	ASSEMBLY			

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q/A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OR	OBsolete DATE
	495A	CONE		20024	2	2CE	90287	20024	5CB	ASSEMBLY	EP .0060		73 289
	494DC	CUP		20024	1	1CB	90317	20024	5CB	ASSEMBLY	EP .0080		
	X1S-495A	CONE SPCR A		20000	1	04Q							
	495A	CONE		20024	1	2CE	90269	20024	5CA	ASSEMBLY	EP .0100		
	78250	CONE		20024	1	2CA							
	493	CUP		20024	1	1CE							
	78537	CUP		20024	1	1CA							
	Y17S-493	CUP SPCR P		20000	1	04R							
	X7S-78250	CONE SPCR A		20000	1	04Q							
	495A	CONE		40024	1	2CE	90302	40024	5CA	ASSEMBLY	EP .0140		
	HM516442	CONE		40024	1	2CP							
	492A	CUP		40024	1	1CL							
	HM516410	CUP		40024	1	1CL							
	X4S-495A	CONE SPCR A		20000	1	04B							
	495A	CONE		20024	1	2CE	90332	20024	5CA	ASSEMBLY	EP .0160		
	HM516442	CONE		20024	1	2CP							
	492A	CUP		20024	1	1CL							
	HM516410A	CUP		20024	1	1CA							
	Y6S-492A	CUP SPCR RSR		20000	1	04C							
	X1S-495A	CONE SPCR A		20000	1	04Q							
495AB	495AB	CONE		00	2	2CF	90238	00	7CB	ASSEMBLY			90 122
	493D	CUP		00	1	1CG							
	495AB	CONE		00	2	2CF	90120	00	7CB	ASSEMBLY	EP .0030		90 122
	453D	CUP		00	1	1CG							
	X1S-495A	CONE SPCR A		00	1	04Q							
495AS	495AS	CONE		0-30	1	2CF	90290	0-30	6CA	ASSEMBLY			
	492A	CUP		0	1	1CF							
	495AS	CONE		0-30	1	2CF	90112	0-30	6CA	ASSEMBLY			
	493	CUP		0	1	1CF							
	495AS	CONE		20157	2	2CA	90302	20214	5CA	ASSEMBLY	EP .0020		
	493	CUP		20024	2	1CE							
	Y20S-493	CUP SPCR S		20000	1	04C							
	X3S-495AS	CONE SPCR A		20000	1	04B							
	495AS	CONE		20157	2	2CA	90301	20214	5CA	ASSEMBLY	EP .0020		
	493	CUP		20024	2	1CE							
	Y21S-493	CUP SPCR S		20000	1	04C							
	X4S-495AS	CONE SPCR A		20000	1	04B							
	495AS	CONE		0	1	2CF	90104	0	6CA	ASSEMBLY			
	493-B	CUP		0	1	1CH							
	495AS	CONE		0	2	2CF	90164	0	6CB	ASSEMBLY			
	493D	CUP		0	1	1CG							
	495AS	CONE		20024	2	2CA	90286	20024	5CB	ASSEMBLY	EP .0040		
	493D	CUP		20024	1	1CB	90306	20024	5CB	ASSEMBLY	EP .0080		
	X1S-495AS	CONE SPCR A		20000	1	04B							
	495AS	CONE		30000	2	2CF	90331	30000	6CB	ASSEMBLY	EP .0020		
	493D	CUP		30000	1	1CG	90216	30000	6CB	ASSEMBLY	EP .0040		
	X1S-495AS	CONE SPCR A		0	1	04B							
	495AS	CONE		40024	2	2CA	90208	40024	5CB	ASSEMBLY	EP .0100		
	493D	CUP		40024	1	1CB	90231	40024	5CB	ASSEMBLY	EP .0120		
	X1S-495AS	CONE SPCR A		20000	1	04B							
	495AS	CONE		40024	2	2CA	90172	40024	5CB	ASSEMBLY	EP .0080		78 110
	493D	CUP		40024	1	1CB	90248	40024	5CB	ASSEMBLY	EP .0160		78 110
	X2S-495AS	CONE SPCR		20000	1	04B							

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	SGC DESC	END PLAY OR PRELOAD	OR -	OBSOLETE DATE
	495AS	CONE		30000	-2	2CF	90314	30000	6CB ASSEMBLY	EP .0020		
	493DC	CUP		30000	1	1CG	90167	30000	6CB ASSEMBLY	EP .0050		
	X15-495AS	CONE	SPCR A	0	1	04B						
495AX	495AX	CONE		40024	2	2CL	90191	40024	5CB ASSEMBLY	EP .0100		
	493D	CUP		40024	1	1CB	90135	40024	5CB ASSEMBLY	EP .0120		
	X15-495A	CONE	SPCR A	20000	1	04Q						
495AXB	495AXB	CONE		00	2	2CF	90244	00	7CB ASSEMBLY			90 122
	493D	CUP		00	1	1CG						
495-B	495-B	CONE		00	1	2CF	90124	00	7CA ASSEMBLY			90 122
	492A	CUP		00	1	1CF						
	495-B	CONE		00-227	1	2CF	90197	00-227	7CA ASSEMBLY			90 122
	492A	CUP		00-227	1	1CF						
	495-B	CONE		00	1	2CF	90033	00	7CA ASSEMBLY			90 122
	493-B	CUP		00	1	1CH						
	495-B	CONE		00	2	2CF	90079	00	7CB ASSEMBLY			90 122
	493D	CUP		00	1	1CG						
	495-B	CONE		00	2	2CF	90305	00	7CB ASSEMBLY	EP .0000		90 122
	493D	CUP		00	1	1CG	90292	00	7CB ASSEMBLY	EP .0040		90 122
	X15-495	CONE	SPCR A	00	1	04Q						
	495-B	CONE		00	2	2CF	90152	00	7CB ASSEMBLY			90 122
	493DC	CUP		00	1	1CG						
495-S	495-S	CONE		0	1	2CF	90151	0	6CA ASSEMBLY			
	492A	CUP		0	1	1CF						
	495-S	CONE		0	1	2CF	90227	0	6CA ASSEMBLY			
	493	CUP		0	1	1CF						
	495-S	CONE		0-174	1	2CF	90093	0-174	6CA ASSEMBLY			
	493	CUP		0	1	1CF						
	495-S	CONE		0	1	2CF	90083	0	6CA ASSEMBLY			
	493-B	CUP		0	1	1CH						
	495-S	CONE		20024	2	2CA	90209	20024	5CB ASSEMBLY	EP .0080		
	493D	CUP		20024	1	1CB	90034	20024	5CB ASSEMBLY	EP .0120		
	X15-495-S	CONE	SPCR A	20000	1	04B						
	495-S	CONE		30000	2	2CF	90140	30000	6CB ASSEMBLY	EP .0040		
	493D	CUP		30000	1	1CG	90250	30000	6CB ASSEMBLY	EP .0050		
	X15-495-S	CONE	SPCR A	0	1	04B						
	495-S	CONE		40024	2	2CA	90036	40024	5CB ASSEMBLY	EP .0080		
	493D	CUP		40024	1	1CB	90233	40024	5CB ASSEMBLY	EP .0120		
	X15-495-S	CONE	SPCR A	20000	1	04B						
	495-S	CONE		0	2	2CF	90329	0	6CA ASSEMBLY	EP .0010		
	493D	CUP		0	1	1CG						
	X15-495-S	CONE	SPCR A	0	1	04B						
	495-S	CONE		20016	2	2CA	90035	20089	5CB ASSEMBLY	EP .0080		
	493D	CUP		20081	1	1CB						
	X25-495-S	CONE	SPCR A1	20000	1	04B						
495H	495H	CONE		0	1	2CF	90129	0	6CA ASSEMBLY			
	493-B	CUP		0	1	1CH						
495XA	495XA	CONE		0	2	2CF	90331	0	6CB ASSEMBLY			
	493D	CUP		0	1	1CG						
NA495A	NA495A	CONE		20194	2	2CA	90038	20194	5CB ASSEMBLY	EP .0200		
	493D	CUP		20081	1	1CB						

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q/A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
	NA495A 493D	CONE CUP		20199 20081		2 2CA 1 1CB	90189 90039	20199 20199		5CB ASSEMBLY 5CB ASSEMBLY	EP .0020 EP .0130	
	NA495A 493D	CONE CUP		30000 30001		2 2CF 1 1CG	90037	30000		6CB ASSEMBLY	EP .0040	
NA495-SH 493D	NA495-SH 493D	CONE CUP		20194 20081		2 2CA 1 1CB	90132	20194		5CB ASSEMBLY	EP .0200	
496	496 492A	CONE CUP		0 0		1 2CF 1 1CF	90205	0		6CA ASSEMBLY		
	496 492A	CONE CUP		0-30 0		1 2CF 1 1CF	90188	0-30		6CA ASSEMBLY		
496	496 493	CONE CUP		0 0		1 2CF 1 1CF	90040	0		6CA ASSEMBLY		
	496 493	CONE CUP		0-30 0		1 2CF 1 1CF	90113	0-30		6CA ASSEMBLY		
496	496 493	CONE CUP		40024 40024		2 2CE 2 1CE	90171	40024		5CA ASSEMBLY	EP .0120	90 302
	Y3S-493	CUP SPCR R		20000		1 04C						
496	496 493	CONE CUP		0 0		2 2CF 1 1CF	905A3 905A4	0 0		6CA ASSEMBLY 6CA ASSEMBLY	EP .0050 EP .0100	
	Y4S-493	CUP SPCR Q		0		1 04R						
496	496 493-B	CONE CUP		0 0		1 2CF 1 1CH	90041	0		6CA ASSEMBLY		
	496 493D	CONE CUP		0 0		2 2CF 1 1CG	90042	0		6CB ASSEMBLY		
496	496 493D	CONE CUP		20024 20024		2 2CE 1 1CB	90089 90126	20024 20024		5CD ASSEMBLY 5CB ASSEMBLY	EP .0080 EP .0100	
	X1S-496	CONE SPCR A		20000		1 04Q						
496	496 493D	CONE CUP		20157 20024		2 2CF 1 1CB	90264 90080	20214 20214		5CB ASSEMBLY 5CB ASSEMBLY	EP .0030 EP .0100	
	X1S-496	CONE SPCR A		20000		1 04Q						
496	496 493D	CONE CUP		20157 20157		2 2CE 1 1CB	90081 90048	20157 20157		5CB ASSEMBLY 5CB ASSEMBLY	EP .0070 EP .0080	
	X1S-496	CONE SPCR A		20000		1 04Q						
496	496 493D	CONE CUP		30000 30000		2 2CF 1 1CG	90043 90044	30000 30000		6CB ASSEMBLY 6CB ASSEMBLY	EP .0000 EP .0020	
	X1S-496	CONE SPCR A		0		1 04Q	90045	30000		6CB ASSEMBLY	EP .0030	
						90046	30000		6CB ASSEMBLY	EP .0040		
						90047	30000		6CB ASSEMBLY	EP .0050		
	496 493D	CONE CUP		40024 40024		2 2CE 1 1CB	90049 90091	40024 40024		5CB ASSEMBLY 5CB ASSEMBLY	EP .0080 EP .0100	
X1S-496	CONE SPCR A		20000		1 04Q	90050 90325	40024 40024		5CB ASSEMBLY 5CB ASSEMBLY	EP .0120 EP .0160		
496	496 493D	CONE CUP		0 0		2 2CF 1 1CG	90254 90195	0 0		6CB ASSEMBLY 6CB ASSEMBLY	EP .0010 EP .0015	
	X1S-496	CONE SPCR A		0		1 04Q	90117	0		5CB ASSEMBLY	EP .0050	
496 493D	CONE CUP		0-30 0		2 2CF 1 1CG	90321	0-30		6CB ASSEMBLY	EP .0010		
X1S-496	CONE SPCR A		0		1 04Q							
496	496 493D	CONE CUP		40024 40024		2 2CE 1 1CB	90326 90192	40024 40024		5CB ASSEMBLY 5CB ASSEMBLY	EP .0080 EP .0120	
	X2S-496	CONE SPCR A1		20000		1 04B	90078	40024		5CB ASSEMBLY	EP .0140	

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q/A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
	496 493DC	CONE CUP		0 0	2	2CF 1ICG	90281	0		6CB ASSEMBLY		
	496 493DC X15-496	CONE CUP CONE SPCR A		30000 30000 0	2	2CF 1ICG 104Q	90272	30000		6CB ASSEMBLY	EP .0050	
	496 493DC X15-496	CONE CUP CONE SPCR A		40024 40024 20000	2	2CE 1ICB 104Q	90329 90258	40024 40024		5CB ASSEMBLY 5CB ASSEMBLY	EP .0100 EP .0120	
	496 493DC X15-496	CONE CUP CONE SPCR A		0 0 0	2	2CF 1ICG 104Q	90280	0		6CB ASSEMBLY	EP .0030	
	496 494-B	CONE CUP		0 0	1	2CF 1ICH	905A2	0		6CA ASSEMBLY		
496AS	496AS 493 Y65-493	CONE CUP CUP SPCR Q		70016 20082 20000	2	2CA 1ICE 104R	90133	70016		5CA ASSEMBLY	EP .0090	
496-B	496-B 493	CONE CUP		00 00	1	2CF 1ICF	90108	00		7CA ASSEMBLY		90 122
496D	496D 492A	CONE CUP		0 0	2	2CG 1ICF	90200	0		6CP ASSEMBLY		
	496D 492A Y15-492A	CONE CUP CUP SPCR		0 0 0	1	2CG 2ICF 104C	90196	0		6CP ASSEMBLY	EP .0015	78 110
	496D 492A Y25-492A	CONE CUP CUP SPCR S		40024 40024 20000	1	2CB 1ICL 104C	90297 90276	40024 40024		5CP ASSEMBLY 5CP ASSEMBLY	EP .0060 EP .0120	
	496D 493 493D Y45-493	CONE CUP CUP CUP SPCR Q		40024 40024 40024 20000	2	2CB 2ICE 1ICB 204R	90054	40024		5CQ ASSEMBLY	EP .0050	90 302
	496D 493 493D Y45-493 X15-496	CONE CUP CUP CUP SPCR Q CONE SPCR A		40024 4E024 20081 2E000 2E000	2	2CB 2ICE 1ICB 204R 104Q	9E4A1	4E024		5CQ ASSEMBLY	EP .0160	
	496D 493 493D Y45-493 X15-496	CONE CUP CUP CUP SPCR Q CONE SPCR A		40024 40024 40024 20000 20000	2	2CB 2ICE 1ICB 204R 104Q	90243	40024		5CQ ASSEMBLY	EP .0160	
	496D 493 Y35-493	CONE CUP CUP SPCR R		20024 20024 20000	1	2CB 2ICE 104C	90161	20024		5CP ASSEMBLY	EP .0020	
	496D 493 Y35-493	CONE CUP CUP SPCR R		40024 40024 20000	1	2CB 2ICE 104C	90052 90316	40024 40024		5CP ASSEMBLY 5CP ASSEMBLY	EP .0100 EP .0120	90 302
	496D 493 Y45-493	CONE CUP CUP SPCR Q		20024 20024 20000	1	2CB 2ICE 104R	9U153	2U024		5CP ASSEMBLY	EP .0080	
	496D 493 Y45-493	CONE CUP CUP SPCR Q		20024 20024 20000	1	2CB 2ICE 104R	90153	20024		5CP ASSEMBLY	EP .0080	

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OR	OBSOLETE DATE
	496D	CONE		40024	1	2CB	90053	40024	5CP	ASSEMBLY	EP .0040		90 302
	493	CUP		40024	2	1CE	90261	40024	5CP	ASSEMBLY	EP .0080		90 302
	Y4S-493	CUP SPCR	Q	20000	1	04R	90260	40024	5CP	ASSEMBLY	EP .0100		90 302
							90116	40024	5CP	ASSEMBLY	EP .0120		
496DA	496DA	CONE		20024	1	2CB	90324	20024	5CP	ASSEMBLY	EP .0200		
	493	CUP		20024	2	1CE							
	Y4S-493	CUP SPCR	Q	20000	1	04R							
	496DA	CONE		20448	1	2CB	90328	20448	5CP	ASSEMBLY	EP .0200		
	493	CUP		20448	2	1CA							
	Y4S-493	CUP SPCR	Q	20000	1	04R							
	496DA	CONE		40024	1	2CB	90270	40024	5CP	ASSEMBLY	EP .0080		90 302
	493	CUP		40024	2	1CE							
	Y4S-493	CUP SPCR	Q	20000	1	04R							
	496DA	CONE		40082	1	2CB	90055	40082	5CP	ASSEMBLY	EP .0090		
	493	CUP		40082	2	1CE							
	Y6S-493	CUP SPCR	Q	20000	1	04R							
496-S	496-S	CONE		0	1	2CF	90220	0	6CA	ASSEMBLY			74 100
	493	CUP		0	1	1CF							
497	497	CONE		0	1	2CF	90056	0	6CA	ASSEMBLY			
	492A	CUP		0	1	1CF							
	497	CONE		0-30	1	2CF	90210	0-30	6CA	ASSEMBLY			
	492A	CUP		0	1	1CF							
	497	CONE		20024	2	2CE	90312	20024	5CA	ASSEMBLY	EP .0200		
	492A	CUP		20024	2	1CL							
	Y4S-492A	CUP SPCR	RSR	20000	1	04C							
	X2S-497	CONE SPCR	A1	20000	1	04B							
	497	CONE		0	1	2CF	90285	0	6CA	ASSEMBLY			
	492H	CUP		0	1	1CF							
	497	CONE		30580	1	2CF	90334	30580	6CA	ASSEMBLY			
	493	CUP		30000	1	1CF							
	497	CONE		0	1	2CF	90057	0	6CA	ASSEMBLY			
	493	CUP		0	1	1CF							
	497	CONE		0-174	1	2CF	90309	0-174	6CA	ASSY			
	493	CUP		0	1	1CF							
	497	CONE		0-227	1	2CF	905A5	0-227	6CA	ASSEMBLY			
	493	CUP		0-227	1	1CF							
	497	CONE		40024	2	2CE	90239	40286	5CA	ASSEMBLY	EP .0200		78 110
	493	CUP		40286	2	1CA							
	Y14S-493	CUP SPCR		20000	1	04C							
	X7S-497	CONE SPCR		20000	1	04B							
	497	CONE		40024	2	2CE	90058	40024	5CA	ASSEMBLY	EP .0120		90 302
	493	CUP		40024	2	1CE							
	Y2S-493	CUP SPCR	R	20000	1	04C							
	X1S-497	CONE SPCR	A	20000	1	04B							
	497	CONE		20024	2	2CE	902A7	20024	5CA	ASSEMBLY	EP .0060		
	493	CUP		20024	2	1CE	902B1	20024	5CA	ASSEMBLY	EP .0080		
	Y4S-493	CUP SPCR	Q	20000	1	04R	90307	20024	5CA	ASSEMBLY	EP .0120		
	497	CONE		20227	2	2CA	902A6	20227	5CA	ASSEMBLY	EP .0060		
	493	CUP		20227	2	1CA							
	Y4S-493	CUP SPCR	Q	20000	1	04R							
	497	CONE		40024	2	2CE	90323	40024	5CA	ASSEMBLY	EP .0080		
	493	CUP		40024	2	1CE							
	Y4S-493	CUP SPCR	Q	20000	1	04R							

ASSEMBLY
PART NUMBERCOMPONENT
PART NUMBER

DESC

SP
TYCOMP
INSP

Q/A

COMP
SGCASSY
CODEASSY
INSP

SGC

ASSY
DESCEND PLAY
PRELGAD

Q/P

OBSOLETE
DATE

497	CONE			40024	2	2CE	90136	40024	5CA	ASSEMBLY	EP	.0100	90	302
493	CUP			40024	2	1CE								
775-493	CUP SPCR			20000	1	04C								
X45-497	CONE SPCR			20000	1	04B								
497	CONE			40024	2	2CE	90160	40024	5CA	ASSEMBLY	EP	.0190	90	302
493	CUP			40024	2	1CE								
X55-497	CONE SPCR			20000	1	04B								
497	CONE			30580	1	2CF	90333	30580	6CA	ASSEMBLY				
493-B	CUP			30000	1	1CH								
497	CONE			0	1	2CF	90059	0	6CA	ASSEMBLY				
493-B	CUP			0	1	1CH								
497	CONE			0-30	1	2CF	90060	0-30	6CA	ASSEMBLY				
493-B	CUP			0	1	1CH								
497	CONE			0-30	1	2CF	90187	0-33	6CA	ASSEMBLY				
493-B	CUP			0-39	1	1CH								
497	CONE			30000	2	2CF	90224	30227	6CB	ASSEMBLY				
493D	CUP			30000	1	1CG								
497	CONE			0	2	2CF	90097	0	6CB	ASSEMBLY				
493D	CUP			0	1	1CG								
497	CONE			40024	4	2CE	90219	40024	5CC	ASSEMBLY	EP	.0200		
493D	CUP			40024	2	1CB								
735-493	CUP SPCR R			20000	1	04C								
X35-497	CONE SPCR A			20000	2	04Q								
497	CONE			20024	2	2CE	90206	20024	5CB	ASSEMBLY	EP	.0120		
493D	CUP			20024	1	1CB								
X25-497	CONE SPCR A1			20000	1	04B								
497	CONE			30000	2	2CF	903A1	30000	6CB	ASSEMBLY	EP	.0040		
493D	CUP			30000	1	1CG								
X25-497	CONE SPCR A1			0	1	04B								
497	CONE			2E024	2	2CA	9E2A1	2E024	5CB	ASSEMBLY	EP	.0010		
493D	CUP			20081	1	1CB								
X35-497	CONE SPCR A			2E000	1	04Q								
497	CONE			20024	2	2CE	90131	20024	5CB	ASSEMBLY	EP	.0030		
493D	CUP			20024	1	1CB	90063	20024	5CB	ASSEMBLY	EP	.0080		
X35-497	CONE SPCR A			20000	1	04Q	90064	20024	5CB	ASSEMBLY	EP	.0100		
							90065	20024	5CB	ASSEMBLY	EP	.0120		
							90141	20024	5CB	ASSEMBLY	EP	.0160		
497	CONE			20024	2	2CE	902A8	20649	5CB	ASSEMBLY				
493D	CUP			20024	1	1CB								
X35-497	CONE SPCR A			40000	1	04Q								
497	CONE			20157	2	2CE	90148	20214	5CB	ASSEMBLY	EP	.0110		
493D	CUP			20024	1	1CB								
X35-497	CONE SPCR A			20000	1	04Q								
497	CONE			30000	2	2CF	90255	30000	6CB	ASSEMBLY	EP	.0010		
493D	CUP			30000	1	1CG	90090	30000	6CB	ASSEMBLY	EP	.0020		
X35-497	CONE SPCR A			0	1	04Q	90061	30000	6CB	ASSEMBLY	EP	.0030		
							90145	30000	6CB	ASSEMBLY	EP	.0040		
							90179	30000	6CB	ASSEMBLY	EP	.0050		
							90138	30000	6CB	ASSEMBLY	EP	.0060		
							90174	30000	6CB	ASSEMBLY	EP	.0080		
497	CONE			40024	2	2CE	90123	40024	5CB	ASSEMBLY	EP	.0080		
493D	CUP			40024	1	1CB	90154	40024	5CB	ASSEMBLY	EP	.0100		
X35-497	CONE SPCR A			20000	1	04Q	90066	40024	5CB	ASSEMBLY	EP	.0120		
							90204	40024	5CB	ASSEMBLY	EP	.0200		

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q/A	COMP SGC	ASSY CODE	ASSY INSP	ASSY SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
	497	CONE		0		2 2CF	90100	0		6CB ASSEMBLY	EP .0020	
	493D	CUP		0		1 1CG	90249	0		6CB ASSEMBLY	EP .0040	
	X35-497	CONE SPCR A		0		1 04Q	90225	0		6CB ASSEMBLY	EP .0050	
							90162	0		6CB ASSEMBLY	EP .0060	
	497	CONE		20024		2 2CE	90291	20024		5CB ASSEMBLY	EP .0040	
	493DC	CUP		20024		1 1CB	90213	20024		5CB ASSEMBLY	EP .0120	
	X35-497	CONE SPCR A		20000		1 04Q						
	497	CONE		30000		2 2CF	90327	30000		6CB ASSEMBLY	EP .0010	
	493DC	CUP		30000		1 1CG	90274	30000		6CB ASSEMBLY	EP .0020	
	X35-497	CONE SPCR A		0		1 04Q	90259	30000		6CB ASSEMBLY	EP .0040	
							90202	30000		6CB ASSEMBLY	EP .0060	
							90310	30000		6CB ASSY	EP .0080	
							90320	30000		6CB ASSEMBLY	EP .0120	
	497	CONE		4E024		2 2CA	9E4A2	4E024		5CB ASSEMBLY	EP .0100	
	493DC	CUP		4E024		1 1CB						
	X35-497	CONE SPCR A		2E000		1 04Q						
	497	CONE		40024		2 2CE	90193	40024		5CB ASSEMBLY	EP .0120	
	493DC	CUP		40024		1 1CB						
	X35-497	CONE SPCR A		20000		1 04Q						
	497	CONE		0		2 2CF	90293	0		6CB ASSEMBLY	EP .0050	
	493DC	CUP		0		1 1CG	90185	0		6CB ASSEMBLY	EP .0060	
	X35-497	CONE SPCR A		0		1 04Q						
	497	CONE		00		2 2CF	90332	00		7CB ASSEMBLY	EP .0020	
	493DC	CUP		00		1 1CG						
	X35-497	CONE SPCR A		0		1 04Q						
497A	497A	CONE		0		2 2CF	90296	0		6CB ASSEMBLY		
	493D	CUP		0		1 1CG						
	497A	CONE		20024		4 2CL	90256	20024		5CC ASSEMBLY	EP .0100	
	493D	CUP		20024		2 1CB						
	X35-497	CUP SPCR R		20000		1 04C						
	X35-497	CONE SPCR A		20000		2 04Q						
	497A	CONE		20024		2 2CL	90226	20024		5CB ASSEMBLY	EP .0100	
	493D	CUP		20024		1 1CB	90278	20024		5CB ASSEMBLY	EP .0120	
	X35-497	CONE SPCR A		20000		1 04Q						
	497A	CONE		30434		2 2CF	90331	30434		6CB ASSEMBLY	EP .0000	
	493D	CUP		30039		1 1CG						
	X35-497	CONE SPCR A		0		1 04Q						
	497A	CONE		40024		2 2CL	90275	40024		5CB ASSEMBLY	EP .0080	
	493D	CUP		40024		1 1CB	90268	40024		5CB ASSEMBLY	EP .0120	
	X35-497	CONE SPCR A		20000		1 04Q	90313	40024		5CB ASSEMBLY	EP .0160	
497-B	497-B	CONE		00		1 2CF	90115	00		7CA ASSEMBLY		90 122
	492A	CUP		00		1 1CF						
	497-B	CONE		00		1 2CF	90180	00		7CA ASSEMBLY		90 122
	493	CUP		00		1 1CF						
	497-B	CONE		00		1 2CF	90067	00		7CA ASSEMBLY		90 122
	493-B	CUP		00		1 1CH						
	497-B	CONE		00		2 2CF	90198	00		7CB ASSEMBLY		90 122
	493D	CUP		00		1 1CG						
	497-B	CONE		00		2 2CF	90125	00		7CB ASSEMBLY	EP .0040	90 122
	493DC	CUP		00		1 1CG						
	X35-497	CONE SPCR A		00		1 04Q						
497H	497H	CONE		0		1 2CF	90282	0		6CA ASSEMBLY		
	493-B	CUP		0		1 1CH						

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE	
NA497-SH	NA497-SH K109597 K109596	CONE CUP SEAL		20000 20001	2	2CA 1 ICK 2 090	90221	20000	5CD	ASSEMBLY	EP .0000	.0050	
	NA497-SH K109597 K109596	CONE CUP SEAL		20142 20001	2	2CA 1 ICK 2 090	90294 90303	20142 20142	5CD 5CD	ASSEMBLY ASSEMBLY	EP .0050 EP .0100	.0080 .0150	
	NA497-SH K109597 K109596	CONE CUP SEAL		20229 20229	2	2CA 1 ICK 2 090	90316	20229	5CD	ASSEMBLY	EP .0070	.0080	
	NA497-SH K312462 K109596	CONE CUP SEAL		20000 20001	2	2CA 1 IDK 2 090	90235	20000	5DD	ASSEMBLY	EP .0000	.0050	
	NA497-SH K312462 K109596	CONE CUP SEAL		20000 20229	2	2CA 1 IDK 2 090	902A9	20229	5DD	ASSEMBLY	EP .0000	.0050	
	NA497-SH K312463 K109596	CONE CUP SEAL		20000 20001	2	2CA 1 IEK 2 090	90236	20000	5DD	ASSEMBLY	EP .0000	.0050	
	NA497-SH K312461 K109596	CONE CUP SEAL		20000 20411	2	2CA 1 IDK 2 090	90242	20411	5DD	ASSEMBLY	EP .0000	.0050	75 188
	NA497-SH K326071 K109596	CONE CUP SEAL		20000 20001	2	2CA 1 IDK 2 090	90223	20000	5DD	ASSEMBLY	EP .0000	.0050	
	U497	U497 U460L	CONE CUP		4A000 4A000	1	2AA 1 1BA	9A4A4	UA661	544	ASSEMBLY	EP .0080	.0160
		U497 U460L	CONE CUP		4A000 4A000	1	2AA 1 1BA	9A4A3	4A000	544	ASSEMBLY	EP .0100	.0210
498	498 492A	CONE CUP		0 0	1	2CF 1 ICF	90266	0	6CA	ASSEMBLY			
	498 492A	CONE CUP		0-30 0	1	2CF 1 ICF	90228	0-30	6CA	ASSEMBLY			
	498 492A Y25 492A	CONE CUP CUP SPCR	S	40024 40024 20000	2	2CE 2 ICL 1 04C	90173	40024	5CA	ASSEMBLY	EP .0100		
	498 492H X35 498	CONE CUP CONE SPCR	A	30000 30000 0	2	2CF 2 ICF 1 04B	90069	30000	6CA	ASSEMBLY	EP .0020		
	498 493	CONE CUP		0 0	1	2CF 1 ICF	90070	0	6CA	ASSEMBLY			
	498 493 Y45 493	CONE CUP CUP SPCR	Q	40024 40024 20000	2	2CE 2 ICF 1 04R	90240	40024	5CA	ASSEMBLY	EP .0120	90 302	
	498 493A	CONE CUP		0 0	1	2CF 1 ICF	90330	0	6CA	ASSEMBLY			
	498 493 B	CONE CUP		0 0	1	2CF 1 ICH	90071	0	6CA	ASSEMBLY			
	498 493 B	CONE CUP		0-30 Q	1	2CF 1 ICH	90315	0-30	6CA	ASSEMBLY			
	498 493D X15 498	CONE CUP CONE SPCR	A	20024 20024 20000	2	2CE 1 ICB 1 04B	90072	20024	5CB	ASSEMBLY	EP .0120		

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
	498	CONE		30000	2	2CF	90142	30000	6CB	ASSEMBLY	EP .0060	
	493D	CUP		30000	1	1CG	90331	30000	6CB	ASSEMBLY	EP .0070	
	X15-498	CONE SPCR A		0	1	04B						
	498	CONE		40024	2	2CE	90073	40024	5CB	ASSEMBLY	EP .0060	
	493D	CUP		40024	1	1CB	90170	40024	5CB	ASSEMBLY	EP .0080	
	X15-498	CONE SPCR A		20000	1	04B	90068	40024	5CB	ASSEMBLY	EP .0120	
	498	CONE		20024	2	2CE	90074	20024	5CB	ASSEMBLY	EP .0080	
	493D	CUP		20024	1	1CB						
	X45-498	CONE SPCR AA		20000	1	04B						
	498	CONE		30000	2	2CF	90232	30000	6CB	ASSEMBLY	EP .0020	
	493DC	CUP		30000	1	1CG						
	X15-498	CONE SPCR A		0	1	04B						
	498	CONE		40024	2	2CE	90184	40024	5CB	ASSEMBLY	EP .0100	
	493DC	CUP		40024	1	1CB	90288	40024	5CB	ASSEMBLY	EP .0120	
	X15-498	CONE SPCR A		20000	1	04B						
	498	CONE		0	2	2CF	90165	0	6CB	ASSEMBLY	EP .0050	
	493DC	CUP		0	1	1CG						
	X15-498	CONE SPCR A		0	1	04B						
	498	CONE		40024	1	2CE	90122	40024	5CA	ASSEMBLY	EP .0120	78 110
	HM516449	CONE		40024	1	2CP						
	492A	CUP		40024	1	1CL						
	HM516410	CUP		40024	1	1CL						
	Y15-492A	CUP SPCR		20000	1	04C						
498-B	498 B	CONE		00	1	2CF	90075	00	7CA	ASSEMBLY		90 122
	493	CUP		00	1	1CF						
498D	498D	CONE		20024	1	2CB	90299	20024	5CP	ASSEMBLY	EP .0160	81 342
	492A	CUP		20024	2	1CL	90308	20024	5CP	ASSEMBLY	EP .0280	
	Y35-492A	CUP SPCR S		20000	1	04C						
	498D	CONE		2E024	1	2CB	9G106	2G024	5CP	ASSEMBLY	EP .0120	
	493	CUP		20024	2	1CE						
	Y55-493	CUP SPCR Q		20000	1	04C						
	498D	CONE		20024	1	2CB	90106	20024	5CP	ASSEMBLY	EP .0120	
	493	CUP		20024	2	1CE						
	Y55-493	CUP SPCR Q		20000	1	04C						
	498D	CONE		28024	1	2CB	98106	28024	5CP	ASSEMBLY	EP .0120	86 037
	493	CUP		20024	2	1CE						
	Y55-493	CUP SPCR Q		20000	1	04C						
	498D	CONE		30000	1	2CG	90102	30000	6CP	ASSEMBLY	EP .0120	81 342
	493	CUP		30000	2	1CF						
	Y55-493	CUP SPCR Q		0	1	04C						
	498D	CONE		4E024	1	2CB	9E203	4E024	5CP	ASSEMBLY	EP .0080	90 302
	493	CUP		40024	2	1CE						
	Y55-493	CUP SPCR Q		20000	1	04C						
	498D	CONE		4E024	1	2CB	9G203	4G024	5CP	ASSEMBLY	EP .0080	
	493	CUP		40024	2	1CE						
	Y55-493	CUP SPCR Q		20000	1	04C						
	498D	CONE		40024	1	2CB	90203	40024	5CP	ASSEMBLY	EP .0080	90 302
	493	CUP		40024	2	1CE	90137	40024	5CP	ASSEMBLY	EP .0120	90 302
	Y55-493	CUP SPCR Q		20000	1	04C						
	498D	CONE		48024	1	2CB	98203	48024	5CP	ASSEMBLY	EP .0080	90 302
	493	CUP		40024	2	1CE	98137	48024	5CP	ASSEMBLY	EP .0120	90 302
	Y55-493	CUP SPCR Q		20000	1	04C						

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q/A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
	498D 493 Y55-493	CONE CUP CUP SPCR	Q	70000 20024 20000	2	2CB 1CE 04C	90212	70000	5CP	ASSEMBLY	EP .0080	81 342
	498D 493 Y55-493	CONE CUP CUP SPCR	Q	78000 20024 20000	2	2CB 1CE 04C	98212	78000	5CP	ASSEMBLY	EP .0080	86 037
498H	498H 493-B	CONE CUP		0 0	1	2CF 1CH	90130	0	6CA	ASSEMBLY		
499A	499A 493X	CONE CUP		0 0-39	1	2CF 1CF	90320	0-39	6CA	ASSEMBLY		
	499A 493X	CONE CUP		0-342 0-342	1	2CF 1CF	90319	0-342	6CA	ASSEMBLY		
	499A 493X	CONE CUP		0-623 0-39	1	2CF 1CF	90323	0-623	6CA	ASSEMBLY		
	499A 494-B	CONE CUP		0 0-39	1	2CF 1CH	90321	0-39	6CA	ASSEMBLY		
	499A 494-B	CONE CUP		0-342 0	1	2CF 1CH	90318	0-342	6CA	ASSEMBLY		
	499A 494-B	CONE CUP		0-623 0-39	1	2CF 1CH	90322	0-623	6CA	ASSEMBLY		
4991	4991 493	CONE CUP		0 0	1	2CF 1CF	90076	0	6CA	ASSEMBLY		
	4991 493-B	CONE CUP		0 0	1	2CF 1CH	90217	0	6CA	ASSEMBLY		
U499	U499 U460L	CONE CUP		4A000 4A000	1	2AA 1BA	9A010 9A011	4A000 4A000	544 544	ASSEMBLY ASSEMBLY	EP .0150-.0210	91 029 90 355
	U499 U460L	CONE CUP		40000 40000	1	2AA 1BA	90010 90011	40000 40000	544 544	ASSEMBLY ASSEMBLY	EP .0150-.0210	90 255 89 228
	U499 U460L	CONE CUP		40000 40000	1	2AA 1BA	95010	45000	544	ASSEMBLY		90 355
	U499 U460L	CONE CUP		40227 40227	1	2AA 1BA	904A1 904A2	40227 40227	544 544	ASSEMBLY ASSEMBLY	EP .0150 EP .0210	90 276 90 276
1511	1511 1511C 15005	RACE THR CAGE ROLLER		2E000	2	075 062 010	9G015	2G000	357	THR BRG		
	1511 1511C 15005	RACE THR CAGE ROLLER		28000	2	075 062 010	98015	20000	357	ASSEMBLY		86 037
	1511 1511C 15005	RACE THR CAGE ROLLER		30000	2	075 062 010	903A2	30662	357	THR BRG		
1511F	1511F 15005	THR BRG ROLLER		2E000	2	075 010	9E2A1	2E000	357	THR BRG		
1511FS	1511FS 1511-S 15005	RACE RACE ROLLER		20000 20000	1	075 075 010	90011	20000	357	THR BRG		
	1511FS 1511-SB 15005	RACE RACE ROLLER		20000 20000	1	075 075 010	90016	20000	357	THR BRG		

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q/A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
1511FSA	1511FSA	RACE		20000		1 075	90014	20000	357	THR BRG		
	1511-S	RACE		20000		1 075						
	15005	ROLLER				25 010						
1511FSA	1511FSA	RACE		20448		1 075	90013	20448	357	THR BRG		
	1511-S	RACE		20448		1 075						
	15005	ROLLER				25 010						
1511FSA	1511FSA	RACE		20000		1 075	90012	20000	357	THR BRG		
	1511-SA	RACE		20000		1 075						
	15005	ROLLER				25 010						
	K116208	PLUG				1 490						
522RB	522RB	CUP		20355		1 1BA	90026	20355	541	ASSEMBLY		74 100
	K95579	SNAP RING				1 090						
525	525	CONE		0		1 2BF	90010	0	6BA	ASSEMBLY		
	522	CUP		0		1 1BF						
527	527	CONE		0		1 2BF	90011	0	6BA	ASSEMBLY		
	522	CUP		0		1 1BF						
528	527	CONE		0-30		1 2BF	90024	0-30	6BA	ASSEMBLY		
	522	CUP		0		1 1BF						
	528	CONE		0		1 2BF	90012	0	6BA	ASSEMBLY		
	522	CUP		0		1 1BF						
528	528	CONE		0-30		1 2BF	90023	0-30	6BA	ASSEMBLY		
	522	CUP		0		1 1BF						
	528	CONE		0		1 2BF	90013	0	6BA	ASSEMBLY		
	522-B	CUP		0		1 1BH						
528A	528A	CONE		0		1 2BF	90022	0	6BA	ASSEMBLY		
	522	CUP		0		1 1BF						
529	529	CONE		0		1 2BF	90015	0	6BA	ASSEMBLY		
	522	CUP		0		1 1BF						
529	529	CONE		40024		2 2BL	90021	40024	5BA	ASSEMBLY	EP .0080	
	522	CUP		40024		2 1BL						
	Y1S-522	CUP SPCR Q		20000		1 04B						
	X1S-529	CONE SPCR A		20000		1 04A						
529-B	529	CONE		0		1 2BF	90016	0	6BA	ASSEMBLY		
	522-B	CUP		0		1 1BH						
	529-B	CONE		00		1 2BF	90017	00	7BA	ASSEMBLY		
	522	CUP		00		1 1BF						
529-B	529-B	CONE		00		1 2BF	90018	00	7BA	ASSEMBLY		
	522-B	CUP		00		1 1BH						
	529-B	CONE		00-153		1 2BF	90019	00-153	7BA	ASSEMBLY		75 217
	522-B	CUP		00-153		1 1BH						
529X	529X	CONE		0		1 2BF	90020	0	6BA	ASSEMBLY		
	522	CUP		0		1 1BF						
535	529X	CONE		0		1 2BF	90025	0	6BA	ASSEMBLY		
	522-B	CUP		0		1 1BH						
	535	CONE		0		1 2BF	90010	0	6BA	ASSEMBLY		
	532A	CUP		0		1 1BF						
535	535	CONE		0		1 2BF	90011	0	6BA	ASSEMBLY		
	532X	CUP		0		1 1BF						
536	536	CONE		0-H000		1 2BF	98033	0-8000	6BA	ASSEMBLY		86 037
	532A	CUP		0		1 1BF						

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q'A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
	536 532A	CONE CUP		0 0		1 2BF 1 1BF	90033	0		6BA ASSEMBLY		
	536 532-B	CONE CUP		0-H000 0		1 2BF 1 1CH	98012	0-8000		6CA ASSEMBLY		86 037
	536 532-B	CONE CUP		0 0		1 2BF 1 1CH	90012	0		6CA ASSEMBLY		
	536 532X	CONE CUP		0-H000 0		1 2BF 1 1BF	9G013	0-G000		6BA ASSEMBLY		
	536 532X	CONE CUP		0-H000 0		1 2BF 1 1BF	98013	0-8000		6BA ASSEMBLY		86 037
	536 532X	CONE CUP		0 0		1 2BF 1 1BF	90013	0		6BA ASSEMBLY		
	536 533D X1S-536	CONE CUP CONE SPCR		40024 40024 20000		2 2BA 1 1BB 1 04A	90042	40024		5BB ASSEMBLY	EP .0080	78 110
537	537 532	CONE CUP		0 0		1 2BF 1 1BF	90014	0		6BA ASSEMBLY		
	537 532A	CONE CUP		0 0		1 2BF 1 1BF	90015	0		6BA ASSEMBLY		
	537 533D	CONE CUP		0 0		2 2BF 1 1BG	90066	0		6BB ASSEMBLY		
	537 533D X1S-537	CONE CUP CONE SPCR A		20024 20024 20000		2 2BA 1 1BB 1 04A	90067 90016	20024 20024		5BB ASSEMBLY 5BB ASSEMBLY	EP .0080 EP .0120	
	537 533D X1S-537	CONE CUP CONE SPCR A		20024 20157 20000		2 2BA 1 1BB 1 04A	90032	20157		5BB ASSEMBLY	EP .0060	
	537 533D X1S-537	CONE CUP CONE SPCR A		40024 40024 20000		2 2BA 1 1BB 1 04A	90043	40024		5BB ASSEMBLY	EP .0080	
537-B	537 B 532	CONE CUP		00 00		1 2BF 1 1BF	90054	00		7BA ASSEMBLY		90 129
	537 B 532A	CONE CUP		00 00		1 2BF 1 1BF	90044	00		7BA ASSEMBLY		90 129
537H	537H 532-B	CONE CUP		0 0		1 2BF 1 1CH	90037	0		6CA ASSEMBLY		76 280
538	538 532-B	CONE CUP		0 0		1 2BF 1 1CH	90065	0		6CA ASSEMBLY		
539	539 532	CONE CUP		0 0		1 2BF 1 1BF	90017	0		6BA ASSEMBLY		
	539 532A	CONE CUP		0 0		1 2BF 1 1BF	90018	0		6BA ASSEMBLY		
	539 532A	CONE CUP		0-30 0		1 2BF 1 1BF	90031	0-30		6BA ASSEMBLY		
	539 532-B	CONE CUP		0 0		1 2BF 1 1CH	90019	0		6CA ASSEMBLY		
	539 532Y	CONE CUP		0 0		1 2BF 1 1BF	90020	0		6BA ASSEMBLY		

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q/A	COMP SGC	ASSY CODE	ASSY INSP	ASSY SGC	ASSY DESC	END PLAT OR PRELOAD	OR DATE	OBsolete DATE
	539	CONE		0		2 2BF	90038	0	6BB	ASSEMBLY			
	539D	CUP		0		1 1BG							
	539	CONE		40024		4 2BL	90047	40024	5BC	ASSEMBLY	EP .0160		
	539D	CUP		40024		2 1BB							
	Y15-539	CUP SPCR	R	20000		1 04B							
	X25-539	CONE SPCR	BB	20000		2 04A							
	X45-539	CONE SPCR	A	20000		1 04A							
	539	CONE		40024		4 2BL	90050	40024	5BC	ASSEMBLY	EP .0160		78 110
	539D	CUP		40024		2 1BB							
	Y25-539	CUP SPCR		20000		1 04B							
	X25-539	CONE SPCR	BB	20000		2 04A							
	539	CONE		20024		2 2BL	90062	20024	5BB	ASSEMBLY	EP .0040		
	539D	CUP		20024		1 1BB	90021	20024	5BB	ASSEMBLY	EP .0380		
	X15-539	CONE SPCR	A	20000		1 04P	90022	20024	5BB	ASSEMBLY	EP .0160		
							90063	20024	5BB	ASSEMBLY	PL .0020		
	539	CONE		30000		2 2BF	90036	30000	6BB	ASSEMBLY	EP .0060		
	539D	CUP		30000		1 1BG	90056	30000	6BB	ASSEMBLY	EP .0070		
	X15-539	CONE SPCR	A	0		1 04P							
	539	CONE		40024		2 2BL	90059	40024	5BB	ASSEMBLY	EP .0070		
	539D	CUP		40024		1 1BB	90061	40024	5BB	ASSEMBLY	EP .0120		
	X15-539	CONE SPCR	A	20000		1 04P							
	539	CONE		0		2 2BF	90045	0	6BB	ASSEMBLY	EP .0050		
	539D	CUP		0		1 1BG							
	X15-539	CONE SPCR	A	0		1 04P							
	539	CONE		40024		2 2BL	90065	40024	5BB	ASSEMBLY	EP .0080		
	539D	CUP		40024		1 1BB	90023	40024	5BB	ASSEMBLY	EP .0160		
	X25-539	CONE SPCR	BB	20000		1 04A							
	539	CONE		30000		2 2BF	90064	30000	6BB	ASSEMBLY	EP .0030		
	539DC	CUP		30000		1 1BG	90041	30000	6BB	ASSEMBLY	EP .0060		
	X15-539	CONE SPCR	A	0		1 04P							
	539	CONE		40024		2 2BL	90048	40024	5BB	ASSEMBLY	EP .0080		
	539DC	CUP		40024		1 1BB							
	X15-539	CONE SPCR	A	20000		1 04P							
539A	539A	CONE		40024		2 2BL	90046	40024	5BB	ASSEMBLY	EP .0120		
	539D	CUP		40024		1 1BB	90066	40024	5BB	ASSEMBLY	EP .0160		
	X15-539	CONE SPCR	A	20000		1 04P							
539-B	539-B	CONE		00		1 2BF	90053	00	7BA	ASSEMBLY			
	532	CUP		00		1 1BF							
	539-B	CONE		00		1 2BF	90024	00	7BA	ASSEMBLY			
	532A	CUP		00		1 1BF							
	539-B	CONE		00		2 2BF	90035	00	7BB	ASSEMBLY			
	533D	CUP		00		1 1BG							
	539-B	CONE		00		2 2BF	90039	00	7BB	ASSEMBLY			
	533DC	CUP		00		1 1BG							
NA539	NA539	CONE		30000		2 2BF	90025	30000	6BB	ASSEMBLY	EP .0050		
	533D	CUP		30001		1 1BG							
	NA539	CONE		30000		2 2BF	90060	30000	6BB	ASSEMBLY	EP .0050		
	533DC	CUP		30001		1 1BG							
540	540	CONE		40024		4 2BA	90057	40024	5BC	ASSEMBLY	EP .0160		78 110
	533D	CUP		40024		2 1BB							
	Y25-539	CUP SPCR		20000		1 04B							
	X15-540	CONE SPCR		20000		2 04A							