



3192... 818
3381... C18
3449... D18
3490... E18
3535... F18
3576... G18
3767... H18
3775... I18
3775... J18
3779... K18
3780... L18
3780... M18
3782... N18
3875... O18

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q/A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
3192	3192 3120	CONE CUP		0-30 0	1	2AF 1AF	90024	0-30	6AA	ASSEMBLY		
	3192 3120	CONE CUP		0-30 0-39	1	2AF 1AF	90031	0-33	6AA	ASSEMBLY		
	3192 3129	CONE CUP		0-30 0-39	1	2AF 1AF	90032	0-33	6AA	ASSEMBLY		
3192-B	3192-B 3120	CONE CUP		00 00	1	2AF 1AF	90027	00	7AA	ASSEMBLY		
3193	3193 3120	CONE CUP		0 0	1	2AF 1AF	90018	0	6AA	ASSEMBLY		
	3193 3120-B	CONE CUP		0 0	1	2AF 1BH	90019	0	6BA	ASSEMBLY		
3196	3196 3120	CONE CUP		0 0	1	2AF 1AF	90020	0	6AA	ASSEMBLY		
	3196 3126	CONE CUP		0 0	1	2AF 1AF	90043	0	6AA	ASSEMBLY		
	3196 3130	CONE CUP		0 0	1	2AF 1AF	90030	0	6AA	ASSEMBLY		
3196-B	3196-B 3130	CONE CUP		00 00	1	2AF 1AF	90037	00	7AA	ASSEMBLY		90 108
3196T	3196T 3120	CONE CUP		0 0	1	2AF 1AF	90021	0	6AA	ASSEMBLY		75 037
3197-B	3197-B 3120	CONE CUP		00 00	1	2AF 1AF	90022	00	7AA	ASSEMBLY		90 108
3198	3198 3120	CONE CUP		0 0	1	2AF 1AF	90034	0	6AA	ASSEMBLY		
	3198 3120-B	CONE CUP		0 0	1	2AF 1BH	90028	0	6BA	ASSEMBLY		
	3198 3126	CONE CUP		0 0	1	2AF 1AF	90042	0	6AA	ASSEMBLY		
	3198 3129	CONE CUP		0 0	1	2AF 1AF	90023	0	6AA	ASSEMBLY		
3199	3199 3120	CONE CUP		0 0	1	2AF 1AF	90041	0	6AA	ASSEMBLY		
	3199 3130	CONE CUP		0 0	1	2AF 1AF	90026	0	6AA	ASSEMBLY		
3379	3379 3320	CONE CUP		0 0	1	2AF 1BF	90011	0	6BA	ASSEMBLY		
3381	3381 3320	CONE CUP		0 0	1	2AF 1BF	90012	0	6BA	ASSEMBLY		
	3381 3320 Y25-3320	CONE CUP CUP SPCR R		40024 40024 20000	2 2 1	2AA 1BL 04B	90033	40024	5BA	ASSEMBLY EP .0120		
	3381 3320 Y25-3320	CONE CUP CUP SPCR R		40082 40082 20000	2 2 1	2AA 1BL 04B	90038	40082	5BA	ASSEMBLY EP .0120		
	3381 3329	CONE CUP		0 0	1	2AF 1BF	90013	0	6BA	ASSEMBLY		

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q/A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
	3381	CONE		0		1 2AF	90014	0		6BA ASSEMBLY		
	3329-B	CUP		0		1 1BH						
3381-B	3381-B	CONE		00		1 2AF	90015	00		7BA ASSEMBLY		90 108
	3320	CUP		00		1 1BF						
3382	3382	CONE		0		1 2AF	90016	0		6BA ASSEMBLY		
	3320	CUP		0		1 1BF						
	3382	CONE		0		1 2AF	90039	0		6BA ASSEMBLY		
	3320-B	CUP		0		1 1BH						
	3382	CONE		0		1 2AF	90017	0		6BA ASSEMBLY		
	3329	CUP		0		1 1BF						
	3382	CONE		40024		2 2AA	90036	40024		5BA ASSEMBLY	EP .0140	
	3339	CUP		40024		2 1BA						
	X15-3382	CONE SPCR A		20000		1 04P						
3382-B	3382-B	CONE		00		1 2AF	90018	00		7BA ASSEMBLY		90 108
	3320	CUP		00		1 1BF						
3383	3383	CONE		0		1 2AF	90020	0		6BA ASSEMBLY		
	3320	CUP		0		1 1BF						
	3383	CONE		40024		2 2AA	90021	40024		5BA ASSEMBLY	EP .0080	
	3320	CUP		40024		2 1BL	90034	40024				
	X15-3320	CUP SPCR R		20000		1 04B						
	X15-3383	CONE SPCR A		20000		1 04A						
	3383	CONE		40024		2 2AA	90039	40024		5BA ASSEMBLY	EP .0080	
	3320	CUP		40024		2 1BL						
	Y25-3320	CUP SPCR R		20000		1 04B						
3384	3384	CONE		0		1 2AF	90023	0		6BA ASSEMBLY		
	3320	CUP		0		1 1BF						
	3384	CONE		0		1 2AF	90037	0		6BA ASSEMBLY		
	3320-B	CUP		0		1 1BH						
	3384	CONE		0		1 2AF	90035	0		6BA ASSEMBLY		
	3329	CUP		0		1 1BF						
3384TB	3384TB	CONE		00		1 2AF	90031	00		7BA ASSEMBLY		76 048
	3339	CUP		00		1 1BF						
3386	3386	CONE		0		1 2AF	90024	0		6BA ASSEMBLY		
	3320	CUP		0		1 1BF						
	3386	CONE		0		1 2AF	90025	0		6BA ASSEMBLY		
	3320-B	CUP		0		1 1BH						
3387	3387	CONE		0		1 2AF	90027	0		6BA ASSEMBLY		
	3320	CUP		0		1 1BF						
	3387	CONE		0		1 2AF	90030	0		6BA ASSEMBLY		
	3320-B	CUP		0		1 1BH						
	3387	CONE		20024		2 2AA	90032	20024		5BA ASSEMBLY	EP .0160	
	3320-B	CUP		20024		2 1BC						
	X15-3387	CONE SPCR AA		20000		1 04A						
	3387	CONE		0		1 2AF	90028	0		6BA ASSEMBLY		
	3328	CUP		0		1 1BF						
	3387	CONE		0		1 2AF	90029	0		6BA ASSEMBLY		
	3329	CUP		0		1 1BF						

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q/A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
JRM3449	JRM3449 JRM3410XD GR20 K150485	CONE CUP GREASE SHPG PLUG		U0678 U0592	2	2AD 1AR 090 469	90UA1	U0678	5AR	ASSEMBLY	EP .0035	
3474	3474 3420	CONE CUP		0	1	2AF 1BF	90010	0	6BA	ASSEMBLY		
	3474 3420-B	CONE CUP		0	1	2AF 1BH	90010	0	6BA	ASSEMBLY		
3476	3476 3420	CONE CUP		0	1	2AF 1BF	90011	0	6BA	ASSEMBLY		
	3476 3420-B	CONE CUP		0	1	2AF 1BH	90012	0	6BA	ASSEMBLY		
	3476 3422 Y15-3422	CONE CUP CUP SPCR R		40024 40024 20000	2	2AA 1BA 04Q	90032	40024	5AA	ASSEMBLY	EP .0170	
	3476 3423D X15-3476	CONE CUP CONE SPCR A		40024 40024 20000	2	2AA 1BB 04A	90033 90034	40024 40024	5BB 5BB	ASSEMBLY ASSEMBLY	EP .0120 EP .0160	
3477	3477 3420	CONE CUP		0	1	2AF 1BF	90043	0	6BA	ASSEMBLY		
	3477 3420-B	CONE CUP		0	1	2AF 1BH	90027	0	6BA	ASSEMBLY		
3478	3478 3420	CONE CUP		0	1	2AF 1BF	90013	0	6BA	ASSEMBLY		
	3478 3420-B	CONE CUP		0	1	2AF 1BH	90014	0	6BA	ASSEMBLY		
	3478 3423D X15-3478	CONE CUP CONE SPCR		0 0 0	2	2AF 1BG 04A	90025	0	6BB	ASSEMBLY	EP .0040	78 248
3479	3479 3420	CONE CUP		0	1	2AF 1BF	90015	0	6BA	ASSEMBLY		
	3479 3420-B	CONE CUP		0	1	2AF 1BH	90016	0	6BA	ASSEMBLY		
	3479 3423D X15-3479	CONE CUP CONE SPCR A		20024 20024 20000	2	2AA 1BB 04A	90031 90023	20024 20024	5BB 5BB	ASSEMBLY ASSEMBLY	EP .0060 EP .0080	
	3479 3423D X25-3479	CONE CUP CONE SPCR BB		40024 40024 20000	2	2AA 1BB 04A	90038	40024	5BB	ASSEMBLY	EP .0080	
3480	3480 3420	CONE CUP		0	1	2AF 1BF	90037	0	6BA	ASSEMBLY		
	3480 3420-B	CONE CUP		0	1	2AF 1BH	90022	0	6BA	ASSEMBLY		
	3480 3423D X15-3482	CONE CUP CONE SPCR A		20024 20024 20000	2	2AA 1BB 04A	90041	20024	5BB	ASSEMBLY	EP .0000	
3482	3482 3420-B	CONE CUP		0	1	2AF 1BH	90021	0	6BA	ASSEMBLY		
	3482 3424YD X15-3482	CONE CUP CONE SPCR A		20024 20024 20000	2	2AA 1BB 04A	90017	20024	5BB	ASSEMBLY	EP .0080	

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q/A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
3490	3490	CONE		0		1 2AF	90018	0		6BA ASSEMBLY		
	3420	CUP		0		1 1BF						
	3490	CONE		40024		2 2AA	90042	40024		5BA ASSEMBLY	EP .0160	
	3420	CUP		40024		2 1BP						
	X15-28150	CONE SPCR A		20000		1 04P						
	3490	CONE		0		1 2AF	90019	0		6BA ASSEMBLY		
	3420-B	CUP		0		1 1BH						
	3490	CONE		0		1 2AF	90036	0		6BA ASSEMBLY		
	3422	CUP		0		1 1BF						
	3490	CONE		20024		2 2AA	90020	20024		5BB ASSEMBLY	EP .0080	
	3423D	CUP		20024		1 1BB	90028	20024		5BB ASSEMBLY	EP .0120	
	X15-3490	CONE SPCR A		20000		1 04P						
	3490	CONE		40000		2 2AA	90035	40000		5BB		73 073
	3423D	CUP		40000		1 1BB						
	X15-3490	CONE SPCR A		40000		1 04P						
3490	CONE		40024		2 2AA	90029	40024		5BB ASSEMBLY	EP .0080		
3423D	CUP		40024		1 1BB	90026	40024		5BB ASSEMBLY	EP .0120		
X15-3490	CONE SPCR A		20000		1 04P	90030	40024		5BB ASSEMBLY	EP .0160		
3490	CONE		0		2 2AF	90033	0		6BB ASSEMBLY	EP .0050		
3423D	CUP		0		1 1BC							
X15-3490	CONE SPCR A		0		1 04P							
JRM3534	JRM3534	CONE		U0606		2 2AA	90U01	U0606		5AU ASSEMBLY	EP .0060	
	JRM3564XD	CUP		U0531		1 1AU						
	GR9	GREASE				1 090						
JRM3500-S	SEAL				2 090							
JRM3535	JRM3535	CONE		U0227		2 2AA	90U04	U0227		5AU ASSEMBLY	EP .0060	
	JRM3564XD	CUP		U0531		1 1AU						
	GR5	GREASE				1 090						
	JRM3500-SC	SEAL				2 090						
	JRM3535	CONE		U0606		2 2AA	90U01	U0606		5AU ASSEMBLY	EP .0060	
	JRM3564XD	CUP		U0531		1 1AU						
	GR5	GREASE				1 090						
	JRM3500-SC	SEAL				2 090						
	JRM3535	CONE		U0611		2 2AA	90U05	U0611		5AU ASSEMBLY	EP .0110	
	JRM3564XD	CUP		U0531		1 1AU						
	GR5	GREASE				1 090						
	JRM3500-SC	SEAL				2 090						
	JRM3535	CONE		U0606		2 2AA	90U03	U0227		5AU ASSEMBLY	EP .0060	
	JRM3564XD	CUP		U0531		1 1AU						
	JRM3500-S	SEAL				2 090						
JRM3535	CONE		U0227		2 2AA	90227	U0227		5AU ASSEMBLY	EP .0060		
JRM3564XD	CUP		U0227		1 1AU							
JRM3500-SC	SEAL				2 090							
JRM3535	CONE		U0227		2 2AA	90UA1	U0227		5AU ASSEMBLY	EP .0090		
JRM3564XD	CUP		U0227		1 1AU							
JRM3500-SC	SEAL				1 090							
EX16690-SF	SEAL				1 090							
JRM3535	CONE		U0227		2 2AA	90U10	U0227		5AU ASSEMBLY	EP .0060		
JRM3564XD	CUP		U0227		1 1AU	90U08	U0227		5AU ASSEMBLY	EP .0090		
EX16690 SE	SEAL				2 090							
JRM3535	CONE		U0227		2 2AA	90UA4	U0227		5AU ASSEMBLY	EP .0060		
JRM3564XD	CUP		U0227		1 1AU	90U11	U0227		5AU ASSEMBLY	EP .0090		
EX16690-SF	SEAL				2 090							

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q/A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAT PRELOAD	DR	OBSELETE DATE
JRM3535A	JRM3535A	CONE		U0609	2	2AA	90U06	U0627	5AU	ASSEMBLY	EP	.0090	
	JRM3565XD	CUP		U0592	1	1AU							
	JRM3535A	CONE		U0609	2	2AA	90U02	U0609	5AU	ASSEMBLY	EP	.0090	
	JRM3565XD	CUP		U0592	1	1AU							
	GR7	GREASE			1	090							
	JRM3500-S	SEAL			2	090							
	JRM3535A	CONE		UF608	2	2AA	9FUA6	UF608	5AU	ASSEMBLY	EP	.0080	
	JRM3565XD	CUP		UF531	1	1AU							
	GR8	GREASE			1	090							
	JRM3500-SA	SEAL			2	090							
	JRM3500-SB	SEAL			2	090							
	JRM3535A	CONE		U8724	2	2AA	98U12	U8724	5AU	ASSEMBLY	EP	.0020	86 037
	JRM3565XD	CUP		U8531	1	1AU							
	JRM3500-S	SEAL			2	090							
JRM3535A	CONE		U0609	2	2AA	90UA3	U0609	5AU	ASSEMBLY	EP	.0090		
JRM3565XD	CUP		U0531	1	1AU								
JRM3500-SA	SEAL			2	090								
JRM3500-SB	SEAL			2	090								
JRM3535A	CONE		U2609	2	2AA	90U07	U0609	5AU	ASSEMBLY	EP	.0090		
JPH3565XD	CUP		U2592	1	1AU								
JRM3500-SA	SEAL			2	090								
JRM3500-SB	SEAL			2	090								
JRM3535A	CONE		U0609	2	2AA	90U03	U0609	5AU	ASSEMBLY	EP	.0090		
JRM3565XD	CUP		U0592	1	1AU								
JRM3500-SC	SEAL			2	090								
JRM3535A	CONE		UF227	2	2AA	9FUA7	UF227	5AU	ASSEMBLY				
JXC16690DG	CUP		UE227	1	1AU								
JRM3500-S	SEAL			1	090								
JRM3535H	JRM3535H	CONE		U0606	2	2AA	90UA9	U0606	5AU	ASSEMBLY	EP	.0060	
	JRM3564XD	CUP		U0531	1	1AU							
	GR2	GREASE			1	090							
JRM3500-SD	SEAL			1	090								
JRM3500-SE	CLOSURE			1	090								
JRM3535X	JRM3535X	CONE		U0606	2	2AA	90U07	U0606	5AU	ASSEMBLY	EP	.0060	
	JRM3564XD	CUP		U0531	1	1AU							
	GR2	GREASE			1	090							
JRM3500-SC	SEAL			2	090								
JRM3535X	CONE		U0227	2	2AA	90UA2	U0227	5AU	ASSEMBLY	EP	.0060		
JRM3564XD	CUP		U0227	1	1AU	90U09	U0227	5AU	ASSEMBLY	EP	.0080		
EX16690-SE	SEAL			2	090								
JRM3535XA	JRM3535XA	CONE		U0606	2	2AA	90UA8	U0606	5AU	ASSEMBLY	EP	.0060	
	JRM3564XD	CUP		U0531	1	1AU							
	GR2	GREASE			1	090							
JRM3500-SD	SEAL			2	090								
JRM3535XA	CONE		U0606	2	2AA	90UA5	U0606	5AU	ASSEMBLY	EP	.0060	87 012	
JRM3564XD	CUP		U0531	1	1AU								
JRM3500-SD	SEAL			2	090								
JRM3536	JRM3536	CONE		U0606	2	2AA	90UA1	U0606	5AU	ASSEMBLY	EP	.0060	
	JRM3564XD	CUP		U0531	1	1AU							
3576	3576	CONE		0	1	2AF	90010	0	6BA	ASSEMBLY			
	3525	CUP		0	1	1BF							
	3576	CONE		0-30	1	2AF	90011	0-33	6SA	ASSEMBLY			
	3525	CUP		0-39	1	1BF							
	3576	CONE		0	1	2AF	90029	0	6BA	ASSEMBLY			
3525-B	CUP		0	1	1BF								

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	G/A	COMP SGC	ASSY CODE	ASSY INSP	SGC DESC	END PLAY OR PRELOAD	OBSOLETE DATE
	3576 3526	CONE CUP		0 0		1 2AF 1 1BF	90031	0	6BA ASSEMBLY		
3576-B	3576-B 3525	CONE CUP		00 00		1 2AF 1 1BF	90032	00	7BA ASSEMBLY		90 094
3577	3577 3520	CONE CUP		0 0		1 2AF 1 1BF	90012	0	6BA ASSEMBLY		
	3577 3525	CONE CUP		0 0		1 2AF 1 1BF	90013	0	6BA ASSEMBLY		
	3577 3525-B	CONE CUP		0 0		1 2AF 1 1BH	90014	0	6BA ASSEMBLY		
3578	3578 3525	CONE CUP		0 0		1 2AF 1 1BF	90015	0	6BA ASSEMBLY		
	3578 3525-B	CONE CUP		0 0		1 2AF 1 1BH	90016	0	6BA ASSEMBLY		
	3578 3526	CONE CUP		0 0		1 2AF 1 1BF	90030	0	6BA ASSEMBLY		
3578-B	3578-B 3525	CONE CUP		00 00		1 2AF 1 1BF	90017	00	7BA ASSEMBLY		90 094
3579	3579 3525	CONE CUP		0 0		1 2AF 1 1BF	90018	0	6BA ASSEMBLY		
	3579 3525-B	CONE CUP		0 0		1 2AF 1 1BH	90019	0	6BA ASSEMBLY		
3583	3583 3525	CONE CUP		0 0		1 2AF 1 1BF	90021	0	6BA ASSEMBLY		
3585	3585 3520	CONE CUP		0 0		1 2AF 1 1BF	90022	0	6BA ASSEMBLY		
	3585 3525	CONE CUP		0 0		1 2AF 1 1BF	90023	0	6BA ASSEMBLY		
	3585 3525-B	CONE CUP		0 0		1 2AF 1 1BH	90026	0	6BA ASSEMBLY		
3586	3586 3520 Y15-3520 X15-3586	CONE CUP CUP SPCR RSR CONE SPCR A		40024 40024 20000 20000		2 2AA 2 1BA 1 04A 1 04A	90036	40024	5BA ASSEMBLY	EP .0120	
	3586 3525	CONE CUP		0 0		1 2AF 1 1BF	90027	0	6BA ASSEMBLY		
	3586 3525	CONE CUP		00 00		1 2AF 1 1BF	90035	00	7AA ASSEMBLY		
	3586 3525-B	CONE CUP		0 0		1 2AF 1 1BH	90033	0	6BA ASSEMBLY		
	3586 3526	CONE CUP		0 0		1 2AF 1 1BF	90034	0	6BA ASSEMBLY		
3659	3659 3620	CONE CUP		0 0		1 2AF 1 1AF	90010	0	6AA ASSEMBLY		
	3659 3620-B	CONE CUP		0 0		1 2AF 1 1AH	90011	0	6AA ASSEMBLY		
3660-B	3660-B 3620	CONE CUP		00 00		1 2AF 1 1AF	90012	00	7AA ASSEMBLY		90 128

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q/A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
3767	3767	CONE		0		1 2BF	90010	0		6BA ASSEMBLY		
	3720	CUP		0		1 1BF						
	3767	CONE		0-174		1 2BF	90178	0-174		6BA ASSY		
	3720	CUP		0		1 1BF						
	3767	CONE		0		1 2BF	90011	0		6BA ASSEMBLY		
	3720-B	CUP		0		1 1BH						
	3767	CONE		0		1 2BF	90086	0		6BA ASSEMBLY		
	3726	CUP		0		1 1BF						
	3767	CONE		0		2 2BF	90012	0		6BB ASSEMBLY		
	3729D	CUP		0		1 1BG						
	3767	CONE		20024		2 2BL	90110	20024		5BB ASSEMBLY	EP .0080	
	3729D	CUP		20024		1 1BB	90017	20024		4BB ASSEMBLY	EP .0100	
	X1S-3767	CONE SPCR A		20000		1 04P	90179	20024		5BB ASSEMBLY	EP .0160	
	3767	CONE		30000		2 2BF	90016	30000		6BB ASSEMBLY	EP .0040	
3729D	CUP		30000		1 1BG	90149	30000		6BB ASSEMBLY	EP .0050		
X1S-3767	CONE SPCR A		0		1 04P	90112	30000		6BB ASSEMBLY	EP .0060		
3767	CONE		40024		2 2BL	90018	40024		5BB ASSEMBLY	EP .0060		
3729D	CUP		40024		1 1BB	90019	40024		5BB ASSEMBLY	EP .0080		
X1S-3767	CONE SPCR A		20000		1 04P	90120	40024		5BB ASSEMBLY	EP .0100		
						90020	40024		5BB ASSEMBLY	EP .0120		
3767	CONE		0		2 2BF	90013	0		6BB ASSEMBLY	EP .0040		
3729D	CUP		0		1 1BG	90015	0		6BB ASSEMBLY	EP .0060		
X1S-3767	CONE SPCR A		0		1 04P							
3767	CONE		30000		2 2BF	90150	30000		6BB ASSEMBLY	EP .0050		
3729DC	CUP		30000		1 1BG	90146	30000		6BB ASSEMBLY	EP .0060		
X1S-3767	CONE SPCR A		0		1 04P							
3767	CONE		0		1 2BF	90021	0		6BA ASSEMBLY			
3732	CUP		0		1 1BF							
3767-B	3767-B	CONE		00		1 2BF	90177	00		7BA ASSEMBLY		90 211
	3720	CUP		00		1 1BF						
3767H	3767H	CONE		0		1 2BF	90022	0		6BA ASSEMBLY		
	3720	CUP		0		1 1BF						
3767H	3767H	CONE		0		1 2BF	90090	0		6BA ASSEMBLY		
	3720-B	CUP		0		1 1BH						
3767H	3767H	CONE		0		1 2BF	90025	0		6BA ASSEMBLY		
	3732	CUP		0		1 1BF						
3774	3774	CONE		0		1 2BF	90026	0		6BA ASSEMBLY		
	3720	CUP		0		1 1BF						
3774-B	3774-B	CONE		00		2 2BF	90023	00		7BB ASSEMBLY		90 211
	3729D	CUP		00		1 1BG						
3775	3775	CONE		40024		2 2BL	90186	40024		5BB ASSEMBLY	EP .0080	
	XC1837DE	CUP		40024		1 1BB						
	X3S-3775	CONE SPCR BB		20000		1 04A						
3775	3775	CONE		0		1 2BF	90027	0		6BA ASSEMBLY		
	3720	CUP		0		1 1BF						
3775	3775	CONE		30059		1 2BF	90181	30059		6BA ASSEMBLY		
	3720-B	CUP		30059		1 1BH						

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q/A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
	3775 3720-B	CONE CUP		0 0		1 2BF 1 1BH	90030	0		6BA ASSEMBLY		
	3775 3720-B	CONE CUP		00 00		1 2BF 1 1BH	90185	00		6BA ASSEMBLY		
	3775 3726	CONE CUP		0 0		1 2BF 1 1BF	90160	0		6BA ASSEMBLY		
	3775 3729D	CONE CUP		0 0		2 2BF 1 1BG	90031	0		6BB ASSEMBLY		
	3775 3729D Y15-3729 X15-3775	CONE CUP CUP SPCR R CONE SPCR BB		20024 20024 20000 20000		4 2BL 2 1BB 1 04B 2 04A	90117	20024		5BC ASSEMBLY	EP .0080	
	3775 3729D Y15-3729 X15-3775	CONE CUP CUP SPCR R CONE SPCR BB		30000 30000 0 0		4 2BF 2 1BG 1 04B 2 04A	90100	30000		6BC ASSEMBLY	EP .0080	
	3775 3729D X15-3775	CONE CUP CONE SPCR BB		40024 40024 20000		2 2BL 1 1BB 1 04A	90170 90032	40024 40024		5BB ASSEMBLY 5BB ASSEMBLY	EP .0080 EP .0160	
	3775 3729D X25-3775	CONE CUP CONE SPCR A		20024 20024 20000		2 2BL 1 1BB 1 04A	90140 90104 90035	20024 20024 20024		5BB ASSEMBLY 5BB ASSEMBLY 5BB ASSEMBLY	EP .0050 EP .0100 EP .0120	
	3775 3729D X25-3775	CONE CUP CONE SPCR A		30000 30000 0		2 2BF 1 1BG 1 04A	90173 90033 90034	30000 30000 30000		6BB ASSEMBLY 6BB ASSEMBLY 6BB ASSEMBLY	EP .0020 EP .0040 EP .0060	
	3775 3729D X25-3775	CONE CUP CONE SPCR A		30030 30000 0		2 2BF 1 1BG 1 04A	90117	30030		6BB ASSEMBLY	EP .0000	
	3775 3729D X25-3775	CONE CUP CONE SPCR A		30434 30039 0		2 2BF 1 1BG 1 04A	90184	30434		6BB ASSEMBLY	EP .0000	
	3775 3729D X25-3775	CONE CUP CONE SPCR A		40024 40024 20000		2 2BL 1 1BB 1 04A	90037 90038 90039 90156	40024 40024 40024 40024		5BB ASSEMBLY 5BB ASSEMBLY 5BB ASSEMBLY 5BB ASSEMBLY	EP .0040 EP .0060 EP .0080 EP .0120	
	3775 3729D X25-3775	CONE CUP CONE SPCR A		0 0 0		2 2BF 1 1BG 1 04A	90175	0		6BB ASSEMBLY	EP .0020	
	3775 3729D X35-3775	CONE CUP CONE SPCR BB		40024 40024 20000		2 2BL 1 1BB 1 04A	90130	40024		5BB ASSEMBLY	EP .0160	
	3775 3730	CONE CUP		0 0		1 2BF 1 1BF	90094	0		6BA ASSEMBLY		
	3775 3732	CONE CUP		0 0		1 2BF 1 1BF	90040	0		6BA ASSEMBLY		
	3775 3732 Y25-3732 X45-3775	CONE CUP CUP SPCR CONE SPCR		40024 40024 20000 20000		2 2BL 2 1BA 1 04B 1 04A	90145	40024		5BA ASSEMBLY	EP .0120	78 248
3775-B	3775-B 3720	CONE CUP		00 00		1 2BF 1 1BF	90101	00		7BA ASSEMBLY		90 211
	3775-B 3729D	CONE CUP		00 00		2 2BF 1 1BG	90041	00		7BB ASSEMBLY		90 211

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q/A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	DESOLETE DATE
	3775-B	CONE		00		1 2BF	90109	00		7BA ASSEMBLY		90 211
	3732	CUP		00		1 1BF						
3776	3776	CONE		0		1 2BF	90043	0		6BA ASSEMBLY		
	3720	CUP		0		1 1BF						
	3776	CONE		20024		2 2BL	90085	20024		5BB ASSEMBLY	EP .0060	
	3729D	CUP		20024		1 1BB	90095	20024		5BB ASSEMBLY	EP .0080	
	X15-3776	CONE SPCR A		20000		1 04P	90044	20024		5BB ASSEMBLY	EP .0120	
	3776	CONE		40024		2 2BL	90098	40024		5BB ASSEMBLY	EP .0080	
	3729D	CUP		40024		1 1BB	90136	40024		5BB ASSEMBLY	EP .0160	
	X15-3776	CONE SPCR A		20000		1 04P						
	3776	CONE		40024		1 2BL	90128	40024		5BA ASSEMBLY	EP .0080	
	3781	CONE		40024		1 2BL						
	3720	CUP		40024		2 1BE						
	X25-3720	CUP SPCR S		20000		1 04Q						
	3776	CONE		40024		1 2BL	90128	40024		5BA ASSEMBLY	EP .0080	
	3781	CONE		40024		1 2BL						
	3720	CUP		40024		2 1BE						
	X25-3720	CUP SPCR S		20000		1 04Q						
3777	3777	CONE		0		1 2BF	90046	0		6BA ASSEMBLY		
	3720	CUP		0		1 1BF						
	3777	CONE		00		1 2BF	90047	00		6BA ASSEMBLY		
	3720-B	CUP		00		1 1BH						
3778	3778	CONE		0		1 2BF	90097	0		6BA ASSEMBLY		
	3720	CUP		0		1 1BF						
	3778	CONE		20024		2 2BL	90139	20024		5BB ASSEMBLY	EP .0080	
	3729D	CUP		20024		1 1BB						
	X15-3779	CONE SPCR A		20000		1 04A						
3779	3779	CONE		0		1 2BF	90047	0		6BA ASSEMBLY		
	3720	CUP		0		1 1BF						
	3779	CONE		0-30		1 2BF	90114	0-30		6BA ASSEMBLY		
	3720	CUP		0		1 1BF						
	3779	CONE		0-30		1 2BF	90105	0-33		6BA ASSEMBLY		
	3720	CUP		0-39		1 1BF						
	3779	CONE		40024		2 2BL	90123	40024		5BA ASSEMBLY	EP .0120	
	3720	CUP		40024		2 1BE						
	X15-3779	CONE SPCR A		20000		1 04A						
	3779	CONE		0		1 2BF	90049	0		6BA ASSEMBLY		
	3720-B	CUP		0		1 1BH						
	3779	CONE		00		2 2BF	90050	00		7BB ASSEMBLY		
	3729D	CUP		00		1 1BG						
	3779	CONE		20024		2 2BL	90051	20024		5BB ASSEMBLY	EP .0060	
	3729D	CUP		20024		1 1BB						
	X15-3779	CONE SPCR A		20000		1 04A						
	3779	CONE		30000		2 2BF	90169	30000		6BB ASSEMBLY	EP .0000	
	3729D	CUP		30000		1 1BG	90125	30000		6BB ASSEMBLY	EP .0060	
	X15-3779	CONE SPCR A		0		1 04A						
	3779	CONE		40024		2 2BL	90188	40024		5BB ASSEMBLY	EP .0020	
	3729D	CUP		40024		1 1BB	90157	40024		5BB ASSEMBLY	EP .0080	
	X15-3779	CONE SPCR A		20000		1 04A	90152	40024		5BB ASSEMBLY	EP .0100	
							90182	40024		5BB ASSEMBLY	EP .0120	

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q/A	COMP SGC	ASSY CODE	ASSY INSP	ASSY SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
	3779	CONE		40024	2	2BL	90127	40024	5BA	ASSEMBLY	EP .0160	
	3730	CUP		40024	2	1BA						
	Y15-3730	CUP SPCR R		20000	1	04Q						
	X25-3779	CONE SPCR A		20000	1	04P						
	3779	CONE		0	1	2BF	90052	0	6BA	ASSEMBLY		
	3732	CUP		0	1	1BF						
	3779	CONE		70087	1	2BL	90053	70087	5BA	ASSEMBLY		
	3732	CUP		20087	1	1BA						
3779-B	3779-B	CONE		00	1	2BF	90174	00	7BA	ASSEMBLY		90 211
	3720	CUP		00	1	1BF						
	3779-B	CONE		00	2	2BF	90106	00	7BB	ASSEMBLY		90 211
	3729D	CUP		00	1	1BG						
3780	3780	CONE		0	1	2BF	9E5A2	0-E000	6BA	ASSEMBLY		
	3720	CUP		0	1	1BF						
	3780	CONE		0	1	2BF	90054	0	6BA	ASSEMBLY		
	3720	CUP		0	1	1BF						
	3780	CONE		40024	2	2BE	90186	40024	5BA	ASSEMBLY	EP .0060	
	3720	CUP		40024	2	1BE						
	Y25-3720	CUP SPCR S		20000	1	04Q						
	3780	CONE		40024	2	2BE	90133	40024	5BA	ASSEMBLY	EP .0160	
	3720	CUP		40024	2	1BE						
	Y45-3720	CUP SPCR R		20000	1	04Q						
	X45-3780	CONE SPCR A		20000	1	04P						
	3780	CONE		40024	2	2BE	90133	40024	5BA	ASSEMBLY	EP .0160	
	3720	CUP		40024	2	1BE						
	Y45-3720	CUP SPCR R		20000	1	04Q						
	X45-3780	CONE SPCR A		20000	1	04P						
	3780	CONE		20024	2	2BE	90185	20227	5BA	ASSEMBLY	EP .0020	
3720	Y75 3720	CUP SPCR Q		20000	1	04B						
	3780	CONE		40024	2	2BE	90151	40024	5BA	ASSEMBLY	EP .0080	
	3720	CUP		40024	2	1BE						
	Y75-3720	CUP SPCR Q		20000	1	04B						
	3780	CONE		40336	2	2BA	90165	40223	5BA	ASSEMBLY	EP .0160	
	3720	CUP		40024	2	1BE						
	Y85-3720	CUP SPCR RSR		20000	1	04B						
	X85-3780	CONE SPCR AA		20000	1	04A						
	3780	CONE		40024	2	2BE	90183	40024	5BA	ASSEMBLY	EP .0200	
	3720	CUP		40024	2	1BE						
	Y95-3720	CUP SPCR RSR		20000	1	04B						
	X95-3780	CONE SPCR AI		20000	1	04A						
	3780	CONE		40024	2	2BE	9K179	4K024	5BF	ASSEMBLY	EP .0160	
	3720	CUP		40024	2	1BE						
	K426900R	CONE SPCR SX		20000	1	049						
	3780	CONE		40024	2	2BE	90179	40024	5BF	ASSEMBLY	EP .0160	
	3720	CUP		40024	2	1BE						
	K426900R	CONE SPCR SX		20000	1	049						
	3780	CONE		20081	1	2BA	90119	20073	5BA	ASSEMBLY		75 188
	3720-B	CUP		20073	1	1BC						
	3780	CONE		0	1	2BF	90055	0	6BA	ASSEMBLY		
	3720-B	CUP		0	1	1BH						
	3780	CONE		0-67	1	2BF	90056	0-67	6BA	ASSEMBLY		75 217
	3720-B	CUP		0-67	1	1BH						

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER-	DESC	SP TY	COMP INSP	Q/A	COMP SGC	ASSY CODE	ASSY INSP	SGC DESC	ASSY DESC	END PLAY OR PRELHD	OBSELETE DATE
3780 3726	CONE CUR			0		1 2BF 1 1BF	90093	0	6BA ASSEMBLY			
3780 3729D	CONE CUP			0		2 2BF 1 1BG	90057	0	6BB ASSEMBLY			
3780 3729D X15-3775	CONE CUP CONE SPCR BB			20024 20024 20000		2 2BE 1 1BB 1 04A	90058	20024	5BB ASSEMBLY	EP .0160		
3780 3729D X15-3775	CONE CUP CONE SPCR BB			40024 40024 20000		2 2BE 1 1BB 1 04A	90059 90087	40024 40024	5BB ASSEMBLY 5BB ASSEMBLY	EP .0120 EP .0160		
3780 3729D X15-3780	CONE CUP CONE SPCR A			20024 20024 20000		2 2BE 1 1BB 1 04P	90061 90137 90062 90063	20024 20024 20024 20024	5BB ASSEMBLY 5BB ASSEMBLY 5BB ASSEMBLY 5BB ASSEMBLY	EP .0050 EP .0030 EP .0120 EP .0160		
3780 3729D X15-3780	CONE CUP CONE SPCR A			30000 30000 0		2 2BF 1 1BG 1 04P	90096 90060 90180	30000 30000 30000	6BB ASSEMBLY 6BB ASSEMBLY 6BB ASSEMBLY	EP .0040 EP .0060 PL .0020		
3780 3729D X15-3780	CONE CUP CONE SPCR A			40024 40024 20000		2 2BE 1 1BB 1 04P	50162 90064 90099 90177	40024 40024 40024 40024	5BB ASSEMBLY 5BB ASSEMBLY 5BB ASSEMBLY 5BB ASSEMBLY	EP .0000 EP .0030 EP .0080 EP .0120		
3780 3729D X15-3780	CONE CUP CONE SPCR A			40024 40286 20000		2 2BE 1 1BB 1 04P	90141	40286	5BB ASSEMBLY	EP .0080		
3780 3729D X15-3780	CONE CUP CONE SPCR A			0 0 0		2 2BF 1 1BG 1 04P	90124 90107	0 0	6BB ASSEMBLY 6BB ASSEMBLY	EP .0040 EP .0060		
3780 3729D X15-3780	CONE CUP CONE SPCR A			0-30 0 0		2 2BF 1 1BG 1 04P	90134	0-30	6BB ASSEMBLY	EP .0040		
3780 3729DC X15-3780	CONE CUP CONE SPCR A			20024 20024 20000		2 2BE 1 1BB 1 04P	90126 90143	20024 20024	5BB ASSEMBLY 5BB ASSEMBLY	EP .0080 EP .0120		
3780 3729DC X15-3780	CONE CUP CONE SPCR A			30000 30000 30000		2 2BF 1 1BG 1 04A	90132	30000	69B			73 073
3780 3729DC X15-3780	CONE CUP CONE SPCR A			30000 30000 0		2 2BF 1 1BG 1 04P	90168	30000	6BB ASSEMBLY	EP .0020		
3780 3729DC X15-3780	CONE CUP CONE SPCR A			0 0 0		2 2BF 1 1BG 1 04P	90135 90163	0 0	6BB ASSEMBLY 6BB ASSEMBLY	EP .0060 EP .0080		
3780 3730 X75-3780	CONE CUP CONE SPCR A			40024 40024 20000		2 2BE 2 1BA 1 04A	90148	40024	5BA ASSEMBLY	EP .0160		
3780 3730 K426900R	CONE CUP CONE SPCR SX			40024 40024 20000		2 2BE 2 1BA 1 049	90161	40024	5BF ASSEMBLY	EP .0160		
3780 3730 K426900R	CONE CUP CONE SPCR SX			40024 40024 20000		2 2BE 2 1BA 1 049	90161	40024	5BF ASSEMBLY	EP .0160		
3780 3732	CONE CUP			0 0		1 2BF 1 1BF	90065	0	6BA ASSEMBLY			

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q/A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OR	OBSOLETE DATE
3780-B	3780-B 3720	CONE CUP		0-30 0-39	1	2BF 1BF	90116	0-33		6BA ASSEMBLY			77 354
	3780-B 3720	CONE CUP		00 00	1	2BF 1BF	90066	00		7BA ASSEMBLY			90 211
	3780-B 3720-B	CONE CUP		00 00	1	2BF 1BF	90139	00		7BA ASSEMBLY			90 211
3780H	3780H 3720	CONE CUP		0 0	1	2BF 1BF	90164	0		6BA ASSEMBLY			
	3780H 3729D	CONE CUP		0 0	2	2BF 1BF	90067	0		6BB ASSEMBLY			
NA3780	NA3780 3729D	CONE CUP		2E024 20081	2	2BA 1BB	9E2A1	2E024		5BB ASSEMBLY			
	NA3780 3729D	CONE CUP		20024 20081	2	2BA 1BB	902A1	20024		5BB ASSEMBLY			85 156
	NA3780 3729D	CONE CUP		20194 20081	2	2BA 1BB	90071	20194		5BB ASSEMBLY	EP .0150		
	NA3780 3729D	CONE CUP		20199 20081	2	2BA 1BB	90089	20199		5BB ASSEMBLY	PL .0020		
	NA3780 3729D	CONE CUP		30000 30001	2	2BF 1BF	90069	30000		6BB ASSEMBLY	EP .0040		
	NA3780 3729D	CONE CUP		30142 30001	2	2BF 1BF	90092	30142		6BB ASSEMBLY	EP .0020		
	NA3780 3729DC	CONE CUP		30000 30001	2	2BF 1BF	90159	30000		6BB ASSEMBLY	EP .0040		
	NA3780-SH 3729D	CONE CUP		20194 20081	2	2BA 1BB	90072	20194		5BB ASSEMBLY	EP .0150		
NA3780-SH	NA3780-SH 3729D	CONE CUP		30000 30001	2	2BF 1BF	90118	30000		6BB ASSEMBLY	EP .0040		
	3781	3781 3720	CONE CUP		0 0	1 1	2BF 1BF	90073	0	6BA ASSEMBLY			
3781	3781 3729D X1S-366	CONE CUP CONE SPCR A		40024 40024 20000	2	2BL 1BB 104P	90182	40024		5BB ASSEMBLY	EP .0080		
	3781 3729D X1S-3781	CONE CUP CONE SPCR		20024 20024 20000	2	2BL 1BB 104A	90154	20024		5BB ASSEMBLY	EP .0100		78 248
	3781 3729D X1S-3781	CONE CUP CONE SPCR		40024 40024 20000	2	2BL 1BB 104A	90075	40024		5BB ASSEMBLY	EP .0080		78 248
	3781 3732	CONE CUP		0 0	1	2BF 1BF	90076	0		6BA ASSEMBLY			
3781A	3781A 3726	CONE CUP		70087 20087	1	2BA 1BA	90074	70087		5BA ASSEMBLY			
3781-B	3781-B 3732	CONE CUP		00 00	1	2BF 1BF	90121	00		7BA ASSEMBLY			90 211
3781H	3781H 3720	CONE CUP		0 0	1	2BF 1BF	90077	0		6BA ASSEMBLY			75 037
	3781H 3720-B	CONE CUP		0 0	1	2BF 1BF	90102	0		6BA ASSEMBLY			75 037

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q/A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
3782	3782	CONE		20024		1 2BE	90187	20488		5BA ASSEMBLY		
	3720	CUP		40024		1 1BE						
	3782	CONE		0		1 2BF	90078	0		6BA ASSEMBLY		
	3720	CUP		0		1 1BF						
	3782	CONE		0		2 2BF	90166	0		6BB ASSEMBLY		
	3729D	CUP		0		1 1BG						
	3782	CONE		20024		2 2BE	90129	20024		5BB ASSEMBLY	EP .0080	
	3729D	CUP		20024		1 1BB	90158	20024		5BB ASSEMBLY	EP .0120	
	X15-3782	CONE SPCR A		20000		1 04A						
	3782	CONE		40024		2 2BE	90113	40024		5BB ASSEMBLY	EP .0120	78 248
3729D	CUP		40024		1 1BB							
X25-3782	CONE SPCR		20000		1 04A							
3782	CONE		0		1 2BF	90080	0		6BA ASSEMBLY			
3732	CUP		0		1 1BF							
3782	CONE		40024		2 2BE	90115	40024		5BA ASSEMBLY	EP .0080	78 248	
3732	CUP		40024		2 1BA							
Y15-3732	CUP SPCR		20000		1 04B							
3782-B	3782-B	CONE		0		2 2BF	90081	0		6BB ASSEMBLY		77 356
	3729D	CUP		0		1 1BG						
	3782-B	CONE		0		2 2BF	90082	0		6BB ASSEMBLY	EP .0060	77 354
3729D	CUP		0		1 1BG							
X15-3782	CONE SPCR A		0		1 04A							
3783	3783	CONE		30000		2 2BF	90108	30000		6BB ASSEMBLY	EP .0040	
	3729D	CUP		30000		1 1BG						
	X15-3782	CONE SPCR A		0		1 04A						
3783	CONE		40024		2 2BL	90167	40024		5BB ASSEMBLY	EP .0120		
3729D	CUP		40024		1 1BB							
X15-3782	CONE SPCR A		20000		1 04A							
3784	3784	CONE		0		2 2BF	90083	0		6BB ASSEMBLY		
	3729D	CUP		0		1 1BG						
	3784	CONE		40024		2 2BL	90176	40024		5BB ASSEMBLY	EP .0160	
	3729D	CUP		40024		1 1BB						
	X15-3775	CONE SPCR BB		20000		1 04A						
	3784	CONE		30000		2 2BF	90172	30000		6BB ASSEMBLY	EP .0053	
	3729D	CUP		30000		1 1BG						
	X15-3780	CONE SPCR A		0		1 04P						
	3784	CONE		40024		2 2BL	90084	40024		5BB ASSEMBLY	EP .0080	
	3729D	CUP		40024		1 1BB	90144	40024		5BB ASSEMBLY	EP .0120	
X15-3780	CONE SPCR A		20000		1 04P							
3784	CONE		0		2 2BF	90155	0		6BB ASSEMBLY			
3729DC	CUP		0		1 1BG							
3822RB	3822RB	CUP		20355		1 1BA	90031	20355		541 ASSEMBLY		
	174631	SNAP RING				1 090						
	3822RB	CUP		40355		1 1BA	90032	40355		541 ASSEMBLY		
174631	SNAP RING				1 090							
3822RB	CUP		40357		1 1BA	90030	40357		541 ASSEMBLY			
174631	SNAP RING				1 090							
3825RB	3825RB	SNAP RING		40000		1 1BA	90034	40000		541		73 073
	K35530			40000		1 090						
3872	3872	CONE		0		1 2AF	90036	0		6BA ASSEMBLY		
	3820	CUP		0		1 1BF						

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q/A	COMP SGC	ASSY CODE	ASSY INSP	ASSY SGC	ASSY DESC	END PLAY OR PRELOAD	OBsolete DATE
3875	3875	CONE		0		1 2AF	90010	0		6BA ASSEMBLY		
	3820	CUP		0		1 1BF						
	3875	CONE		0		1 2AF	90038	0		6BA ASSEMBLY		
	3821	CUP		0		1 1BF						
	3875	CONE		20024		2 2AP	902A1	20024		5BA ASSEMBLY	EP .0060	
	3821	CUP		20024		2 1BA						
	Y55-3820	CUP SPCR P		20000		1 04Q						
	X15-44150	CONE SPCR A		20000		1 04A						
	3875	CONE		20024		2 2AP	90027	20024		5BA ASSEMBLY	EP .0080	
	3821	CUP		20024		2 1BA						
Y15-3821	CUP SPCR Q		20000		1 04B							
X15-3875	CONE SPCR A		20000		1 04A							
3876	3876	CONE		40024		2 2AP	90041	40024		5BA ASSEMBLY	EP .0060	
	3820	CUP		40024		2 1BE						
	X15-25572	CONE SPCR A		20000		1 04P						
3877	3877	CONE		0		1 2AF	90012	0		6BA ASSEMBLY		
	3820	CUP		0		1 1BF						
	3877	CONE		0-30		1 2AF	90021	0-33		6BA ASSEMBLY		
	3820	CUP		0-33		1 1BF						
	3877	CONE		40024		2 2AP	90014	40024		5BA ASSEMBLY	EP .0080	78 248
	3820	CUP		40024		2 1BE						
	Y15-3820	CUP SPCR		20000		1 04B						
	X15-3877	CONE SPCR		20000		1 04A						
	3877	CONE		0		1 2AF	90026	0		6BA ASSEMBLY		
	3820-P	CUP		0		1 1BH						
	3877	CONE		0		1 2AF	90015	0		6BA ASSEMBLY		
	3821	CUP		0		1 1BF						
	3877	CONE		20177		2 2AA	90028	20177		5BA ASSEMBLY	EP .0035	78 248
	3821	CUP		20177		2 1BA	90029	20177		5BA ASSEMBLY	EP .0045	78 248
	Y25-3821	CUP SPCR		20000		1 04B						
X25-3877	CONE SPCR		20000		1 04A							
3877	CONE		40024		1 2AP	90030	40082		5BA ASSEMBLY	EP .0000		
M802048	CONE		40024		1 2AD							
3820	CUP		40082		1 1BE							
M802011	CUP		40024		1 1BE							
Y55-3820	CUP SPCR P		20000		1 04Q							
X55-3877	CONE SPCR A		20000		1 04P							
3878	3878	CONE		0		1 2AF	90018	0		6BA ASSEMBLY		
	3820	CUP		0		1 1BF						
3879	3879	CONE		0		1 2AF	90035	0		6BA ASSEMBLY		
	3820	CUP		0		1 1BF						
3880	3880	CONE		20024		1 2AP	9F299	2F024		5BA ASSEMBLY		
	3820	CUP		20024		1 1BE						
3880	CONE		0		1 2AF	90020	0		6BA ASSEMBLY			
3820	CUP		0		1 1BF							
3880	CONE		20024		2 2AP	90037	20024		5BA ASSEMBLY	EP .0060		
3820	CUP		20024		2 1BE							
Y25-3820	CUP SPCR R		20000		1 04B							
X15-3880	CONE SPCR A		20000		1 04P							
3880	CONE		20024		2 2AP	90040	20223		5BA ASSEMBLY	EP .0040		
3820	CUP		20024		2 1BE							
Y45-3820	CUP SPCR R		20000		1 04Q							
X15-3880	CONE SPCR A		20000		1 04P							