



05839... B05
07087... C05
07097... D05
07098... E05
07100... F05
07100... G05
07100... H05
08125... I05
08125... J05
09074... K05
10044... L05
10049... M05
10638... N05
11019... O05

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
	XC05839C XC05839DA	CONE CUP		0-174 0		1 2GF 1 1EF	90011	0-174	6EA	ASSEMBLY		75 204
	XC05839C XC05839DA	CONE CUP		0-227 0-227		1 2GF 1 1EF	90013	0-227	6EA	ASSEMBLY		75 204
	XC05839C XC05839DA	CONE CUP		0-483 0-483		1 2GF 1 1EF	90015	0-483	6EA	ASSEMBLY		
XC05839CA	XC05839CA XC05839DA	CONE CUP		0-174 0		1 2GF 1 1EF	90012	0-174	6EA	ASSEMBLY		75 204
	XC05839CA XC05839DA	CONE CUP		0-227 0-227		1 2GF 1 1EF	90014	0-227	6EA	ASSEMBLY		75 204
	XC05839CA XC05839DA	CONE CUP		0-483 0-483		1 2GF 1 1EF	90016	0-483	6EA	ASSEMBLY		
XC06537CF	XC06537CF L68110 XC06537-S	CONE CUP CUP SPCR		40472 40472		2 2AA 2 1AE 1 049	90010	40472	5AF	ASSEMBLY		76 218
	XC06537CF L68111 XC06537-SA	CONE CUP CUP SPCR		40472 40472 20000		2 2AA 2 1AE 1 049	90011	40472	5AF	ASSEMBLY		76 166
07000LA	07100 07000LA	CONE DUOFASEAL		20024		1 2AD 1 090	902A1	20024	542	ASSEMBLY		
	07100 07000LA	CONE DUOFASEAL		40024		1 2AD 1 090	90133	40024	542	ASSEMBLY		
07079	07079 07196	CONE CUP		0 0		1 2AF 1 1AF	90010	0	6AA	ASSEMBLY		
	07079 07196D XIS-07079	CONE CUP CONE SPCR A		20024 20024 20000		2 2AP 1 1AB 1 04A	90128 90089	20024 20024	5AB 5AB	ASSEMBLY ASSEMBLY	EP .0000 EP .0080	
	07079 07196D XIS-07079	CONE CUP CONE SPCR A		20024 20286 20000		2 2AP 1 1AB 1 04A	90100	20286	5AG	ASSEMBLY	EP .0030	
	07079 07196D XIS-07079	CONE CUP CONE SPCR A		20051 20024 20000		2 2AP 1 1AB 1 04A	90011	20051	5AB	ASSEMBLY	EP .0040	
	07079 07204	CONE CUP		0 0		1 2AF 1 1AF	90012	0	6AA	ASSEMBLY		
	07079 07204-B	CONE CUP		0 0		1 2AF 1 1AH	90013	0	6AA	ASSEMBLY		
07079-B	07079-B 07196	CONE CUP		00 00		1 2AF 1 1AF	90072	00	7AA	ASSEMBLY		
	07079-B 07204-B	CONE CUP		00 00		1 2AF 1 1AH	90014	00	7AA	ASSEMBLY		
	07079-B 07205	CONE CUP		00 00-H000		1 2AF 1 1AF	98098	00	7AA	ASSEMBLY		86 037
	07079-B 07205	CONE CUP		00 00		1 2AF 1 1AF	90098	00	7AA	ASSEMBLY		
07087	07087 07196	CONE CUP		0 0		1 2AF 1 1AF	90015	0	6AA	ASSEMBLY		
	07087 07196-B	CONE CUP		0 0		1 2AF 1 1AH	90075	0	6AA	ASSEMBLY		

810ER

ASSEMBLY IDENTIFICATION REPORT, COPYRIGHTED 1992 BY THE TIMKEN COMPANY

07087

6. 1992 33.8-

PAGE

3.0

ASSEMBLY
PART NUMBERCOMPONENT
PART NUMBER

DESC

SP
TYCOMP
INSP

Q-A

COMP
SGCASSY
CODEASSY
INSP

SGC

ASSY
DESCEND PLAY OR
PRELOADOBSOLETE
DATE

	07087	CONE		40024	2	2AP	90118	40024	5AB	ASSEMBLY	EP .0160	78 276
	07196D	CUP		40024	1	1AB						
	X15-07087	CONE SPCR		20000	1	04A						
	07087	CONE		20024	2	2AP	90113	20024	5AB	ASSEMBLY	EP .0000	89 065
	07196D	CUP		20024	1	1AB						
	X15-07087X	CONE SPCR		20000	1	04A						
	07087	CONE		40024	2	2AP	90109	40024	5AB	ASSEMBLY	EP .0040	77 279
	07196D	CUP		40024	1	1AB						
	X15-07087X	CONE SPCR		20000	1	04A						
	07087	CONE		0	1	2AF	90016	0	6AA	ASSEMBLY		
	07204	CUP		0	1	1AF						
07087-B	07087-B	CONE		00	1	2AF	90076	00	7AA	ASSEMBLY		90 129
	07196	CUP		00	1	1AF						
	07087-B	CONE		00	1	2AF	90017	00	7AA	ASSEMBLY		90 129
	07196-B	CUP		00	1	1AF						
07087X	07087X	CONE		48000	2	2AA	98644	48000	5AA	ASSEMBLY	EP .0060	86 037
	07210X	CUP		48000	2	1AA						
	X35-07087X	CONE SPCR A		40000	1	04A						
07093	07093	CONE		0	1	2AF	90018	0	6AA	ASSEMBLY		
	07196	CUP		0	1	1AF						
	07093	CONE		0-30	1	2AF	90019	0-33	6AA	ASSEMBLY		
	07196	CUP		0-33	1	1AF						
	07093	CONE		0	1	2AF	90102	0	6AA	ASSEMBLY		
	07196-B	CUP		0	1	1AF						
	07093	CONE		0-30	1	2AF	90115	0-30	6AA	ASSEMBLY		
	07196-B	CUP		0	1	1AF						
	07093	CONE		0-35	1	2AF	90130	0-35	6AA	ASSEMBLY		
	07196-B	CUP		0-32	1	1AF						
	07093	CONE		00	1	2AF	906A1	00	7AA	ASSEMBLY		
	07196-B	CUP		00	1	1AF						
	07093	CONE		0	1	2AF	90020	0	6AA	ASSEMBLY		
	07204	CUP		0	1	1AF						
	07093	CONE		0-224	1	2AF	90021	0-224	6AA	ASSEMBLY		
	07204	CUP		0-221	1	1AF						
	07093	CONE		0	1	2AF	90022	0	6AA	ASSEMBLY		
	07204-B	CUP		0	1	1AF						
07093-B	07093-B	CONE		00	1	2AF	90023	00	7AA	ASSEMBLY		90 129
	07196	CUP		00	1	1AF						
	07093-B	CONE		00	1	2AF	90024	00	7AA	ASSEMBLY		90 129
	07196-B	CUP		00	1	1AF						
	07093-B	CONE		00	1	2AF	90025	00	7AA	ASSEMBLY		90 129
	07204-B	CUP		00	1	1AF						
07096	07096	CONE		0	1	2AF	90126	0	6AA	ASSEMBLY		
	07196	CUP		0	1	1AF						
07097	07097	CONE		0	1	2AF	90068	0	6AA	ASSEMBLY		
	07196	CUP		0	1	1AF						
	07097	CONE		0-30	1	2AF	90047	0-30	6AA	ASSEMBLY		
	07196	CUP		0	1	1AF						

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
	07097 07196	CONE CUP		0-580 0	1	2AF 1AF	90133	0-580	6AA	ASSEMBLY		
	07097 07196-B	CONE CUP		0 0	1	2AF 1AH	90091	0	6AA	ASSEMBLY		
	07097 07196D	CONE CUP		0 0	2	2AF 1AG	90062	0	6AB	ASSEMBLY		
	07097 07196D X15-07097	CONE CUP CONE SPCR A		20024 20024 20000	2	2AP 1AB 104A	90026	20024	5AB	ASSEMBLY	EP .0080	
	07097 07204	CONE CUP		30030 30039	1	2AF 1AF	90132	30033	6AA	ASSEMBLY		
	07097 07204	CONE CUP		0 0	1	2AF 1AF	90027	0	6AA	ASSEMBLY		
	07097 07204	CONE CUP		0-30 0-39	1	2AF 1AF	90131	0-33	6AA	ASSEMBLY		
	07097 07204	CONE CUP		00 00	1	2AF 1AF	906A1	00	7AA	ASSEMBLY		
	07097 07204-B	CONE CUP		0 0	1	2AF 1AH	90088	0	6AA	ASSEMBLY		
	07097 07205	CONE CUP		0 0-H000	1	2AF 1AF	98110	0-S000	6AA	ASSEMBLY		86 037
	07097 07205	CONE CUP		0 0	1	2AF 1AF	90110	0	6AA	ASSEMBLY		
07097-B	07097-B 07196	CONE CUP		00 00	1	2AF 1AF	90028	00	7AA	ASSEMBLY		90 129
	07097-B 07196-B	CONE CUP		00 00	1	2AF 1AH	90092	00	7AA	ASSEMBLY		90 129
	07097-B 07196D X15-07097	CONE CUP CONE SPCR A		00 00 00	2	2AF 1AG 104A	90029	00	7AB	ASSEMBLY	EP .0010	90 129
	07097-B 07204	CONE CUP		00 00	1	2AF 1AF	90079	00	7AA	ASSEMBLY		91 256
07098	07098 07196	CONE CUP		0 0	1	2AF 1AF	90030	0	6AA	ASSEMBLY		
	07098 07196	CONE CUP		0-30 0-39	1	2AF 1AF	90074	0-33	6AA	ASSEMBLY		
	07098 07196	CONE CUP		0-174 0	1	2AF 1AF	90065	0-174	6AA	ASSEMBLY		
	07098 07196-B	CONE CUP		0 0	1	2AF 1AH	90031	0	6AA	ASSEMBLY		
	07098 07196-B	CONE CUP		0-30 0	1	2AF 1AH	90114	0-30	6AA	ASSEMBLY		
	07098 07196D X15-07097	CONE CUP CONE SPCR A		40024 40024 20000	2	2AP 1AB 104A	90081 90105	40024 40024	5AB 5AB	ASSEMBLY ASSEMBLY	EP .0050 EP .0060	
	07098 07204	CONE CUP		0 0	1	2AF 1AF	90032	0	6AA	ASSEMBLY		
	07098 07204	CONE CUP		0 0	1	2AF 1AF	90122 90123	0-227 0-227	6AA 6AA	ASSEMBLY ASSEMBLY		

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
	07098 07204	CONE CUP		0-30 0-39		1 2AF 1 1AF	90033	0-33	6AA	ASSEMBLY		
	07098 07204	CONE CUP		0-174 0		1 2AF 1 1AF	90034	0-174	6AA	ASSEMBLY		
	07098 07204	CONE CUP		00 00		1 2AF 1 1AF	906A1	00	7AA	ASSEMBLY		
	07098 07204	CONE CUP		00-227 00-227		2 2AF 2 1AF	90124	00-227	7AA	ASSEMBLY		
	XC2347-S XC2347-SA	CONE SPCR A CUP SPCR R		0-227 0-227		1 04A 1 04A						
	07098 07204-B	CONE CUP		0 0		1 2AF 1 1AH	90036	0	6AA	ASSEMBLY		
	07098 07205	CONE CUP		0 0-H000		1 2AF 1 1AF	90037	0-E000	6AA	ASSEMBLY		
	07098 07205	CONE CUP		0 0-H000		1 2AF 1 1AF	98037	0-8000	6AA	ASSEMBLY		85 206
	07098 07205	CONE CUP		0 0		1 2AF 1 1AF	90037	0	6AA	ASSEMBLY		
07098-B	07098-B 01196-B	CONE CUP		00 00		1 2AF 1 1AH	90121	00	7AA	ASSEMBLY		91 256
	07098-B 07204	CONE CUP		00 00		1 2AF 1 1AF	90039	00	7AA	ASSEMBLY		90 129
07098H	07098H 07204	CONE CUP		0 0		1 2AF 1 1AF	90090	0	6AA	ASSEMBLY		
07100	07100 07196	CONE CUP		30030 30039		1 2AF 1 1AF	903A5	30033	6AA	ASSEMBLY		
	07100 07196	CONE CUP		0 0		1 2AF 1 1AF	90041	0	6AA	ASSEMBLY		
	07100 07196	CONE CUP		0-30 0-39		1 2AF 1 1AF	90061	0-33	6AA	ASSEMBLY		
	07100 07196	CONE CUP		0-174 0		1 2AF 1 1AF	90087	0-174	6AA	ASSEMBLY		
	07100 07196	CONE CUP		00 00		1 2AF 1 1AF	906A6	00	7AA	ASSEMBLY		
	07100 07196	CONE CUP		40024 40024		2 2AD 2 1AD	90040	40024	5AA	ASSEMBLY	EP .0080	
	X15-07100 Y15-07196	CONE SPCR A CUP SPCR R		20000 20000		1 04P 1 04P						
	07100 07196 Y25-07196	CONE CUP CUP SPCR		40024 40024 20000		2 2AD 2 1AD 1 04^	90066	40024	5AA	ASSEMBLY	EP .0080	78 276
	07100 07196-B	CONE CUP		0 0		1 2AF 1 1AH	90043	0	6AA	ASSEMBLY		
	07100 07196-B	CONE CUP		00 00		1 2AF 1 1AH	90042	00	7AA	ASSEMBLY		
	07100 07196D	CONE CUP		0 0		2 2AF 1 1AG	90044	0	6AB	ASSEMBLY		
	07100 07196D	CONE CUP		0-30 0		2 2AF 1 1AG	90086	0-30	6AB	ASSEMBLY		

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q/A	COMP SGC	ASSY CODE	ASSY INSP	ASSY SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
07100 07196D X15-07100	CONE CUP CONE	SPCR A		20024 20024 20000	2 1 1	2AD 1AB 04P	90125 902A4 90132 90063 90103	20024 20024 20024 20024 20024	5AB 5AB 5AG 5AG 5AB	ASSEMBLY ASSEMBLY ASSEMBLY ASSEMBLY ASSEMBLY	EP .0000 EP .0040 EP .0080 EP .0080 EP .0120	
07100 07196D X15-07100	CONE CUP CONE	SPCR A		20024 20157 20000	2 1 1	2AD 1AB 04F	90127	20157	5AB	ASSEMBLY	EP .0000	
07100 07196D X15-07100	CONE CUP CONE	SPCR A		20051 20024 20000	2 1 1	2AD 1AB 04P	90045	20051	5AG	ASSEMBLY	EP .0130	
07100 07196D X15-07100	CONE CUP CONE	SPCR A		30000 30000 0	2 1 1	2AF 1AG 04P	90119 90093 90101 90094	30000 30000 30000 30000	6AB 6AB 6AB 6AB	ASSEMBLY ASSEMBLY ASSEMBLY ASSEMBLY	EP .0000 EP .0040 EP .0050 EP .0060	
07100 07196D X15-07100	CONE CUP CONE	SPCR A		30030 30000 0	2 1 1	2AF 1AG 04P	90078	30030	6AB	ASSEMBLY	EP .0000	
07100 07196D X15-07100	CONE CUP CONE	SPCR A		4E024 40024 20000	2 1 1	2AA 1AB 04P	9E4A3	4E024	5AB	ASSEMBLY	EP .0060	
07100 07196D X15-07100	CONE CUP CONE	SPCR A		40024 40024 20000	2 1 1	2AD 1AB 04P	9E4A2	4E024	5AB	ASSEMBLY	EP .0060	
07100 07196D X15-07100	CONE CUP CONE	SPCR A		40024 40024 20000	2 1 1	2AD 1AB 04P	90104 90046 9E4A1 90095 90097	40024 40024 40024 40024 40024	5AB 5AG 5AB 5AG 5AB	ASSEMBLY ASSEMBLY ASSEMBLY ASSEMBLY ASSEMBLY	EP .0010 EP .0060 EP .0080 EP .0080 EP .0100	
07100 07196D X15-07100	CONE CUP CONE	SPCR A		0 0 0	2 1 1	2AF 1AG 04P	90122 90107	0 0	6AB 6AB	ASSEMBLY ASSEMBLY	EP .0000 EP .0030	
07100 07196D X25-07100	CONE CUP CONE	SPCR		40024 40024 20000	2 1 1	2AD 1AB 04A	90073	40024	5AB	ASSEMBLY	EP .0080	78 276
07100 07196D X55-07100	CONE CUP CONE	SPCR BB		40024 40024 20000	2 1 1	2AD 1AB 04A	90117	40024	5AB	ASSEMBLY	EP .0160	
07100 07196DC	CONE CUP			0 0	2 1	2AF 1AG	90108	0	6AB	ASSEMBLY		
07100 07196DC X15-07100	CONE CUP CONE	SPCR A		30000 30000 0	2 1 1	2AF 1AG 04P	90099	30000	6AB	ASSEMBLY	EP .0060	
07100 07196DC X15-07100	CONE CUP CONE	SPCR A		0 0 0	2 1 1	2AF 1AG 04P	90112	0	6AB	ASSEMBLY	EP .0050	
07100 07204	CONE CUP			30030 30039	1 1	2AF 1AF	90133	30033	6AA	ASSEMBLY		
07100 07204	CONE CUP			0 0	1 1	2AF 1AF	90048	0	6AA	ASSEMBLY		
07100 07204	CONE CUP			0-174 0	1 1	2AF 1AF	90082	0-174	6AA	ASSEMBLY		
07100 07204-B	CONE CUP			0 0	1 1	2AF 1AF	90049	0	6AA	ASSEMBLY		

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OR	OBSOLETE DATE
	07100 07210X	CONE CUP		0 0		1 2AF 1 1AF	90096	0		6AA ASSEMBLY			89 117
07100-B	07100-B 07196	CONE CUP		00 00		1 2AF 1 1AF	90050	00		7AA ASSEMBLY			91 323
	07100-B 07196-B	CONE CUP		0 0		1 2AF 1 1AH	90052	0		6AA ASSEMBLY			90 129
	07100-B 07196 B	CONE CUP		00 00		1 2AF 1 1AH	90051	00		7AA ASSEMBLY			90 129
	07100-B 07196D	CONE CUP		0 0		2 2AF 1 1AG	90070	0		6AB ASSEMBLY			90 129
	07100-B 07196D	CONE CUP		00 00		2 2AF 1 1AG	90053	00		7AB ASSEMBLY			90 129
	07100-B 07196D X15 07100	CONE CUP CONE SPCR A		0 0 0		2 2AF 1 1AG 1 04P	90069	0		6AB ASSEMBLY	EP .0010		90 129
	07100-B 07196D X15-07100	CONE CUP CONE SPCR A		00 00 00		2 2AF 1 1AG 1 04P	90054	00		7AB ASSEMBLY	EP .0030		90 129
	07100-B 07196DC X15-07100	CONE CUP CONE SPCR A		00 00 00		2 2AF 1 1AG 1 04P	90124	00		7AB ASSEMBLY	EP .0040		90 129
	07100-B 07204	CONE CUP		00 00		1 2AF 1 1AF	90055	00		7AA ASSEMBLY			91 073
	07100-B 07204 B	CONE CUP		00 00		1 2AF 1 1AH	90056	00		7AA ASSEMBLY			90 129
07100D	07100D 07196-B	CONE CUP		0 0		1 2AG 2 1AH	90057	0		6AP ASSEMBLY			
	07100D 07204	CONE CUP		0 0		1 2AG 2 1AF	90077	0		6AP ASSEMBLY			
07100L	07100L 07000L	CONE DROF ASEAL		40000		1 2AA 1 090	90071	40000		542 ASSEMBLY			85 031
07100 S	07100 S 07196	CONE CUP		0-H000 0		1 2AF 1 1AF	98106	0 8000		6AA ASSEMBLY			86 037
	07100-S 07196	CONE CUP		0 0		1 2AF 1 1AF	90106	0		6AA ASSEMBLY			
	07100-S 07205	CONE CUP		0-E000 0-E000		1 2AF 1 1AF	9E120	0-E000		6AA ASSEMBLY			
	07100-S 07205	CONE CUP		0-H000 0-H000		1 2AF 1 1AF	98120	0-8000		AA ASSEMBLY			86 037
	07100-S 07205	CONE CUP		0 0		1 2AF 1 1AF	90120	0		6AA ASSEMBLY			
	07100 S 07210X	CONE CUP		0 H000 0		1 2AF 1 1AF	98129	0 8000		6AA ASSEMBLY			86 037
	07100-S 07210X	CONE CUP		0 0-H000		1 2AF 1 1AF	9G129	0-G000		6AA ASSEMBLY			92 017
	07100-S 07210X	CONE CUP		0 0		1 2AF 1 1AF	90129	0		6AA ASSEMBLY			
07100H	07100H 07204	CONE CUP		0 0		1 2AF 1 1AF	90067	0		6AA ASSEMBLY			

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASST INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
	07100H 07204-B	CONE CUP		0 0		1 2AF 1 1AH	90058 0			6AA ASSEMBLY		
07100HB	07100HB 07204-B	CONE CUP		00 00		1 2AF 1 1AH	90059 .00			7AA ASSEMBLY		90-129
07101DH	07101DH 07204	CONE CUP		0 0		1 2AG 2 1AF	90060 0			6AP ASSEMBLY		
	07101DH 07205	CONE CUP		0 0-H000		1 2AG 1 1AF	98111 0-8000			6AP ASSEMBLY		86 037
	07101DH 07205	CONE CUP		0 0		1 2AG 2 1AF	90111 0			6AP ASSEMBLY		
08118	08118 08231	CONE CUP		0 0		1 2AF 1 1AF	90010 0			6AA ASSEMBLY		
	08118 08231-B	CONE CUP		0 0		1 2AF 1 1AH	90011 0			6AA ASSEMBLY		
	08118 08231D	CONE CUP		0 0		2 2AF 1 1AG	90012 0			6AB ASSEMBLY		
	08118 08231D X15-08118	CONE CUP CONE SPCR A		20024 20024 20000		2 2AA 1 1AB 1 04A	90053 20024 90014 20024	20024 20024		5AB ASSEMBLY 5AB ASSEMBLY	EP .0060 EP .0090	
	08118 08231D X15-08118	CONE CUP CONE SPCR A		20024 20024 20000		2 2AA 1 1AB 1 04A	90058 20227			5AB ASSEMBLY		
	08118 08231D X15-08118	CONE CUP CONE SPCR A		30000 30000 0		2 2AF 1 1AG 1 04A	90032 30000 90043 30000 90013 30000	30000 30000		6AB ASSEMBLY 6AB ASSEMBLY 6AB ASSEMBLY	EP .0010 EP .0050 EP .0070	
	08118 08231D X15-08118	CONE CUP CONE SPCR A		40024 40024 20000		2 2AA 1 1AB 1 04A	90056 40024			5AB ASSEMBLY	EP .0080	
08118-B	08118-B 08231	CONE CUP		00 00		1 2AF 1 1AF	90015 00			7AA ASSEMBLY		90 115
	08118-B 08231-B	CONE CUP		00 00		1 2AF 1 1AH	90016 00			7AA ASSEMBLY		90 115
	08118-B 08231D	CONE CUP		0 0		2 2AF 1 1AG	90034 0			6AB ASSEMBLY		76 299
08125	08125 08231	CONE CUP		0 0		1 2AF 1 1AF	90017 0			6AA ASSEMBLY		
	08125 08231	CONE CUP		0-30 0		1 2AF 1 1AF	90050 0-30			6AA ASSEMBLY		
	08125 08231	CONE CUP		0-30 0-34		1 2AF 1 1AF	90064 0-33			6AA ASSEMBLY		
	08125 08231	CONE CUP		00 00		1 2AF 1 1AF	90025 00			7AA ASSEMBLY		
	08125 08231 X105-08125 K106610R	CONE CUP CONE SPCR BB CUP SPCR 57		40024 40024 20000 20000		2 2AA 2 1AP 1 04A 1 049	90062 40024	40024		5AS ASSEMBLY	EP .0080	
	08125 08231 X65-08125	CONE CUP CONE SPCR A		40024 40024 20000		2 2AA 2 1AP 1 04P	90051 40024			5AA ASSEMBLY	EP .0100	

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
	08125	CONE		40024	2	2AA	90059	40024	5AS	ASSEMBLY	EP .0080	
	08231	CUP		40024	2	1AP						
	X95-08125	CONE	SPCR A	20000	1	04P						
	K106610R	CUP	SPCR SY	20000	1	049						
	08125	CONE		40024	2	2AA	90049	40024	5AA	ASSEMBLY	EP .0080	78 276
	08231	CUP		40024	2	1AP						
	Y15-08231	CUP	SPCR	20000	1	04A						
	08125	CONE		0	1	2AF	90020	0	6AA	ASSEMBLY		
	08231-B	CUP		0	1	1AH						
	08125	CONE		0-30	1	2AF	90021	0-33	6AA	ASSEMBLY		
	08231-B	CUP		0-39	1	1AH						
	08125	CONE		00	1	2AF	90019	00	7AA	ASSEMBLY		
	08231-B	CUP		00	1	1AH						
	08125	CONE		0	2	2AF	90022	0	6AB	ASSEMBLY		
	08231D	CUP		0	1	1AG						
	08125	CONE		0-30	2	2AF	90046	0-30	6A2	ASSEMBLY		
	08231D	CUP		0	1	1AG						
	08125	CONE		20024	2	2AA	90044	20024	5AB	ASSEMBLY	EP .0010	
	08231D	CUP		20024	1	1AB	90044	20024	5AB	ASSEMBLY	EP .0080	
	X65-08125	CONE	SPCR A	20000	1	04P	90055	20024	5AB	ASSEMBLY	EP .0100	
	08125	CONE		20253	2	2A4	902A4	20253	5AB	ASSEMBLY	EP .0020	
	08231D	CUP		20253	1	1AB						
	X65-08125	CONE	SPCR A	20000	1	04P						
	08125	CONE		30000	2	2AF	903A1	30000	6AB	ASSEMBLY	EP .0000	86 022
	08231D	CUP		30000	1	1AG	90040	30000	6AB	ASSEMBLY	EP .0050	
	X65-08125	CONE	SPCR A	0	1	04P	90042	30000	6AB	ASSEMBLY	EP .0060	
							91.063	30000	6AB	ASSEMBLY	EP .0100	
	08125	CONE		30030	2	2AF	90036	30030	6AB	ASSEMBLY	EP .0020	
	08231D	CUP		30000	1	1AG						
	X65-08125	CONE	SPCR A	0	1	04P						
	08125	CONE		30030	2	2AF	90057	30033	6AB	ASSEMBLY	EP .0050	
	08231D	CUP		30039	1	1AG						
	X65-08125	CONE	SPCR A	0	1	04P						
	08125	CONE		4E024	2	2AA	9E4A3	4E024	5AB	ASSEMBLY	EP .0100	
	08231D	CUP		20024	1	1AB						
	X65-08125	CONE	SPCR A	2E000	1	04P						
	08125	CONE		40024	2	2AA	90024	40024	5AB	ASSEMBLY	EP .0080	
	08231D	CUP		40024	1	1AB	90038	40024	5AB	ASSEMBLY	EP .0120	
	X65-08125	CONE	SPCR A	20000	1	04P						
	08125	CONE		0	2	2AF	905A2	0	6AB	ASSEMBLY	EP .0000	
	08231D	CUP		0	1	1AG	90039	0	6AB	ASSEMBLY	EP .0010	
	X65-08125	CONE	SPCR A	0	1	04P	90061	0	6AB	ASSEMBLY	EP .0040	
							90023	0	6AB	ASSEMBLY	EP .0050	
	08125	CONE		0-30	2	2AF	90045	0-30	6AB	ASSEMBLY	EP .0020	
	08231D	CUP		0	1	1AG						
	X65-08125	CONE	SPCR A	0	1	04P						
	08125	CONE		0 174	2	2AF	90048	0 174	6AB	ASSEMBLY	EP .0000	
	08231D	CUP		0	1	1AG						
	X65-08125	CONE	SPCR A	0	1	04P						
	08125	CONE		20024	2	2AA	90041	20024	5AB	ASSEMBLY	EP .0120	78 276
	08231D	CUP		20024	1	1AB						
	X75-08125	CONE	SPCR	20000	1	04A						

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
	08125 08231DC X65-08125	CONE CUP CONE SPCR A		30000 30000 0	2	2AF 1AG 104P	90060	30000	6AB	ASSEMBLY	EP .0040	74 107
08125-B	08125-B 08231	CONE CUP		00 00	1	2AF 1AF	90035	00	7AA	ASSEMBLY		91-256
	08125-B 08231-B	CONE CUP		0 0	1	2AF 1AH	90027	0	6AA	ASSEMBLY		77 003
	08125-B 08231-B	CONE CUP		0-174 0	1	2AF 1AH	90028	0-174	6AA	ASSEMBLY		90 115
	08125-B 08231-B	CONE CUP		00 00	1	2AF 1AH	90026	00	7AA	ASSEMBLY		90 115
	08125-B 08231D	CONE CUP		0 0	2	2AF 1AG	90033	0	6AB	ASSEMBLY		90 115
08125H	08125H 08231-B	CONE CUP		0 0	1	2AF 1AH	90029	0	6AA	ASSEMBLY		
08125HB	08125HB 08231-B	CONE CUP		00 00	1	2AF 1AH	90030	00	7AA	ASSEMBLY		90 115
NA08125	NA08125 08231D	CONE CUP		30000 30000	2	2AF 1AG	90031	30000	6AB	ASSEMBLY	EP .0030	
09062	09062 09195	CONE CUP		0 0	1	2AF 1AF	90010	0	6AA	ASSEMBLY		
	09062 09196	CONE CUP		0 0	1	2AF 1AF	90034	0	6AA	ASSEMBLY		
09067	09067 09194	CONE CUP		0 0	1	2AF 1AF	90011	0	6AA	ASSEMBLY		
	09067 09195	CONE CUP		40024 20024	1	2AD 1AD	9F499	4F024	5AA	ASSEMBLY		
	09067 09195	CONE CUP		0 0	1	2AF 1AF	90012	0	6AA	ASSEMBLY		
	09067 09195AB	CONE CUP		0 0	1	2AF 1AH	90013	0	6AA	ASSEMBLY		
	09067 09196	CONE CUP		0 0	1	2AF 1AF	90033	0	6AA	ASSEMBLY		
09067-B	09067-B 09195	CONE CUP		00 00	1	2AF 1AF	90035	00	7AA	ASSEMBLY		82 307
	09067-B 09196	CONE CUP		00 00	1	2AF 1AF	90014	00	7AA	ASSEMBLY		82 307
09070	09070 09194	CONE CUP		0 0	1	2AF 1AF	90027	0	6AA	ASSEMBLY		
	09070 09195	CONE CUP		0 0	1	2AF 1AF	90015	0	6AA	ASSEMBLY		
09074	09074 09194	CONE CUP		0 0	1	2AF 1AF	90020	0	6AA	ASSEMBLY		
	09074 09194	CONE CUP		0-30 0-39	1	2AF 1AF	90021	0-33	6AA	ASSEMBLY		
	09074 09195AB	CONE CUP		0 0	1	2AF 1AH	90037	0	6AA	ASSEMBLY		

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASST CODE	ASST INSP	SGC DESC	END PLAY OR PRELOAD	OBSOLETE DATE
	09074 09196	CONE CUP		0 0		1 2AF 1 1AF	90022	0	6AA ASSEMBLY		
09074A	09074A 09082 1003	CONE CONE ROLLER		40156 40000		1 2AA 1 2AA 28 C10	90016	40000	531 ASSEMBLY		76 166
	09074A 09082 09201 1003 154592 165180	CONE CONE CUP ROLLER WASHER NUT		40156 40000 40024		1 2AA 1 2AA 2 1AA 28 010 1 469 1 463	90018	40000	530 ASSEMBLY		
	09074A 09082 09201 1003 154592 165180	CONE CONE CUP ROLLER WASHER NUT		40156 40000 40024		2 2AA 2 2AA 4 1AA 56 010 2 469 2 463	90038	40000	531 ASSEMBLY		
09074-B	09074-B 09194	CONE CUP		00 00		1 2AF 1 1AF	90023	00	7AA ASSEMBLY		
09078	09078 09194	CONE CUP		0 0		1 2AF 1 1AF	90025	0	6AA ASSEMBLY		
	09078 09195	CONE CUP		0 0		1 2AF 1 1AF	90026	0	6AA ASSEMBLY		
	09078 09195AB	CONE CUP		0 0		1 2AF 1 1AA	90019	0	6AA ASSEMBLY		
	09078 09196	CONE CUP		0 0		1 2AF 1 1AF	90028	0	6AA ASSEMBLY		
09079	09079 09083 09195DB 1003 154592 165180	CONE CONE CUP ROLLER WASHER NUT		40000 40000 40000		1 2AA 1 2AA 1 1AB 28 010 1 469 1 463	90030	40000	530 ASSEMBLY		
	09079 09083 09195DB 1003 154592 165180	CONE CONE CUP ROLLER WASHER NUT		40000 40000 40000		2 2AA 2 2AA 2 1AB 56 010 2 469 2 463	90039	40000	531 ASSEMBLY		
09081	09081 09194 X15-09081	CONE CUP CONE SPCR A		20051 20024 20000		2 2AP 2 1AD 1 04A	911036	211051	5AA ASSEMBLY	EP .0050	
	09081 09194 X15-09081	CONE CUP CONE SPCR A		20051 20024 20000		2 2AP 2 1AD 1 04A	90036	20051	5AA ASSEMBLY	EP .0050	
XC09636C	XC09636C XC09636D	CONE CUP		30130 30000		1 2YB 2 1HA	90010	30130	5KP ASSEMBLY		
JP10044	JP10044 JP10010	CONE CUP		BH000 BH000		1 2EF 1 1CF	9GB01	BG000	6CA ASSEMBLY		91 073
	JP10044 JP10010	CONE CUP		B0000 B0000		1 2EF 1 1CF	90B01	B0000	6CA ASSEMBLY		
	JP10044 JP10010	CONE CUP		B8000 B8000		1 2EF 1 1CF	98B01	B8000	6CA ASSEMBLY		86 037

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q/A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OR	OBSOLETE DATE	
JP10048	JP10044	CONE		BH000	1	2EF	9GB02	BG000	6CA	ASSEMBLY			90 079	
	JP10010-B	CUP		BH000	1	1CH								
	JP10044	CONE		B0000	1	2EF	90B02	B0000	6CA	ASSEMBLY				
	JP10010-B	CUP		B0000	1	1CH								
	JP10044	CONE		B8000	1	2EF	98B02	B8000	6CA	ASSEMBLY			86 037	
	JP10010-B	CUP		B8000	1	1CH								
	JP10044	CONE		B8595	1	2EF	98B03	B8595	6CA	ASSEMBLY			82 092	
	JP10010-B	CUP		B8000	1	1CH								
	JP10048	CONE		C0000	1	2DF	90CA1	C0000	6CY	ASSEMBLY				
	JP10019HR	CUP		C0000	1	1CY								
	K143296	O RING			1	090								
	K147794	SEAL			1	090								
K147795R	SNAP RING			1	049									
K148863	RIB RING			1	090									
K148864	SEAL RET			1	090									
K150190	LOCK PIN			1	090									
K524657	SCREWPIUG			2	090									
JP10048	CONE			C0227	1	2DF	90CA2	C0227	6CY	ASSEMBLY			90 267	
JP10019HR	CUP			C0227	1	1CY								
K143296	O RING			1	090									
K147794	SEAL			1	090									
K147795R	SNAP RING			1	049									
K148863	RIB RING			1	090									
K148864	SEAL RET			1	090									
K150190	LOCK PIN			1	090									
K524657	SCREWPIUG			2	090									
JP10048	CONE			B0000	1	2DF	90BA3	B0000	6CY	ASSEMBLY				
JP10019HR	CUP			B0000	1	1CY								
K147795R	SNAP RING			1	049									
K143296	O RING			1	090									
K147794	SEAL			1	090									
K148863	RIB RING			1	090									
K148864	SEAL RET			1	090									
K150190	LOCK PIN			1	090									
K524657	SCREWPIUG			2	090									
JP10049	JP10049	CONE		BE000	1	2EF	9EB01	BE000	6CA	ASSEMBLY				
	JP10010	CUP		BE000	1	1CF								
	JP10049	CONE		BF000	1	2EF	9FB01	BF000	6CA	ASSEMBLY			86 274	
	JP10010	CUP		BF000	1	1CF								
	JP10049	CONE		BH000	1	2EF	9GB01	BG000	6CA	ASSEMBLY			90 354	
	JP10010	CUP		BH000	1	1CF								
	JP10049	CONE		B0000	1	2EF	90B01	B0000	6CA	ASSEMBLY				
	JP10010	CUP		B0000	1	1CF								
	JP10049	CONE		B8000	1	2EF	98B01	B8000	6CA	ASSEMBLY			86 037	
	JP10010	CUP		B8000	1	1CF								
	JP10049	CONE		BH000	1	2EF	9GB02	BG000	6CA	ASSEMBLY			90 354	
	JP10010-B	CUP		BH000	1	1CH								
JP10049	CONE		B0000	1	2EF	90B02	B0000	6CA	ASSEMBLY					
JP10010-B	CUP		B0000	1	1CH									
JP10049	CONE		B8000	1	2EF	98B02	B8000	6CA	ASSEMBLY			86 037		
JP10010-B	CUP		B8000	1	1CH									
JP10049	CONE		CE058	1	2EF	9ECA1	CE058	6CA	ASSEMBLY			90 354		
JP10010-B	CUP		CE058	1	1CH									
JP10049	CONE		CF058	1	2EF	9FC01	CF058	6CA	ASSEMBLY			86 154		
JP10010-B	CUP		CF058	1	1CH	9FCA1	CF058	6CA	ASSEMBLY			90 354		

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
	JP10049	CONE		C0058	1	2EF	90C01	C0058	6CA	ASSEMBLY		82 259
	JP10010-B	CUP		C0058	1	1CH						
JP10049H	JP10049H	CONE		B0000	1	2EF	9GBA2	BF000	6CA	ASSEMBLY		
	JP10010	CUP		BH000	1	1CF						
	K149885	MANIFOLD			1	090						
	JP10049H	CONE		B0000	1	2EF	9GBA3	BG000	6CA	ASSEMBLY		
	JP10010-B	CUP		BH000	1	1CH						
	K148885	MANIFOLD			1	090						
XC10237CC	XC10237CC	CONE		8E252	2	2DA	90011	8E252	850	ASSEMBLY	EP .0160-.0220	
	XC10237DA	CUP		8E252	1	1CB						
	XC10237-S	CONE SPCR A		2E000	1	04B						
	K135420	LOCKPLATE			1	483						
	K145150	AEC			1	480						
	K145151	BACK SPCR			1	090						
	K145152	ENCLOSURE			2	488						
	K145153	FLINGER			2	488						
	K145154	BACK RING			1	090						
	K422089	CAP SCREW			3	482						
	K512096	GROMMET			2	474						
	XC10237CC	CONE		8E252	2	2DA	90010	8E252	850	ASSEMBLY	EP .0160-.0220	
	XC10237DA	CUP		8E252	1	1CB						
	XC10237-S	CONE SPCR A		2E000	1	04B						
	K145151	BACK SPCR			1	090						
	K145152	ENCLOSURE			2	488						
	K145153	FLINGER			2	488						
	K145154	BACK RING			1	090						
	K512096	GROMMET			2	474						
XC10237CD	XC10237CD	CONE		20227	2	2DA	902A1	20227	5CA	ASSEMBLY	EP .0160	
	XC10237DB	CUP		20227	2	1CA						
	XC10237-SA	CONE SPCR A1		20000	1	04B						
	XC10237-SB	CUP SPCR RSR		20000	1	04C						
JXC10238CJ	JXC10238CJ	CONE		KE227	1	2AB	9EKA1	KE227	5AA	ASSEMBLY	EP .0315-.0025	
	JXC10238DG	CUP		KE227	2	1AA						
	XC10238-SC	CUP SPCR R		2E000	1	04A						
JXC10240CD	JXC10240CD	CONE		K0000	2	2AA	90FA1	K0000	5BA	ASSEMBLY	EP .0010	
	JXC10240DE	CUP		K0000	1	1BB						
	XC10240-SA	ENCL RING			2	090						
T10250	T10250E	Q SPCR		20000	1	04H	90010	20000	367	THR. BRG	EP .0000	83 069
	T10250CL	CAGE RING			2	060						
	T10250CS	CAGE RING			2	060						
	T10250DH	DBL IH RC		20000	1	075						
	T10250F	FLT IH RC		20000	2	075						
	T10250R	ROLLERS			46	010						
	K525374	UNKNOWN			46	030						
T10250DH	T10250E	Q SPCR		20000	1	04H	90010	20000	367	ASSEMBLY	EP .0000	
	T10250CL	CAGE RING			2	060						
	T10250CS	CAGE RING			2	060						
	T10250DH	DBL IH RC		20000	1	075						
	T10250F	FLT IH RC		20000	2	075						
	T10250R	ROLLERS			46	010						
	K525374	UNKNOWN			46	030						
XC10638C	XC10638C	CONE		0-174	1	2HF	90010	0-174	6EA	ASSEMBLY		75 092
	XC10638D	CUP		0	1	1EF						
	XC10638C	CONE		0-227	1	2HF	90014	0-227	6EA	ASSEMBLY		75 092
	XC10638D	CUP		0-227	1	1EG						
	XC10638C	CONE		0-483	1	2HF	90020	0-483	6EA	ASSEMBLY		
	XC10638D	CUP		0-483	1	1EF						

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
XC10638CA	XC10638CA	CONE		0-174	1	2HF	90011	0-174	6EA	ASSEMBLY		75 092
	XC10638D	CUP		0	1	1EF						
	XC10638CA	CONE		0-227	1	2HF	90015	0-227	6EA	ASSEMBLY		75 092
	XC10638D	CUP		0-227	1	1EG						
XC10638CA	XC10638CA	CONE		0-483	1	2HF	90021	0-483	6EA	ASSEMBLY		
	XC10638D	CUP		0-483	1	1EF						
	XC10638CA	CONE		0-174	1	2HF	90012	0-174	6FA	ASSEMBLY		75 092
	XC10639D	CUP		0	1	1FF						
XC10639C	XC10639C	CONE		0-227	1	2HF	90016	0-227	6FA	ASSEMBLY		75 092
	XC10639D	CUP		0-227	1	1FG						
	XC10639C	CONE		0-483	1	2HF	90018	0-483	6FA	ASSEMBLY		
	XC10639D	CUP		0-483	1	1FF						
XC10639CA	XC10639CA	CONE		0-174	1	2HF	90013	0-174	6FA	ASSEMBLY		75 092
	XC10639D	CUP		0	1	1FF						
	XC10639CA	CONE		0-227	1	2HF	90017	0-227	6FA	ASSEMBLY		75 092
	XC10639D	CUP		0-227	1	1FG						
XC10639CA	XC10639CA	CONE		0-483	1	2HF	90019	0-483	6FA	ASSEMBLY		
	XC10639D	CUP		0-483	1	1FF						
	JEX10739C	JEX10739C	CONE	C0227	1	2AF	90C01	C0227	6AA	ASSEMBLY		
	JEX10739D	CUP		C0227	1	1AF						
JEX10739CA	JEX10739CA	CONE		C0227	1	2AF	90C02	C0227	6AA	ASSEMBLY		
	JEX10739D	CUP		C0227	1	1AF						
XC10836DG	XC10836DG	CUP		40227	1	1AC	90010	40227	5AC	ASSEMBLY		84 067
	XC10836 SA	O RING			1	090						
XC10837C	XC10837C	CONE		20436	1	2LA	90010	20436	5HA	ASSEMBLY		72 136
	XC10837D	CUP		20436	1	1HA						
XC10838C	XC10838C	CONE		20436	1	2LA	90011	20436	5HA	ASSEMBLY		72 136
	XC10838D	CUP		20436	1	1HA						
T11000	T11000	RACE		20000	1	076	92000	20000	357	ASSEMBLY		79 262
	T11000C	CAGE RING			1	060						
	T11000F	RACE		20000	1	076						
	T11000R	ROLLER			24	010						
	T11000	RACE		20000	1	076	90010	20000	367	ASSEMBLY		
	T11000CL	CAGE RING			1	060						
	T11000C5	CAGE RING			1	060						
	T11000F	RACE		20000	1	076						
	T11000CR	ROLLER			24	010						
	K121872	CAGE PINS			24	030						
JP11019HR	JP11019HR	CUP		C0000	1	1DT	90011	C0000	6DY	ASSEMBLY		86 223
	K142273	CAP SCREW			2	469						
	K516787	C R RING			1	090						
	K516789R	SNAP PIN			1	090						
	K516792	LOCK PIN			1	090						
	K518787	PIPE PLUG			2	090						
	K528882	SPRG RET			1	090						
	K528883	RB RGPUSH			1	090						
	K528890	COMP SPRG			24	090						

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	SGC DESC	END PLAY OR PRELOAD	OR	OBSOLETE DATE
	JP11019HR	CUP		B0618		1	1DY	90B06	B0618	6DY	ASSEMBLY	
	K143217	SEAL RET				1	090					
	K516787	C R RING				1	090					
	K516789R	SNAP RING				1	090					
	K516792	LOCK PIN				1	090					
	K518774	PRESSEAL				1	090					
	K518787	PIPE PLUG				2	090					
	K523979	O RING				1	090					
	JP11019HR	CUP		C0000		1	1DY	90C05	C0000	6DY	ASSEMBLY	
	K143217	SEAL RET				1	090	90C06	C0000	6DY	ASSEMBLY	85 140
	K516787	C R RING				1	090					
	K516789R	SNAP RING				1	090					
	K516792	LOCK PIN				1	090					
	K518774	PRESSEAL				1	090					
	K518787	PIPE PLUG				2	090					
	K523979	O RING				1	090					
	JP11019HR	CUP		30000		1	1DH	90010	30000	6DA	ASSEMBLY	83 313
	K516787	C R RING				1	090					
	K516788	SEAL RET				1	090					
	K516789R	SNAP RING				1	090					
	K516792	LOCK PIN				1	090					
	K516793	O RING				1	090					
	JP11019HR	CUP		B0618		1	1DY	90B05	B0618	6DY	ASSEMBLY	83 311
	K516787	C R RING				1	090					
	K516788	SEAL RET				1	090					
	K516789R	SNAP RING				1	090					
	K516792	LOCK PIN				1	090					
	K518774	PRESSEAL				1	090					
	K518787	PIPE PLUG				2	090					
	K523979	O RING				1	090					
	JP11019HR	CUP		C0000		1	1DY	90C01	C0000	6DY	ASSEMBLY	88 145
	K516787	C R RING				1	090					
	K516788	SEAL RET				1	090					
	K516789R	SNAP RING				1	090					
	K516792	LOCK PIN				1	090					
	K518774	PRESSEAL				1	090					
	K518787	PIPE PLUG				2	090					
	K523979	O RING				1	090					
	JP11019HR	CUP		C0227		1	1DY	90C03	C0227	6DY	ASSEMBLY	83 311
	K516787	C R RING				1	090					
	K516788	SEAL RET				1	090					
	K516789R	SNAP RING				1	090					
	K516792	LOCK PIN				1	090					
	K518774	PRESSEAL				1	090					
	K518787	PIPE PLUG				2	090					
	K523979	O RING				1	090					
	JP11019HR	CUP		C0000		1	1DY	90C02	C0000	6DY	ASSEMBLY	77 060
	K516787	C R RING				1	090					
	K516788A	SEAL RET				1	090					
	K516789R	SNAP RING				1	090					
	K516792	LOCK PIN				1	090					
	K518787	PIPE PLUG				1	090					
	K523979	O RING				1	090					
KA11020-Z	15574A	CONE		40024		1	2AA	SA002		46A	KIT	
	15522A	CUP		20024		1	1AA					