



33115...B01
33209...C01
33213...D01
33251...E01
33275...F01
33281...G01
33287...H01
33449...I01
33889...J01
33689...K01
33895...L01
33895...M01
33943...N01
34294...O01

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q/A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
XAA33115	XAA33115 Y33115	CONE CUP		HF000 HF000	1 1	2CA 1CA	92HA1	HF000	580	ASSEMBLY		
	XAA33115 Y33115	CONE CUP		KF000 KF000	1 1	2CA 1CA	92KA4	KF000	580	ASSEMBLY		87 027
	XAA33115 Y33115	CONE CUP		KF000 KF000	1 1	2CA 1CA	92KA1	K2000	580	ASSEMBLY		
33116	X33116 Y33116	CONE CUP		HF000 HF000	1 1	2CA 1CA	9FHA1	HF000	580	ASSEMBLY		
	X33116 Y33116	CONE CUP		KF000 KF000	1 1	2CA 1CA	92KA1	K2000	580	ASSEMBLY		
33117	X33117 Y33117	CONE CUP		HF000 HF000	1 1	2DA 1CA	92H50	HF000	580	ASSEMBLY		89 228
	X33117 Y33117	CONE CUP		KF000 KF000	1 1	2DA 1CA	92KA1	K2000	580	ASSEMBLY		
	X33117 Y33117	CONE CUP		NF000 NF000	1 1	2DA 1CA	92NA2	N2000	580	ASSEMBLY		
33118	X33118 Y33118	CONE CUP		KF000 KF000	1 1	2EA 1CA	92KA1	K2000	580	ASSEMBLY		
33205	X33205 Y33205	CONE CUP		H1000 H1000	1 1	2AA 1AA	90H50 91H50 92H50	H1000 H1000 H1000	580 580 580	ASSEMBLY ASSEMBLY ASSEMBLY		77 174 92 017
	X33205 Y33205	CONE CUP		H1025 H1024	1 1	2AA 1AA	92H51 92H53	H1025 H1025	580 580	ASSEMBLY ASSEMBLY		
	X33205 Y33205	CONE CUP		H2227 H2000	1 1	2AA 1AA	92H27	H2227	580	ASSEMBLY		
	X33205 Y33205	CONE CUP		KF000 KF000	1 1	2AA 1AA	92KA1	K2000	580	ASSEMBLY		
	X33205 Y33205	CONE CUP		KF025 KF000	1 1	2AA 1AA	92KA3	K2025	580	ASSEMBLY		
	X33205 Y33205	CONE CUP		NF000 NF000	1 1	2AA 1AA	92NA2	N2000	580	ASSEMBLY		
	X33205 Y33205	CONE CUP		H2227 H2000	1 1	2AA 1AA	92H27	H2227	580	ASSEMBLY		80 283
	X33205 Y33205	CONE CUP		H1000 H1000	1 1	2AA 1AA	92H50	H1000	580	ASSEMBLY		89 228
	X33205 Y33205	CONE CUP		KF000 KF000	1 1	2AA 1AA	92KA1	K2000	580	ASSEMBLY		
	X33205 Y33205	CONE CUP		KF708 KF708	1 1	2AA 1AA	92KA2	K2708	580	ASSEMBLY		
33207	X33207 Y33207	CONE CUP		NF000 NF516	1 1	2AA 1AA	92NA3	N2000	580	ASSEMBLY		
	X33207 Y33207	CONE CUP		H1000 H1000	1 1	2AA 1AA	92H50	H1000	580	ASSEMBLY		90 030
	X33207 Y33207	CONE CUP		KF000 KF000	1 1	2AA 1AA	92KA1	K2000	580	ASSEMBLY		
	X33207 Y33207	CONE CUP		NF000 NF000	1 1	2AA 1AA	92NA2	N2000	580	ASSEMBLY		
33208	X33208 Y33208	CONE CUP		H1000 H1000	1 1	2AA 1AA	92H50	H1000	580	ASSEMBLY		90 030
	X33208 Y33208	CONE CUP		KF000 KF000	1 1	2AA 1AA	92KA1	K2000	580	ASSEMBLY		
	X33208 Y33208	CONE CUP		NF000 NF000	1 1	2AA 1AA	92NA2	N2000	580	ASSEMBLY		

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q/A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBsolete DATE
33209	X33209	CONE		H2000		1 2BA	92H50	H2000	580	ASSEMBLY		89 228
	Y33209	CUP		H2000		1 1BA						
33210	X33209	CONE		KF000		1 2BA	92KA1	K2000	580	ASSEMBLY		
	Y33209	CUP		KF000		1 1BA						
33210	X33210	CONE		HF516		1 2BA	92HA3	HF516	580	ASSEMBLY		90 030 77 174
	Y33210	CUP		HF516		1 1BA						
33210	X33210	CONE		H1000		1 2BA	92H50	H1000	580	ASSEMBLY		90 030 77 174
	Y33210	CUP		H1000		1 1BA	91H50	H1000	580	ASSEMBLY		
33210	X33210	CONE		H1514		1 2BA	92H51	H1514	580	ASSEMBLY		86 044
	Y33210	CUP		H1514		1 1BA						
33210	X33210	CONE		KF000		1 2BA	92KA1	K2000	580	ASSEMBLY		
	Y33210	CUP		KF000		1 1BA						
33210	X33210	CONE		NF000		1 2CA	92HA2	N2000	580	ASSEMBLY		
	Y33210	CUP		NF000		1 1BA						
33211	X33211	CONE		H1000		1 2BA	90H50	H1000	580	ASSEMBLY		77 174 90 030
	Y33211	CJP		H1000		1 1BA	92H50	H1000	580	ASSEMBLY		
33211	X33211	CONE		KF000		1 2BA	92KA1	K2000	580	ASSEMBLY		
	Y33211	CUP		KF000		1 1BA						
33211	X33211	CONE		NF000		1 2BA	92HA2	N2000	580	ASSEMBLY		
	Y33211	CUP		NF000		1 1BA						
XGA33211	XGA33211	CONE		KF000		1 2BA	92KA1	K2000	580	ASSEMBLY		
	Y33211	CUP		KF000		1 1BA						
XGA33211	XGA33211	CONE		NF000		1 2BA	92HA4	N2000	580	ASSEMBLY		
	Y33211	CUP		NF000		1 1BA						
XLA33211	XLA33211	CONE		KF000		1 2BA	92KA1	K2000	580	ASSEMBLY		
	Y33211	CJP		KF000		1 1BA						
33212	X33212	CONE		H1000		1 2BA	92H50	H1000	580	ASSEMBLY		88 188
	Y33212	CUP		H1000		1 1BA						
33212	X33212	CONE		KF000		1 2BA	92KA1	K2000	580	ASSEMBLY		
	Y33212	CUP		KF000		1 1BA						
33212	X33212	CONE		NF000		1 2BA	92HA2	NF000	580	ASSEMBLY		
	Y33212	CUP		NF000		1 1BA						
XAA33212	XAA33212	CONE		KF000		1 2BA	92KA1	K2000	580	ASSEMBLY		
	Y33212	CUP		KF000		1 1BA						
XAB 33212	XAB 33212	CONE		KF000		1 2BA	92KA1	K2000	580	ASSEMBLY		
	Y33212	CUP		KF000		1 1BA						
XGB 33212	XGB 33212	CONE		KF000		1 2BA	92KA1	K2000	580	ASSEMBLY		
	Y33212R	CUP		KF000		1 1CC						
33213	X33213	CONE		H1000		1 2CA	92H50	H1000	580	ASSEMBLY		90 010 90 177 77 174
	Y33213	CUP		H1000		1 1CA	91H50	H1000	580	ASSEMBLY		
33213	X33213	CONE		H1000		1 2CA	92HA1	H2702	580	ASSEMBLY		89 188
	Y33213	CUP		H1000		1 1CA						
33213	X33213	CONE		KF000		1 2CA	92KA1	K2000	580	ASSEMBLY		
	Y33213	CUP		KF000		1 1CA						
33213	X33213	CONE		KF000		1 2CA	92KA9	K2702	580	ASSEMBLY		
	Y33213	CUP		KF000		1 1CA						

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	QTY	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAT OR PRELOAD	OBSOLETE DATE
33214	X33213	CONE		NF000	1	2CA	92NA3	N2000	580	ASSEMBLY		
	Y33213	CUP		NF000	1	1CA						
	X33214	CONE		H1000	1	2CA	92H50	H1000	580	ASSEMBLY		90 030
	Y33214	CUP		H1000	1	1CA	91H50	H1000	580	ASSEMBLY		
33215	X33214	CONE		KF000	1	2CA	92KA1	K2000	580	ASSEMBLY		
	Y33214	CUP		KF000	1	1CA						
	X33214	CONE		NF000	1	2CA	92NA2	N2000	580	ASSEMBLY		
	Y33214	CUP		NF000	1	1CA						
33216	X33215	CONE		HF514	1	2CA	92HA1	HF514	580	ASSEMBLY		
	Y33215	CUP		HF514	1	1CA						
	X33215	CONE		H1000	1	2CA	92H50	H1000	580	ASSEMBLY		90 030
	Y33215	CUP		H1000	1	1CA						
33217	X33215	CONE		KF000	1	2CA	92KA1	K2000	580	ASSEMBLY		
	Y33215	CUP		KF000	1	1CA						
	X33215	CONE		KF000	1	2CA	92KA9	K2702	580	ASSEMBLY		
	Y33215	CUP		KF000	1	1CA						
33225	X33216	CONE		H2000	1	2CA	92H50	H2000	580	ASSEMBLY		89 228
	Y33216	CUP		H2000	1	1CA						
	X33216	CONE		KF000	1	2CA	92KA1	K2000	580	ASSEMBLY		
	Y33216	CUP		KF000	1	1CA						
33225	X33216	CONE		NF000	1	2CA	92NA2	N2000	580	ASSEMBLY		
	Y33216	CUP		NF000	1	1CA						
	X33217	CONE		H1000	1	2CA	90H50	H1000	580	ASSEMBLY		77 174
	Y33217	CUP		H1000	1	1CA	92H50	H1000	580	ASSEMBLY		90 010
33225	X33217	CONE		KF000	1	2CA	92KA1	K2000	580	ASSEMBLY		
	Y33217	CUP		KF000	1	1CA						
	33225	CONE		0	1	2CF	90010	0	6CA	ASSEMBLY		
	33462	CUP		0	1	1CF						
33225	33225	CONE		20024	2	2CA	90091	20024	5CB	ASSEMBLY	EP .0080	
	33462D	CUP		20024	1	1CB						
	X15-33225	CONE SPCR A		20000	1	04A						
	33225	CONE		30000	2	2CF	90067	30000	6CB	ASSEMBLY	EP .0040	
33225	33462D	CUP		30000	1	1CG						
	X15-33225	CONE SPCR A		0	1	04A						
	33225	CONE		40024	2	2CA	90074	40024	5CB	ASSEMBLY	EP .0060	
	33462D	CUP		40024	1	1CB						
33225	X15-33225	CONE SPCR A		20000	1	04A						
	33225	CONE		0	1	2CF	90011	0	6CA	ASSEMBLY		
	33472	CUP		0	1	1CF						
	33225	CONE		40024	2	2CA	90012	40024	5CA	ASSEMBLY	EP .0080	75 133
33225	33472	CUP		40024	2	1CA						
	Y15-33472	CUP SPCR		20000	1	04C						
	33225	CONE		00	1	2CF	90095	00	7CA	ASSEMBLY		90 128
	33462	CUP		00	1	1CF						
33251	33251	CONE		0	1	2CF	90057	0	6CA	ASSEMBLY		
	33461	CUP		0	1	1CF						
33251	33251	CONE		0	1	2CF	90013	0	6CA	ASSEMBLY		
	33462	CUP		0	1	1CF						

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	SGC DESC	END PLAY PRELOAD	OR	OBSOLETE DATE
	33251 33462-B	CONE CUP		0 0		1 2CF 1 1CH	90108	0	6AA ASSEMBLY			
	33251 33462D X25-33251	CONE CUP CONE SPCR A		20024 20024 20000		2 2CA 1 1CB 1 04B	90096 90093 90097	20024 20024 20024	5CB ASSEMBLY 5CB ASSEMBLY 5CB ASSEMBLY	EP .0040 EP .0060 EP .0120		
	33251 33462D X25-33251	CONE CUP CONE SPCR A		40024 40024 20000		2 2CA 1 1CB 1 04B	90083 90094 90085	40024 40024 40024	5CB ASSEMBLY 5CB ASSEMBLY 5CB ASSEMBLY	EP .0080 EP .0120 EP .0160		
	33251 33462DC X25-33251	CONE CUP CONE SPCR A		40024 40024 20000		2 2CA 1 1CB 1 04B	90090	40024	5CB ASSEMBLY	EP .0120		
33251	33472	CONE CUP	0	0		1 2CF 1 1CF	90014	0	6CA ASSEMBLY			
	33251 66225 33462 66462 Y15-33462	CONE CONE CUP CUP CUP SPCR S		20024 20024 20024 20024 20000		1 2CA 1 2BP 1 1CL 1 1CL 1 04R	90048	20024	5CA ASSEMBLY	EP .0060		
	33251 78750 K53494 X15-33251	CONE CONE CUP CONE SPCR A		40024 40024 40024 20000		1 2CA 1 2CA 1 1CF 1 04B	90041	40024	5CD ASSEMBLY	EP .0080		
33261	33261 33462	CONE CUP		0 0		1 2CF 1 1CF	90086	0	6CA ASSEMBLY			
	33261 33462D X15-33262	CONE CUP CONE SPCR A		40024 40024 20000		2 2CA 1 1CB 1 04A	90060	40024	5CB ASSEMBLY	EP .0060		
	33261 33462D X15-33262	CONE CUP CONE SPCR A		0 0 0		2 2CF 1 1CG 1 04A	90098	0	6CB ASSEMBLY	EP .0030		
33262	33262 33462	CONE CUP		0 0		1 2CF 1 1CF	90015	0	6CA ASSEMBLY			
	33262 33462-B	CONE CUP		0 0		1 2CF 1 1CH	90045	0	6CA ASSEMBLY			
	33262 33462D X15-33262	CONE CUP CONE SPCR A		20024 20024 20000		2 2CA 1 1CB 1 04A	90078 90100 90053	20024 20024 20024	5CB ASSEMBLY 5CB ASSEMBLY 5CB ASSEMBLY	EP .0030 EP .0040 EP .0060		
	33262 33462D X15-33262	CONE CUP CONE SPCR A		30000 30000 0		2 2CF 1 1CG 1 04A	90084	30000	6CB ASSEMBLY	EP .0030		
	33262 33462D X25-33262	CONE CUP CONE SPCR		40024 40024 20000		2 2CA 1 1CB 1 04B	90102	40024	5CB ASSEMBLY	EP .0160		77 200
33262-B	33262-B 33462	CONE CUP		00 00		1 2CF 1 1CF	90016	00	7CA ASSEMBLY			90 128
	33262-B 33462-B	CONE CUP		00 00		1 2CF 1 1CH	90017	00	7CA ASSEMBLY			90 128
33269	33269 33462	CONE CUP		0 0		1 2CF 1 1CF	90018	0	6CA ASSEMBLY			
	33269 33462D X15-33269	CONE CUP CONE SPCR		00024 20024 20000		2 2CA 1 1CB 1 04B	90063	20024	5CB ASSEMBLY	EP .0080		77 200

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	SGC DESC	END PLAY OR PRELOAD	OBSOLETE DATE
33275	33275	CONE		30058	1	2CF	90021	30058	6CA ASSEMBLY		
	33462	CUP		30058	1	1CF					
33275	33275	CONE		30059	1	2CF	90022	30059	6CA ASSEMBLY		
	33462	CUP		30059	1	1CF					
33275	33275	CONE		30060	1	2CF	90023	30060	6CA ASSEMBLY		
	33462	CUP		30060	1	1CF					
33275	33275	CONE		0	1	2CF	90019	0	6CA ASSEMBLY		
	33462	CUP		0	1	1CF					
33275	33275	CONE		3E000	2	2CF	9E3A1	3E000	6CA ASSEMBLY	EP .0030	89 072
	33462	CUP		30000	2	1CF					
	X15-33275	CUP SPCR	Q	2E000	1	04B					
	Y25-33462	CUP SPCR	Q	2E000	1	04C					
33275	33275	CONE		30000	2	2CF	9E3A2	3E000	6CA ASSEMBLY	EP .0030	89 072
	33462	CUP		30000	2	1CF					
	X15-33275	CUP SPCR	Q	0-E000	1	04B					
	Y25-33462	CUP SPCR	Q	0-E000	1	04C					
33275	33275	CONE		0	1	2CF	90020	0	6CA ASSEMBLY		
	33462-B	CUP		0	1	1CH					
33275	33275	CONE		30000	2	2CF	90106	30000	6CA ASSEMBLY	EP .0000	
	33462D	CUP		30000	2	1CF	903A3	30000	6CA ASSEMBLY	EP .0000	
X35-33275	CONE SPCR A		0	1	04Q						
33275	33275	CONE		40024	2	2CL	90075	40024	5CB ASSEMBLY	EP .0060	
	33462D	CUP		40024	1	1CB	90079	40024	5CB ASSEMBLY	EP .0080	
	X35-33275	CONE SPCR A		20000	1	04Q	90062	40024	5CB ASSEMBLY	EP .0120	
33275	33275	CONE		40024	2	2CL	90088	40024	5CB ASSEMBLY	EP .0160	
	33462D	CUP		40024	1	1CB					
	X45-33275	CONE SPCR A1		20000	1	04B					
33275	33275	CONE		30058	1	2CF	90024	30058	6CA ASSEMBLY		
	33472	CUP		30058	1	1CF					
33275	33275	CONE		30059	1	2CF	90025	30059	6CA ASSEMBLY		
	33472	CUP		30059	1	1CF					
33275	33275	CONE		30060	1	2CF	90026	30060	6CA ASSEMBLY		
	33472	CUP		30060	1	1CF					
33275	33275	CONE		0	1	2CF	90056	0	6CA ASSEMBLY		
	33472	CUP		0	1	1CF					
33275	33275	CONE		70016	2	2CL	90054	70016	5CA ASSEMBLY	EP .0050	77 200
	33472	CUP		20082	2	1CA					
	Y35-33472	CUP SPCR		20000	1	04C					
33275	33275	CONE		40024	1	2CL	90089	40024	5CA ASSEMBLY	EP .0160	
	H715345	CONE		40024	1	2CL					
	33462	CUP		40024	1	1CL					
	H715311	CUP		40024	1	1CL					
	X1H33275	CONE SPCR AH		20000	1	04B					
33275-B	33275-B	CONE		00	1	2CF	90027	00	7CA ASSEMBLY		
	33462	CUP		00	1	1CF					
33275-B	33275-B	CONE		00	1	2CF	90042	00	7CA ASSEMBLY		
	33462-B	CUP		00	1	1CH					
33275H	33275H	CONE		0	1	2CF	90028	0	6CA ASSEMBLY		
	33462-B	CUP		0	1	1CH					
33275HB	33275HB	CONE		00	1	2CF	90073	00	7CA ASSEMBLY		72 188
	33462-B	CUP		00	1	1CH					

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
	33287 33462 Y55-33462	CONE CUP CUP SPCR R		20024 20024 20000	2	2CL 1CL 04R	90110	20024	5CA	ASSEMBLY	EP .0060	
	33287 33462-B	CONE CUP		0 0	1	2CF 1CH	90040	0	6CA	ASSEMBLY		
	33287 33462-B	CONE CUP		0-30 0	1	2CF 1CH	90061	0-30	6CA	ASSEMBLY		
	33287 33462-B	CONE CUP		0-30 0 39	1	2CF 1CH	90103	0-33	6CA	ASSEMBLY		
	33287 33462D	CONE CUP		0 0	2	2CF 1CG	90076	0	6CB	ASSEMBLY		
	33287 33462D X35-33287	CONE CUP CONE SPCR A		20024 20024 20000	2	2CL 1CB 04Q	90082 902A1	20024 20024	5CB 5CB	ASSEMBLY ASSEMBLY	EP .0020 EP .0060	
	33287 33462D X35-33287	CONE CUP CONE SPCR A		20024 20024 40000	2	2CL 1CB 04Q	902A2	20649	5CB	ASSEMBLY		
	33287 33462D X35-33287	CONE CUP CONE SPCR A		30000 30000 0	2	2CF 1CG 04Q	90105 90104	30000 30000	6CB 6CB	ASSEMBLY ASSEMBLY	EP .0030 EP .0060	
	33287 33462D X35-33287	CONE CUP CONE SPCR A		30434 30039 0	2	2CF 1CG 04Q	90109	30434	6CB	ASSEMBLY	EP .0010	
	33287 33462D X35-33287	CONE CUP CONE SPCR A		40024 40024 20000	2	2CL 1CB 04Q	90107 90065 90064 90092 90087	40024 40024 40024 40024 40024	5CB 5CB 5CB 5CB 5CB	ASSEMBLY ASSEMBLY ASSEMBLY ASSEMBLY ASSEMBLY	EP .0060 EP .0080 EP .0100 EP .0120 EP .0160	
	33287 33462D X35-33287	CONE CUP CONE SPCR A		0 0 0	2	2CF 1CG 04Q	90058	0	6CB	ASSEMBLY	EP .0060	
	33287 33462D X35-33287 Y55-33462	CONE CUP CONE SPCR A CUP SPCR R		20024 20024 20000 20000	4	2CL 2CB 204Q 04R	90080	20024	5CC	ASSEMBLY	EP .0100	
	33287 33462DC X35-33287	CONE CUP CONE SPCR A		30030 30039 0	2	2CF 1CG 04Q	90072	30033	6CB	ASSEMBLY	PL .0010	
	33287 33462DC X35-33287	CONE CUP CONE SPCR A		40024 40024 20000	2	2CL 1CB 04Q	90066	40024	5CB	ASSEMBLY	EP .0100	
	33287 33472	CONE CUP		0 0	1	2CF 1CF	90047	0	6CA	ASSEMBLY		
	33287 33472 X15-33287 Y25-33472	CONE CUP CONE SPCR A CUP SPCR		40024 40024 20000 20000	2	2CL 1CA 04Q 04C	90052	40024	5CA	ASSEMBLY	EP .0140	77 200
	33287 33472DC X15-33287	CONE CUP CONE SPCR A		40081 40262 20000	2	2CL 1CB 04Q	90059	40262	5CB	ASSEMBLY	EP .0100	
33287-B	33287-B 33462-B	CONE CUP		00 00	1	2CF 1CH	90046	00	7CA	ASSEMBLY		50 128

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	ASSY SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
33281	33281 33462	CONE CUP		0 0		1 2CF 1 1CF	90029	0		6CA ASSEMBLY		
	33281 33462	CONE CUP		0-30 0-39		1 2CF 1 1CF	90050	0-33		6CA ASSEMBLY		
	33281 33462-B	CONE CUP		30059 30059		1 2CF 1 1CH	90044	30059		6CA ASSEMBLY		
	33281 33462-B	CONE CUP		0 0		1 2CF 1 1CH	90030	0		6CA ASSEMBLY		
	33281 33462-B	CONE CUP		0-30 0-39		1 2CF 1 1CH	90049	0-33		6CA ASSEMBLY		
	33281 33462D X15-33281	CONE CUP CONE SPCR A		20024 20024 20000		2 2CF 1 1CF 1 04B	902A4 902A2	20024 20024		5CB ASSEMBLY 5CB ASSEMBLY	EP .0080 EP .0100	
	33281 33462D X15-33281	CONE CUP CONE SPCR A		30000 30000 0		2 2CF 1 1CF 1 04B	90081 903A3 90099 90101	30000 30000 30000 30000		6CB ASSEMBLY 6CB ASSEMBLY 6CB ASSEMBLY 6CB ASSEMBLY	EP .0010 EP .0020 EP .0030 EP .0050	
	33281 33462D X15-33281	CONE CUP CONE SPCR A		0-30 0-39 0		2 2CF 1 1CF 1 04B	90070	0-33		6CB ASSEMBLY	EP .0050	
	33281 33462DC	CONE CUP		00 00		2 2CF 1 1CF	906A1	00		7CB ASSEMBLY		
	33281 33472	CONE CUP		30058 30058		1 2CF 1 1CF	90032	30058		6CA ASSEMBLY		
	33281 33472	CONE CUP		30059 30059		1 2CF 1 1CF	90033	30059		6CA ASSEMBLY		
	33281 33472	CONE CUP		30060 30060		1 2CF 1 1CF	90034	30060		6CA ASSEMBLY		
	33281 33472	CONE CUP		0 0		1 2CF 1 1CF	90031	0		6CA ASSEMBLY		
33281-B	33281-B 33462	CONE CUP		00 00		1 2CF 1 1CF	90039	00		7CA ASSEMBLY		90 128
	33281-B 33462-B	CONE CUP		30058 30058		1 2CF 1 1CH	90035	30058		6CA ASSEMBLY		76 299
	33281-B 33462-B	CONE CUP		30059 30059		1 2CF 1 1CH	90036	30059		6CA ASSEMBLY		76 299
	33281-B 33462-B	CONE CUP		30060 30060		1 2CF 1 1CH	90037	30060		6CA ASSEMBLY		76 299
	33281-B 33462-B	CONE CUP		00 00		1 2CF 1 1CH	90038	00		7CA ASSEMBLY		90 128
33287	33287 33461	CONE CUP		0 0		1 2CF 1 1CF	90055	0		6CA ASSEMBLY		
	33287 33461	CONE CUP		0-30 0		1 2CF 1 1CF	90051	0-30		6CA ASSEMBLY		
	33287 33462	CONE CUP		0 0		1 2CF 1 1CF	90043	0		6CA ASSEMBLY		
	33287 33462	CONE CUP		0-30 0-39		1 2CF 1 1CF	90068	0-33		6CA ASSEMBLY		

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	ASSY SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
JHM33449	JHM33449 JHM33410	CONE CUP		K0025 K0000	1	2AA 1AA	90K01	K0534	5AA	ASSEMBLY		
T33511	09195 T33511 K50729	CUP TUBE BACK RING		40024	2	1AD 1 451 2 419	90010	40024	451	TUBE ASSY		
T33517	09195 T33517 K50729	CUP TUBE BACK RING		40024	2	1AD 1 451 2 419	90010	40024	451	TUBE ASSY		
T33541	09195 T33541 K50729	CUP TUBE BACK RING		20024	2	1AD 1 451 2 419	902A1	20024	451	TUBE ASSY		
33880	33880 33821	CONE CUP		0 0	1	2BF 1BF	90081	0	6BA	ASSEMBLY		
	33880 33821D	CONE CUP		0-30 0-39	2	2BF 1 18G	90080	0-33	6BB	ASSEMBLY		
	33880 33821D X15-33880	CONE CUP CONE SPCR A		30000 30000 0	2	2BF 1 18G 1 04A	90036	30000	6BB	ASSEMBLY	EP .0050	
	33880 33821D X15-33880	CONE CUP CONE SPCR A		40024 40024 20000	2	2BF 1 18G 1 04A	90037	40024	5BB	ASSEMBLY	EP .0080	
	33880 33821D X15-33880	CONE CUP CONE SPCR A		0 0 0	2	2BF 1 18G 1 04A	90039	0	6BB	ASSEMBLY	EP .0050	
33885	33885 33821	CONE CUP		0 0	1	2BF 1BF	90010	0	6BA	ASSEMBLY		
	33885 33821D X15-33885	CONE CUP CONE SPCR A		20024 20024 20000	2	2BP 1 18G 1 04A	90026 90070	20024 20024	5BB 5BB	ASSEMBLY ASSEMBLY	EP .0080 EP .0200	
	33885 33821D X15-33885	CONE CUP CONE SPCR A		40024 40024 20000	2	2BP 1 18G 1 04A	90025	40024	5BB	ASSEMBLY	EP .0200	
	33885 33821D X25-33885	CONE CUP CONE SPCR		20024 20024 20000	2	2BP 1 18G 1 04A	90047	20024	5BB	ASSEMBLY	EP .0160	77 200
	33885 33821D X25-33885	CONE CUP CONE SPCR		40024 40024 20000	2	2BP 1 18G 1 04A	90074	40024	5BB	ASSEMBLY	EP .0160	77 200
33889	33889 33820-B	CONE CUP		0 0	1	2BF 1BH	90027	0	6BA	ASSEMBLY		
	33889 33820-B	CONE CUP		00 00	1	2BF 1BH	90095	00	7BA	ASSEMBLY		
	33889 33821	CONE CUP		0 0	1	2BF 1BF	90011	0	6BA	ASSEMBLY		
	33889 33821 Y15-33821	CONE CUP CUP SPCR R		20024 20024 20000	2	2BP 1 18P 1 04Q	90024	20024	5BA	ASSEMBLY	EP .0010	77 200
	33889 33821 Y25-33821 X35-33889	CONE CUP CUP SPCR CONE SPCR BB		40024 40024 20000 20000	2	2BP 1 18P 1 04B 1 04A	90044	40024	5BA	ASSEMBLY	EP .0180	77 200

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OR DATE	OBsolete DATE
	33889 33821D	CONE CUP		0 0		2 2BF 1 1BG	90038 0			6BB ASSEMBLY			
	33889 33821D X15-33889	CONE CUP CONE SPCR A		20024 20024 20000		2 2BP 1 1BB 1 04A	90032 20024			57B ASSEMBLY	EP .0080		
	33889 33821D X15-33889	CONE CUP CONE SPCR A		30000 30000 0		2 2BF 1 1BG 1 04A	90089 30000 90033 30000			6BB ASSEMBLY 6BB ASSEMBLY	EP .0020 EP .0060		
	33889 33821D X15-33889	CONE CUP CONE SPCR A		40024 40024 20000		2 2BP 1 1BB 1 04A	90088 40024 90029 40024 90073 40024 90062 40024			57B ASSEMBLY 5BB ASSEMBLY 5BB ASSEMBLY 5BR ASSEMBLY	EP .0310 EP .0080 EP .0120 EP .0200		
	33889 33821D X15-33889	CONE CUP CONE SPCR A		0 0 0		2 2BF 1 1BG 1 04A	90097 0			6BB ASSEMBLY	EP .0060		
	33889 33821D X15-33889	CONE CUP CONE SPCR A		00 00 0		2 2BF 1 1BG 1 04A	90098 00			7BA ASSEMBLY	EP .0010		
	33889 33821D X15-33889	CONE CUP CONE SPCR BB		20024 20024 20000		2 2BP 1 1BB 1 04A	902A1 20024			5BB ASSEMBLY	EP .0120		
	33889 33821DC X15-33889	CONE CUP CONE SPCR A		40024 40024 20000		2 2BP 1 1BB 1 04A	90040 40024			5BB ASSEMBLY	EP .0080		
	33889 39573 33820 B 39520 X25-33889	CONE CONE CUP CUP CONE SPCR A		40024 40082 40024 40082 20000		1 2BP 1 2CP 1 1BC 1 1BL 1 04A	90043 40082			5BA ASSEMBLY	EP .0070		
	33889 HM903249 33821 HM903210 HM903210EA HM903219XA	CONE CONE CUP CUP CUP SPCR CONE SPCR A		20024 20024 20024 20024 20000 20000		1 2BP 1 2BP 1 1BP 1 1BL 1 04B 1 04P	90062 20024			5BA ASSEMBLY	EP .0060	78 299	
	33889 HM903249 33821 HM903210 HM903210EC HM903249XA	CONE CONE CUP CUP CUP SPCR P CONE SPCR A		20024 20024 20024 20024 20000 20000		1 2BP 1 2BP 1 1BP 1 1BL 1 04B 1 04P	90078 20024			5BA ASSEMBLY	EP .0360		
NA33889-SW	NA33889-SW K100825 K100826	CONE CUP CLOSURE		20024 20001		2 2BA 1 1CK 2 411	90035 20000			5CD ASSEMBLY	EP .0000-.0050		
	NA33889-SW K103272 K100826	CONE CUP CLOSURE		20024 20001		2 2BA 1 1CK 2 411	90042 20000			5CD ASSEMBLY	EP .0000-.0050		
	NA33889-SW K103272 K100826	CONE CUP CLOSURE		20199 20001		2 2BA 1 1CK 2 411	90053 20199			5CD ASSEMBLY	EP .0120-.0170		
	NA33889-SW K103272 K100826	CONE CUP CLOSURE		20229 20229		2 2BA 1 1CK 2 411	90091 20229			5CD ASSEMBLY	EP .0030-.0080		
	NA33889-SW K103272 K100826	CONE CUP CLOSURE		30000 30001		2 2BF 1 1CG 2 411	90059 30000			6CB ASSEMBLY	EP .0000-.0030		

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELUND	OR	OBSOLETE DATE
	NA33889-SH K103272 K106796	CONE CUP SEAL		20229 20229		2 2BA 1 1CK 2 090	90096	20229	5CD	ASSEMBLY	EP .0030		.0080
	NA33889-SH K106797 K106796	CONE CUP SEAL		20024 20001		2 2BA 1 1CK 2 090	90058	20000	5CD	ASSEMBLY	EP .0000		.0050
	NA33889-SH K106797 K106796	CONE CUP SEAL		20024 20229		2 2BA 1 1CK 2 090	90084	20227	5CD	ASSEMBLY	EP .0000		.0050
	NA33889-SH K106797 K106796	CONE CUP SEAL		20024 20229		2 2BA 1 1CK 2 090	90083	20229	5CD	ASSEMBLY	EP .0000		.0050
	NA33889-SH K106797 K106796	CONE CUP SEAL		20229 20229		2 2BA 1 1CK 2 090	90085	20229	5CD	ASSEMBLY	EP .0030		.0080
33890	33890 33820-B	CONE CUP		0 0		1 2BF 1 1BH	90012	0		6BA	ASSEMBLY		
	33890 33821	CONE CUP		0 0		1 2BF 1 1BF	90017	0		6BA	ASSEMBLY		
	33890 33821D	CONE CUP		0 0		2 2BF 1 1BG	90014	0		6BB	ASSEMBLY		
	33890 33821D X15-33890	CONE CUP CONE SPCR A		20024 20024 20000		2 2BP 1 1BB 1 04A	90076 902A1	20024 20024	5BB 5BB	ASSEMBLY ASSEMBLY	EP .0080 EP .0120		
	33890 33821D X15-33890	CONE CUP CONE SPCR A		30000 30000 0		2 2BF 1 1BG 1 04A	90065 90098	30000 30000	6BB 6BB	ASSEMBLY ASSEMBLY	EP .0030 EP .0060		
	33890 33821D X15-33890	CONE CUP CONE SPCR A		40024 40024 20000		2 2BP 1 1BB 1 04A	90017	40024	5BB	ASSEMBLY	EP .0120		90 242
	33890 33821D X15-33890	CONE CUP CONE SPCR A		0 0 0		2 2BF 1 1BG 1 04A	90015 90016	0 0		6BB 6BB	ASSEMBLY ASSEMBLY	EP .0070 EP .0090	
	33890 33821DC	CONE CUP		0 0		2 2BF 1 1BG	90090	0		6BB	ASSEMBLY		
	33890 33895 33821 Y35-33821	CONE CONE CUP CUP SPCR		40024 40024 40024 20000		1 2BP 1 2BP 2 1BP 1 04B	90035	40223	5BA	ASSEMBLY			77 249
33891	33891 33820-B	CONL CUP		0 0		1 2BF 1 1BH	90028	0		6BA	ASSEMBLY		
	33891 33821	CONE CUP		0 0		1 2BF 1 1BF	90092	0		6BA	ASSEMBLY		
33895	33895 33820-B	CONE CUP		0 0		1 2BF 1 1BH	90041	0		6BA	ASSEMBLY		
	33895 33820-B	CONE CUP		0-174 0		1 2BF 1 1BH	90034	0-174		6BA	ASSEMBLY		
	33895 33821	CONE CUP		30059 30059		1 2BF 1 1BF	90073	30059		6BA	ASSEMBLY		
	33895 33821	CONE CUP		0 0		1 2BF 1 1BF	90019	0		6BA	ASSEMBLY		

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
	33895	CONE		40024	2	2BP	90098	40024	5BA	ASSEMBLY	EP .0080	
	33821	CUP		40024	2	1BP						
	Y15-33821	CUP SPCR R		20000	1	04Q						
	33895	CONE		40024	2	2BP	90059	40024	5BA	ASSEMBLY	EP .0290	
	33821	CUP		40024	2	1BP						
	X45-33895	CONE SPCR A1		20000	1	04A						
	33895	CONE		0	2	2BF	90020	0	6BB	ASSEMBLY		
	33821D	CUP		0	1	1BG						
	33895	CONE		20024	2	2BP	90052	20024	5BB	ASSEMBLY	EP .0080	
	33821D	CUP		20024	1	1BB	90060	20024	5BB	ASSEMBLY	EP .0100	
	X15-33895	CONE SPCR A		20000	1	04A						
	33895	CONE		30000	2	2BF	90051	30000	6BB	ASSEMBLY	EP .0000	
	33821D	CUP		30000	1	1BG	90075	30000	6BB	ASSEMBLY	EP .0040	
	X15-33895	CONE SPCR A		0	1	04A	90056	30000	6BB	ASSEMBLY	EP .0050	
	33895	CONE		40024	2	2BP	90031	40024	5BB	ASSEMBLY	EP .0080	
	33821D	CUP		40024	1	1BB	90023	40024	5BB	ASSEMBLY	EP .0120	
	X15-33895	CONE SPCR A		20000	1	04A	90049	40024	5BB	ASSEMBLY	EP .0160	
	33895	CONE		0	2	2BF	90087	0	6BB	ASSEMBLY	EP .0070	
	33821D	CUP		0	1	1BG	90021	0	6BB	ASSEMBLY	EP .0080	
	X15-33895	CONE SPCR A		0	1	04A	90022	0	6BB	ASSEMBLY	EP .0090	
	33895	CONE		40024	2	2BP	90030	40024	5BB	ASSEMBLY	EP .0080	
	33821D	CUP		40024	1	1BB	90046	40024	5BB	ASSEMBLY	EP .0120	
	X25-33895	CONE SPCR BB		20000	1	04A						
	33895	CONE		30000	2	2BF	90086	30000	6BB	ASSEMBLY	EP .0020	
	33821DC	CUP		30000	1	1BG	90071	30000	6BB	ASSEMBLY	EP .0050	
	X15-33895	CONE SPCR A		0	1	04A						
	33895	CONE		0	1	2BF	90099	0	6BB	ASSEMBLY		82 118
	33822	CUP		0	1	1BA						
	33895	CONE		40024	1	2BP	90048	40082	5BA	ASSEMBLY	EP .0070	
	39578	CONE		40082	1	2CP						
	33820-B	CUP		40024	1	1BC						
	39520	CUP		40082	1	1BI						
	X35-33895	CONE SPCR A		20000	1	04P						
	33895	CONE		40024	1	2BP	90068	40024	5CA	ASSEMBLY	EP .0140	
	66212	CONE		40024	1	2BP						
	33821	CUP		40024	1	1BP						
	66462	CUP		40024	1	1CL						
	XC1610-SA	CONE SPCR A		20000	1	04A						
	33895	CONE		40024	1	2BP	90069	40024	5CA	ASSEMBLY	EP .0140	
	66212	CONE		40024	1	2BP						
	33821	CUP		40024	1	1BP						
	66462	CUP		40024	1	1CL						
	XC1747-S	CONE SPCR A		20000	1	04A						
	33895	CONE		40024	1	2BP	90045	40082	5BA	ASSEMBLY	EP .0080	
	HM807049	CONE		40082	1	2BL						
	33820-B	CUP		40024	1	1BC						
	HM807011	CUP		40082	1	1BA						
	HM807049XA	CONE SPCR A		20000	1	04P						
	33895	CONE		40024	1	2BP	90045	40082	5BA	ASSEMBLY	EP .0080	89 237
	HM807049	CONE		40082	1	2BL						
	33820-B	CUP		40024	1	1BC						
	HM807011	CUP		40082	1	1BA						
	HM807049XA	CONE SPCR A		20000	1	04P						
33895-B	33895-B	CONE		00	1	2BF	90054	00	7BA	ASSEMBLY		90 128
	33820-B	CUP		00	1	1BH						

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	COMP Q/A SGC	ASSEY CODE	ASSY INSP	ASSY SGC	ASSY DESC	END PLAY OR LOAD	OR	OBSOLETE DATE
NA33895-SH	NA33895-SH K103272	CONE CUP		20024 20001	2 2BA 1 1CK	90085	20000	5CD	ASSEMBLY	EP		.0050
	NA33895-SH K103272 K100826	CONE CUP CLOSURE		20024 20001	2 2BA 1 1CK 2 411	90082	20000	5CD	ASSEMBLY	EP		.0050
	NA33895-SH K103272 K106796	CONE CUP SEAL		20024 20001	2 2BA 1 1CK 2 090	90057	20000	5CD	ASSEMBLY	EP		.0050
	NA33895-SH K103272 K106796	CONE CUP SEAL		20229 20229	2 2BA 1 1CK 2 090	90093	20229	5CD	ASSEMBLY	EP		.0030-.0080
	NA33895-SH K103272 K106796	CONE CUP SEAL		30000 30001	2 2BA 1 1CK 2 090	90084	30000	6CB	ASSEMBLY	EP		.0000-.0030
	NA33895-SH K106797 K106796	CONE CUP SEAL		20024 20001	2 2BA 1 1CK 2 090	90050	20000	5CD	ASSEMBLY	EP		.0000-.0050
	NA33895-SH K106797 K106796	CONE CUP SEAL		20024 20229	2 2BA 1 1CK 2 090	90064	20229	5CD	ASSEMBLY	EP		.0000-.0050
	NA33895-SH K106797 K106796	CONE CUP SEAL		20229 20229	2 2BA 1 1CK 2 090	90086	20229	5CD	ASSEMBLY	EP		.0030-.0080
	NA33895-SH K302667 K106796	CONE CUP SEAL		20024 20001	2 2BA 1 1CK 2 090	90066	20000	5CD	ASSEMBLY	EP		.0000-.0050
	NA33895-SH K302667 K106796	CONE CUP SEAL		20229 20229	2 2BA 1 1CK 2 090	90097	20229	5CD	ASSEMBLY	EP		.0030-.0080
	NA33895-SH K312493 K100826	CONE CUP CLOSURE		20024 20001	2 2BA 1 1CK 2 411	90094	20000	5CD	ASSEMBLY	EP		.0000-.0050
	NA33895-SH K312493 K106796	CONE CUP SEAL		20024 20001	2 2BA 1 1CK 2 090	90067	20000	5CD	ASSEMBLY	EP		.0000-.0050
	NA33895-SH K426866 K106796	CONE CUP SEAL		20024 20001	2 2BA 1 1CK 2 090	90072	20229	5CD	ASSEMBLY	EP		.0000-.0050
	NA33895-SH K444665 K106796	CONE CUP SEAL		20024 20001	2 2BA 1 1CK 2 090	90079	20000	5CD	ASSEMBLY	EP		.0000-.0050
K33907	K21046A K33907 K33941	HEARPLATE HOUSING LUG LINER			2 489 1 487 2 489	90010			486 HSG ASSY			
K33932	K33924 K33925 K33932 K33934 T62086	HEARPLATE LUG COVER BRG HSG HEARPLATE LUG LINER			4 489 2 466 1 487 2 489 2 489	90010			486 HSG ASSY			
K33943	K33943 K35229 K35232 K35233	HOUSING GUARD BRACKET GUARD LUG			1 487 1 489 2 488 1 469	90011			486 HSG ASSY			

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	COMP Q-A	ASSY SGC	ASSY CODE	ASSY INSP	ASSY SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
	K33943	HOUSING			1	487	90010			486 HSG ASSY		
	K35232	BRACKET			2	488						
	K35233	GUARD LUG			1	469						
K33944	K33944	BRG HSG			1	487	90010			486 HSG ASSY		
	K33945	LUG LINER			2	489						
	T71559	HSG LINER			2	489						
K33988	K33988	BRG HSG			1	487	90010			486 HSG ASSY		
	T55103	LUG LINER			2	489						
	T66747	WEARPLATE			2	489						
	T66748	WEARPLATE			2	489						
K33989	K33925	L P COVER			2	466	90010			486 HSG ASSY		
	K33989	BRG HSG			1	487						
	K33991	HSG LINER			2	489						
T34180A	09195	CUP		40024	2	1AD	90010	40024		451 TUBE ASSY		
	T34180A	TUBE			1	451						
	K52003	CLOSURE			2	411						
34274	34274	CONE		0	1	2CF	90010	0		6CA ASSEMBLY		
	34478	CUP		0	1	1CF						
	34274	CONE		20024	2	2CL	90050	20157		5CB ASSEMBLY	EP .0060	
	34478D	CUP		20157	1	1CB						
	X15-34274	CONE SPCR A		20000	1	04B						
	34274	CONE		30000	2	2CF	903A1	30000		6CB ASSEMBLY	EP .0040	
	34478DC	CUP		30000	1	1CG						
	X15-34274	CONE SPCR A		0	1	04B						
	34274	CONE		0	1	2CF	90036	0		6CA ASSEMBLY		
	34481-B	CUP		0	1	1CH						
	34274	CONE		0-174	1	2CF	90089	0-174		6CA ASSEMBLY		
	34481-B	CUP		0	1	1CH						
	34274	CONE		0	1	2CF	90011	0		6CA ASSEMBLY		
	34500	CUP		0	1	1CF						
34275	34275	CONE		0	1	2CF	90012	0		6CA ASSEMBLY		
	34478	CUP		0	1	1CF						
	34275	CONE		40024	2	2CA	90065	40024		5CB ASSEMBLY	EP .0100	
	34478D	CUP		40024	1	1CB						
	X15-34274	CONE SPCR A		20000	1	04B						
	34275	CONE		0	1	2CF	90100	0		6CA ASSEMBLY		
	34492A	CUP		0	1	1CF						
	34275	CONE		0	1	2CF	90013	0		6CA ASSEMBLY		
	34500	CUP		0	1	1CF						
	34275	CONE		40024	1	2CA	90014	40024		5CB ASSEMBLY	EP .0070	
	42633	CONE		40024	1	2CA						
	XC1923DB	CUP		40024	1	1CB						
	XC1923-S	CONE SPCR A		20000	1	04B						
34275HV	34275HV	CONE		00-564	1	2CF	90102	00-564		7CA ASSEMBLY		
	34478V	CUP		00-564	1	1CF						
	K525364	MANIFOLD			1	090						
34294	34294	CONE		40024	1	2CA	90042	40024		5CA ASSEMBLY	EP .0160	
	34300	CONE		40024	1	2CA						
	34478	CUP		40024	2	1CB						
	X25-34294	CONE SPCR AA		20000	1	04B						
	34294	CONE		0	1	2CF	90015	0		6CA ASSEMBLY		
	34478	CUP		0	1	1CF						

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q/A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBsolete DATE
	34294	CONE		0-227	1	2CF	90096	0-227		6CA ASSEMBLY		
	34478	CUP		0-227	1	1CF						
	34294	CONE		30000	2	2CF	90041	30000		6CB ASSEMBLY	EP .0050	
	34478D	CUP		30000	1	1CG						
	X15-34294	CONE SPCR A		0	1	04Q						
	34294	CONE		30434	2	2CF	90095	30434		6CB ASSEMBLY	EP .0020	
	34478D	CUP		30039	1	1CG						
	X15-34294	CONE SPCR A		0	1	04Q						
	34294	CONE		40024	2	2CA	90068	40024		5CB ASSEMBLY	EP .0080	
	34478D	CUP		40024	1	1CB	90084	40024		5CB ASSEMBLY	EP .0100	
	X15-34294	CONE SPCR A		20000	1	04Q						
	34294	CONE		0	2	2CF	905A1	0		6CB ASSEMBLY	EP .0050	
	34478D	CUP		0	1	1CG						
	X15-34294	CONE SPCR A		0	1	04Q						
	34294	CONE		40024	4	2CA	90062	40024		5CC ASSEMBLY	EP .0120	
	34478D	CUP		40024	2	1CB						
	X15-34294	CONE SPCR A		20000	2	04Q						
	X15-34478	CUP SPCR R		20000	1	04C						
	34294	CONE		0	1	2CF	90038	0		5CA ASSEMBLY		
	34481-B	CUP		0	1	1CH						
	34294	CONE		0	1	2CF	90097	0		6CA ASSEMBLY		
	34500	CUP		0	1	1CF						
	34294	CONE		0-227	1	2CF	90093	0-227		6CA ASSEMBLY		
	34500	CUP		0-227	1	1CF						
	34294	CONE		40024	2	2CA	90045	40024		5CA ASSEMBLY	EP .0050	
	34500	CUP		40024	2	1CA						
	X15-34500	CUP SPCR Q		20000	1	04C						
34294-B	34294-B	CONE		00	1	2CF	90016	00		7CA ASSEMBLY		90 129
	34478	CUP		00	1	1CF						
34300	34300	CONE		0	1	2CF	90017	0		6CA ASSEMBLY		
	34478	CUP		0	1	1CF						
	34300	CONE		0-30	1	2CF	90016	0-30		6CA ASSEMBLY		
	34478	CUP		0	1	1CF						
	34300	CONE		0-30	1	2CF	90073	0-33		6CA ASSEMBLY		
	34478	CUP		0-39	1	1CF						
	34300	CONE		30000	2	2CF	90102	30000		6CB ASSEMBLY	EP .0040	
	34478	CUP		30000	2	1CF						
	X45-34478	CUP SPCR S		0	1	04R						
	34300	CONE		0	2	2CF	90094	0		6CB ASSEMBLY		
	34478D	CUP		0	1	1CG						
	34300	CONE		40024	2	2CL	90058	40024		5CB ASSEMBLY	EP .0120	
	34478D	CUP		40024	1	1CB						
	X55-34300	CONE SPCR AA		20000	1	04B						
	34300	CONE		20024	2	2CL	90057	20024		5CB ASSEMBLY	EP .0060	
	34478D	CUP		20024	1	1CB						
	X25-34301	CONE SPCR A		20000	1	04B						
	34300	CONE		30000	2	2CF	90078	30000		6CB ASSEMBLY	EP .0050	
	34478D	CUP		30000	1	1CG						
	X25-34301	CONE SPCR A		0	1	04B						
	34300	CONE		40024	2	2CL	90072	40024		5CB ASSEMBLY	EP .0060	
	34478D	CUP		40024	1	1CB	40065	40024		5CB ASSEMBLY	EP .0080	
	X25-34301	CONE SPCR A		20000	1	04B	90077	40024		5CB ASSEMBLY	EP .0120	