



34300...B02
34301...C02
34306...D02
35176...E02
36185...F02
36690...G02
36690...H02
36990...I02
36990...J02
37425...K02
37431...L02
38549...M02
39236...N02
39250...002

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q/A	COMP 6GC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
							90082	40024	5CB	ASSEMBLY	EP .0160	
	34300	CONE		30000	2	2CF	90101	30000	6CB	ASSEMBLY	EP .0050	
	34478DC	CUP		30000	1	1CG						
	X25-34301	CONE	SPCR A	0	1	04B						
	34300	CONE		0	1	2CF	90019	0	6CA	ASSEMBLY		
	34479	CUP		0	1	1CF						
	34300	CONE		0	1	2CF	90020	0	6CA	ASSEMBLY		
	34481-B	CUP		0	1	1CH						
	34300	CONE		0-30	1	2CF	90099	0-30	6CA	ASSEMBLY		
	34481-B	CUP		0	1	1CH						
	34300	CONE		20024	2	2CL	90070	20024	5CA	ASSEMBLY	EP .0100	
	34481-B	CUP		20024	2	1CG						
	X65-34300	CONE	SPCR AA	20300	1	04B						
	34300	CONE		20024	1	2CI	902A1	20024	5CA	ASSEMBLY		
	34500	CUP		20024	1	1CA						
	34300	CONE		20024	1	2CL	902A1	20024	5CA	ASSEMBLY		
	34500	CUP		20024	1	1CA						
	34300	CONE		0	1	2CF	90021	0	6CA	ASSEMBLY		
	34500	CUP		0	1	1CF						
	34300	CONE		40024	2	2CL	90022	40024	5CA	ASSEMBLY	EP .0080	77 200
	34500	CUP		40024	2	1CA						
	X15-34300	CONE	SPCR	20000	1	04B						
	34300	CONE		40024	2	2CL	90046	40024	5CA	ASSEMBLY	EP .0160	
	34500	CUP		40024	2	1CA						
	X35-34300	CONE	SPCR A1	20000	1	04B						
34300-B	34300-B	CONE		00	1	2CF	90023	00	7CA	ASSEMBLY		90 129
	34478	CUP		00	1	1CF						
	34300-B	CONE		00	1	2CF	90025	00	7CA	ASSEMBLY		90 129
	34500	CUP		00	1	1CF						
34300H	34300H	CONE		0	1	2CF	90072	0	6CA	ASSEMBLY		75 288
	34478	CUP		0	1	1CF						
34301	34301	CONE		0	1	2CF	90026	0	6CA	ASSEMBLY		
	34478	CUP		0	1	1CF						
	34301	CONE		40024	2	2CI	90035	40024	5CA	ASSEMBLY	EP .0120	
	34478	CUP		40024	2	1CI						
	Y15-34478	CUP	SPCR R	20000	1	04C						
	34301	CONE		40024	2	2CI	90067	40024	5CA	ASSEMBLY	EP .0060	
	34478	CUP		40024	2	1CI	90081	40024	5CA	ASSEMBLY	EP .0160	
	Y45-34478	CUP	SPCR S	20000	1	04R						
	34301	CONE		20024	2	2CL	90061	20024	5CB	ASSEMBLY	EP .0080	
	34478D	CUP		20024	1	1CB						
	X25-34301	CONE	SPCR A	20000	1	04B						
	34301	CONE		30000	2	2CF	903A2	30000	6CB	ASSEMBLY	EP .0010	
	34478D	CUP		30000	1	1CG	90053	30000	6CB	ASSEMBLY	EP .0050	
	X25-34301	CONE	SPCR A	0	1	04B						
34301	34478D	CONE		30434	2	2CF	903A1	30434	6CB	ASSEMBLY	EP .0010	
	X25-34301	CUP	SPCR A	30039	1	1CG						
		CONE	SPCR A	0	1	04B						
	34301	CONE		40024	2	2CI	90054	40024	5CB	ASSEMBLY	EP .0060	
	34478D	CUP		40024	1	1CB	90059	40024	5CB	ASSEMBLY	EP .0120	
	X25-34301	CONE	SPCR A	20000	1	04B	90083	40024	5CL	ASSEMBLY	EP .0160	

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	ASSY SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
	34301	CONE		0		2 2CF	90087	0		6CB ASSEMBLY	EP .0050	
	34478D	CUP		0		1 1CG						
	X25-34301	CONE SPCR A		0		1 04B						
	34301	CONE		0		1 2CF	90027	0		6CA ASSEMBLY		
	34481-B	CUP		0		1 1CH						
	34301	CONE		0		1 2CF	90028	0		6CA ASSEMBLY		
	34500	CUP		0		1 1CF						
	34301	CONE		40024		2 2CL	90049	40024		5CA ASSEMBLY	EP .0160	77 200
	34500	CUP		40024		2 1CA						
	X15-34301	CONE SPCR		20000		1 04B						
34304	34304	CONE		0		1 2CF	90092	0		6CA ASSEMBLY		
	34478	CUP		0		1 1CF						
	34304	CONE		0-30		1 2CF	90074	0-33		6CA ASSEMBLY		
	34478	CUP		0-39		1 1CF						
	34304	CONE		40024		2 2CA	90075	40024		5CB ASSEMBLY	EP .0120	
	34478D	CUP		40024		1 1CB						
	X25-34306	CONE SPCR A		20000		1 04B						
34306	34306	CONE		0		1 2CF	90029	0		6CA ASSEMBLY		
	34478	CUP		0		1 1CF						
	34306	CONE		0-30		1 2CF	90055	0-33		6CA ASSEMBLY		
	34478	CUP		0-39		1 1CF						
	34306	CONE		0		1 2CF	90091	0		6CA ASSEMBLY		
	34478-B	CUP		0		1 1CH						
	34306	CONE		20024		2 2CL	90051	20024		5CB ASSEMBLY	EP .0080	
	34478D	CUP		20024		1 1CB						
	X25-34306	CONE SPCR A		20000		1 04B						
	34306	CONE		20157		2 2CL	90071	20214		5CB ASSEMBLY	EP .0040	
	34478D	CUP		20024		1 1CB						
	X25-34305	CONE SPCR A		20000		1 04B						
	34306	CONE		30000		2 2CF	90066	30000		6CB ASSEMBLY	EP .0040	
	34478D	CUP		30000		1 1CG						
	X25-34306	CONE SPCR A		0		1 04B						
	34306	CONE		30030		2 2CF	90052	30030		6CB ASSEMBLY	EP .0030	
	34478D	CUP		30000		1 1CG						
	X25-34306	CONE SPCR A		0		1 04B						
	34306	CONE		40024		2 2CL	90086	40024		5CB ASSEMBLY	EP .0120	
	34478D	CUP		40024		1 1CB						
	X25-34306	CONE SPCR A		20000		1 04B						
	34306	CONE		40024		2 2CL	904A1	40499		5CB ASSEMBLY		
	34478D	CUP		40024		1 1CB						
	X25-34306	CONE SPCR A		40000		1 04B						
	34306	CONE		0		2 2CF	90069	0		6CB ASSEMBLY	EP .0040	
	34478D	CUP		0		1 1CG	90101	0		6CB ASSEMBLY	EP .0050	
	X25-34306	CONE SPCR A		0		1 04B						
	34306	CONE		40024		2 2CL	90076	40024		5CB ASSEMBLY	EP .0160	
	34478D	CUP		40024		1 1CB						
	X45-34306	CONE SPCR A1		20000		1 04B						
	34306	CONE		40024		2 2CL	90102	40024		5CB ASSEMBLY	EP .0120	
	34478DC	CUP		40024		1 1CB						
	X25-34306	CONE SPCR A		20000		1 04B						
	34306	CONE		0		1 2CF	90030	0		6CA ASSEMBLY		
	34481-B	CUP		0		1 1CH						

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
	34306 34481-B	CONE CUP		0-30 0		1 2CF 1 1CF	90098	0-30		6CA ASSEMBLY		
	34306 34481-B	CONE CUP		0-174 0		1 2CF 1 1CF	90090	0-174		6CA ASSEMBLY		
	34306 34492A X3S-34306 Y1S-34492	CONE CUP CONE SPCR CUP SPCR		40024 40024 20000 20000		2 2CL 2 1CA 1 04B 1 04C	90056	40024		5CA ASSEMBLY	EP .0200	77 200
	34306 34500	CONE CUP		0 0		1 2CF 1 1CF	90031	0		6CA ASSEMBLY		
	34306 34500	CONE CUP		0-30 0-39		1 2CF 1 1CF	90034	0-33		6CA ASSEMBLY		
	34306 34500 X1S-34306	CONE CUP CONE SPCR A		40024 40024 20000		2 2CL 2 1CA 1 04B	90024	40024		5CA ASSEMBLY	EP .0080	
34306-B	34306-B 34478	CONE CUP		00 00		1 2CF 1 1CF	90042	00		7CA ASSEMBLY		
	34306-B 34478 X2S-34306	CONE CUP CONE SPCR A		00 00 00		2 2CF 1 1CG 1 04B	90080	00		7CB ASSEMBLY	EP .0030	90 129
	34306-B 34481-B	CONE CUP		0 0		1 2CF 1 1CH	90088	0		6CA ASSEMBLY		90 129
	34306-B 34481-B	CONE CUP		00 00		1 2CF 1 1CH	90060	00		7CA ASSEMBLY		90 129
	34306 B 34500	CONE CUP		00 00		1 2CF 1 1CF	90032	00		7CA ASSEMBLY		90 129
34306H	34306H 34478-B	CONE CUP		0 0		1 2CF 1 1CH	90037	0		6CA ASSEMBLY		
	34306H 34481-B	CONE CUP		0 0		1 2CF 1 1CH	90040	0		6CA ASSEMBLY		
T34370	T34370 T43654	HOUSING BOLT				1 487 2 489	90010			486 HSG ASSY		
34478RB	34478RB K103229	CUP SNAP RING		20355		1 1CA 1 090	90043	20355		541 ASSEMBLY		
	34478RB K103229	CUP SNAP RING		20355		1 1CA 1 090	90043	20355		541 ASSEMBLY		
	34478RB K103229	CUP SNAP RING		40355		1 1CA 1 090	90044	40355		541 ASSEMBLY		
T34975	T34975 K50729	TUBE BACK RING				1 451 2 419	90010			451 TUBE ASSY		
T34980X	09195 T34980X K50729	CUP TUBE BACK RING		40024		2 1AD 1 451 2 419	90010	40024		451 TUBE ASSY		
V35051A	09195 K52003	CUP CLOSURE		40024		2 1AD 2 411	90010			451 TUBE ASSY		
K35057A	T29672 K35057A	CLOSURE TUBE				2 411 1 454	90010			454 TUBE ASSY		
35175	35175 35326	CONE CUP		0 0		1 2AF 1 1BF	90010	0		6BA ASSEMBLY		

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	ASSY SGC	ASSY DESC	END PLAY OR PRELOAD	OR	OBSOLETE DATE
35176	35176 35326	CONE CUP		0 0		1 2AF 1 1BF	90011	0		6BA ASSEMBLY			
K35276	K33379 K35276 K62392	COUPLING HOUSING COVER				1 488 1 487 1 488	90010			486 HSG ASSY			
K35280	K35280 K35292 K35294 K35295	HOUSING LUG LINER WEARPLATE L P COVER				1 487 2 489 2 489 2 489	90010			486 HSG ASSY			81 162
K35284	K21046A K35284 K35285	WEARPLATE HOUSING LUG LINER				2 489 1 487 2 489	90010			486 HSG ASSY			
T35647	T35647 K50729	TUBE BACK R'ING				1 451 2 419	90010			451 TUBE ASSY			
T35650A	09195 T35650A K52004	CUP TUBE CLOSURE		40024		2 1AD 1 451 2 411	90010	40024		451 TUBE ASSY			
K35923A	09067 09195 T27362 K35923A K36060 K47704 T49325 K52003	CONE CUP FLINGER TUBE CLOSURE ROLL SHFT ADJCOLLAR CLOSURE		40024 40024		2 2AD 2 1AD 2 412 1 451 2 411 1 474 2 090 2 411	90011	40024		451 TUBE ASSY			
	09195 K35923A K52003	CUP TUBE CLOSURE		40024		2 1AD 1 451 2 411	90010	40024		451 TUBE ASSY			
K36060	K36060 T49549 T49551	CLOSURE FELT CLOSURE				1 411 1 491 1 411	90010			543 ASSEMBLY			
K36101	K21046A K36101 T55101	WEARPLATE HOUSING LUG LINER				2 489 1 487 2 489	90010			486 HSG ASSY			
K36104	K36104 K36165	AEC IMPELLER				1 419 1 474	90010			474 AEC ASSY			
K36106	K36106 K36115 K36116 K36117 T59810	HOUSING LUG LINER HSG LINER L P COVER WEARPLATE				1 487 2 489 2 489 2 489 1 489	90010			486 HSG ASSY			78 347
K36120	K21046A K36120 T71506	WEARPLATE HOUSING GUIDE LNR				2 489 1 487 2 489	90010			486 HSG ASSY			
36137	36137 36300	CONE CUP		0 0		1 2AF 1 1AF	90010	0		6AA ASSEMBLY			
	36137 36300 X15-36137 Y15-36300	CONE CUP CONE SPCR CUP SPCR		40024 40024 20000 20000		2 2AA 2 1AA 1 04A 1 04A	90012	40024		5AA ASSEMBLY EP .0180			77 200
36137-B	36137-B 36300	CONE CUP		00 00		1 2AF 1 1AF	90011	00		7AA ASSEMBLY			87 183

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	SGC DESC	END PLAY OR PRELOAD	OBSOLETE DATE
K36185	K23476	HEARPLATE				2 489	90010		486 HSG ASSY		
	K25860	L P COVER				2 466					
	K25860A	L P COVER				2 466					
	K36185	BRG HSG				1 487					
	T62002	LUG LINER				2 489					
T36413XA	09195	CIIP		40024		2 1AD	90011	40024	451 TUBE ASSY		
	T36413XA K52003	TUBE CLOSURE				1 451 2 411					
	09195	CIIP		40024		2 1AD	90010	40024	451 TUBE ASSY		
	T36413XA K52007	TUBE CLOSURE				1 451 2 411					
36686	36686	CONE		0		1 2GF	905A1	0	6DA ASSEMBLY		
	36620	CUP		0		1 1DF					
	36686	CONE		0-174		1 2GF	90046	0-174	6DA ASSEMBLY		
	36620	CUP		0		1 1DF					
	36686	CONE		00		1 2GF	906A2	00	7DA ASSEMBLY		
	36620	CUP		00		1 1DF					
	36686	CONE		0		1 2GF	90050	0	6DA ASSEMBLY		
	36620-B	CUP		0		1 1DH					
	36686	CONE		30000		4 2GF	90048	30000	6DC ASSEMBLY EP .0100		
	36620D Y35-36620 X15-48685	CUP CUP SPCR Q CONE SPCR A		30000 0 0		2 1DG 1 04D 2 04R					
36686	CONE		30000		2 2GF	90047	30000	6DB ASSEMBLY EP .0100			
36620D X15-48685	CUP CONE SPCR A		30000 0		1 1DG 1 04R						
36686	CONE		40024		2 2GA	90052	40024	5DB ASSEMBLY EP .0120			
36620D X15-48685	CUP CONE SPCR A		40024 20000		1 1DB 1 04R						
36686	CONE		30000		2 2GF	90049	30000	6DB ASSEM EP .0100			
	36620DC	CUP		30000		1 1DG					
	X15-48685	CONE SPCR A		0		1 04R					
36690	36690	CONE		30580		1 2GF	90060	30580	6DA ASSEMBLY		
	36620	CUP		30000		1 1DF					
	36690	CONE		40024		1 2G1	9F499	4F024	5DA ASSEMBLY		
	36620	CUP		40024		1 1DL					
	36690	CONE		0		1 2GF	90010	0	6DA ASSEMBLY		
	36620	CUP		0		1 1DF					
	36690	CONE		0-30		1 2GF	90045	0-30	6DA ASSEMBLY		
	36620	CUP		0		1 1DF					
	36690	CONE		0-30		1 2GF	90025	0-33	6DA ASSEMBLY		
	36620	CUP		0-39		1 1DF					
	36690	CONE		0-174		1 2GF	90011	0-174	6DA ASSEMBLY		
	36620	CUP		0		1 1DF					
36690	CONE		00-521		1 2GF	906A1	00-521	7DA ASSEMBLY		89 079	
36620	CUP		00		1 1DF						
36690	CONE		00-651		1 2GF	906A2	00-651	7D7 ASSEMBLY			
36620	CUP		00-651		1 1DF						
36690	CONE		40024		2 2G1	90020	40024	5DA ASSEMBLY EP .0120		77 200	
36620	CUP		40024		2 1DL						
Y15-36620	CUP SPCR		20000		1 04D						

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
	36690	CONE		0-589	2	2GF	90058	0 539	6DS	ASSEMBLY		
	36620	CUP		0-589	2	1DF						
	Y4S-36620	CUP SPCR R		0	1	04D						
	X6S-36690	CONE SPCR A		0	1	04C						
	36690	CONE		0	1	2GF	90040	0	6DA	ASSEMBLY		
	36620-B	CUP		0	1	1DH						
	36690	CONE		0	2	2GF	90015	0	6DB	ASSEMBLY		
	36620D	CUP		0	1	1DG						
	36690	CONE		20024	2	2GL	90027	20024	5DB	ASSEMBLY	EP .0100	
	36620D	CUP		20024	1	1DB	90023	20024	5DB	ASSEMBLY	EP .0120	
	X1S-36690	CONE SPCR A		20000	1	04R						
	36690	CONE		20081	2	2GL	90026	20262	5DB	ASSEMBLY	EP .0160	
	36620D	CUP		20262	1	1DB						
	X1S-36690	CONE SPCR A		20000	1	04R						
	36690	CONE		30000	2	2GF	90056	30000	6DB	ASSEMBLY	EP .0020	
	36620D	CUP		30000	1	1DG	90044	30000	6DB	ASSEMBLY	EP .0040	
	X1S-36690	CONE SPCR A		0	1	04R	90029	30000	6DB	ASSEMBLY	EP .0060	
							90051	30000	6DB	ASSEMBLY	EP .0080	
							90050	30000	6DB	ASSEMBLY	EP .017	
							90043	30000	6DB	ASSEMBLY	PL .0020	
	36690	CONE		30000	2	2GF	903A4	30663	6DB	ASSEMBLY	PL .0015	
	36620D	CUP		30000	1	1DG	903A3	30663	6DB	ASSEMBLY	PL .0020	
	X1S-36690	CONE SPCR A		0	1	04R						
	36690	CONE		30434	2	2GF	90055	30434	6DB	ASSEMBLY	EP .0005	
	36620D	CUP		30039	1	1DG	90057	30434	6DB	ASSEMBLY	PL .0020	
	X1S-36690	CONE SPCR A		0	1	04R						
	36690	CONE		40024	2	2GL	90054	40024	5DB	ASSEMBLY	EP .0000	
	36620D	CUP		40024	1	1DB	90019	40024	5DB	ASSEMBLY	EP .0120	
	X1S-36690	CONE SPCR A		20000	1	04R	90017	40024	5DB	ASSEMBLY	EP .0160	
							90028	40024	5DB	ASSEMBLY	EP .0200	
	36690	CONE		40024	2	2GL	94017	44024	5DB	ASSEMBLY	EP .0160	
	36620D	CUP		40024	1	1DB						
	X1S-36690	CONE SPCR A		20000	1	04R						
	36690	CONE		0	2	2GF	90022	0	6DB	ASSEMBLY	EP .0005	
	36620D	CUP		0	1	1DG	90014	0	6DB	ASSEMBLY	EP .0080	
	X1S-36690	CONE SPCR A		0	1	04R						
	36690	CONE		40024	2	2GL	90033	40024	5DB	ASSEMBLY	EP .0160	
	36620D	CUP		40024	1	1DB						
	X2S-36690	CONE SPCR A1		20000	1	04C						
	36690	CONE		20024	2	2GL	90024	20024	5DB	ASSEMBLY	EP .0120	
	36620DC	CUP		20024	1	1DB						
	X1S-36690	CONE SPCR A		20000	1	04R						
	36690	CONE		30000	2	2GF	90021	30000	6DB	ASSEMBLY	EP .0080	
	36620DC	CUP		30000	1	1DG						
	X1S-36690	CONE SPCR A		0	1	04R						
	36690	CONE		40024	2	2GL	90032	40024	5DB	ASSEMBLY	EP .0120	
	36620DC	CUP		40024	1	1DB	90053	40024	5DB	ASSEMBLY	EP .0160	
	X1S-36690	CONE SPCR A		20000	1	04R	90036	40024	5DB	ASSEMBLY	EP .0200	
	36690	CONE		0	2	2GF	90034	0	6DB	ASSEMBLY	EP .0080	
	36620DC	CUP		0	1	1DG						
	X1S-36690	CONE SPCR A		0	1	04R						
	36690	CONE		0	1	2GF	90030	0	6DA	ASSEMBLY		
	36626	CUP		0	1	1DF						

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q/A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
	36690	CONE		20024		2 2GL	90041	20024	5DA	ASSEMBLY	EP .0120	
	36626	CUP		20024		2 1DA						
	Y15-36626	CUP SPCR	RSR	20000		1 04D						
	X45-36690	CONE SPCR	A	20000		1 04C						
	36690	CONE		20024		2 2GL	90042	20024	5DA	ASSEMBLY	EP .0120	
	36626	CUP		20024		2 1DA						
	Y25-36626	CUP SPCR	RSR	20000		1 04D						
	X55-36690	CONE SPCR	A	20000		1 04C						
36690-B	36690-B	CONE		0		1 2GF	90038	0	6DA	ASSEMBLY		76 243
	36620	CUP		0		1 1DF						
	36690-B	CONE		00		1 2GF	90012	00	7DA	ASSEMBLY		90 127
	36620	CUP		00		1 1DF						
	36690-B	CONE		00		1 2GF	90016	00	7DA	ASSEMBLY		90 127
	36620-B	CUP		00		1 1DH						
	36690-B	CONE		00		2 2GF	90031	00	7DB	ASSEMBLY		90 127
	36620D	CUP		00		1 1DG						
36691	36691	CONE		40024		1 2GA	9F499	4F024	5DA	ASSEMBLY		
	36620	CUP		40024		1 1DL						
36691-B	36691-B	CONE		0		1 2GF	90035	0	6DA	ASSEMBLY		76 127
	36620-B	CUP		0		1 1DH						
K36980XA	09067	CONE		40024		2 2AD	90011	40024	451	TUBE ASSY		
	09195	CUP		40024		2 1AD						
	127362	FLINGER				2 412						
	K36061	CLOSURE				2 411						
	K36980XA	TUBE				1 451						
	T49567	CONV CLR				2 490						
	K52003	CLOSURE				2 411						
	09067	CONE		40024		2 2AD	90010	40024	451	TUBE ASSY		
	09195	CUP		40024		2 1AD						
	127362	FLINGER				2 412						
	K36061	CLOSURE				2 411						
	K36980XA	TUBE				1 451						
	T49567	CONV CLR				2 490						
	K52003	CLOSURE				2 411						
	K89406	SHAFT				1 490						
	09195	CUP		40024		2 1AD	90012	40024	451	TUBE ASSY		
	K36980XA	TUBE				1 451						
	K52003	CLOSURE				2 411						
K36993A	14276	CUP		40024		2 1AE	90010	40024	454	TUBE ASSY		
	129672	CLOSURE				2 411						
	K36983A	TUBE				1 454						
36990	36990	CONE		0		1 2HF	90010	0	6EA	ASSEMBLY		
	36920	CUP		0		1 1EF						
	36990	CONE		0-30		1 2HF	90030	0-33	6EA	ASSEMBLY		
	36920	CUP		0-39		1 1EF						
	36990	CONE		0-174		1 2HF	905A1	0-174	6EA	ASSEMBLY		
	36920	CUP		0		1 1EF						
	36990	CONE		0-284		1 2HF	905A3	0-284	6EA	ASSEMBLY		
	36920	CUP		0-39		1 1EF						
	36990	CONE		20024		4 2HA	90046	20024	5EC	ASSEMBLY	EP .0200	
	36920CD	CUP		20024		2 1EB						
	Y15-36920	CUP SPCR	S	20000		1 04E						
	X15-36990	CONE SPCR	A	20000		2 04D						

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	ASSY SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
36990	36920CD	CONE CUP		20024		2 2HA	90036	20024	5EB	ASSEMBLY	EP .0010	
X1S-36990	36920CD	CONE SPCR A		20024		1 1EB	90038	20024	5EB	ASSEMBLY	EP .0080	
				20000		1 04D	90040	20024	5EB	ASSEMBLY	EP .0100	
							90035	20024	5EB	ASSEMBLY	EP .0120	
							90034	20024	5EB	ASSEMBLY	EP .0160	
							90045	20024	5EB	ASSEMBLY	EP .0180	
							90041	20024	5EB	ASSEMBLY	EP .0200	
36990	36920CD	CONE CUP		20024		2 2HA	902A2	20649	5EB	ASSEMBLY		
X1S-36990	36920CD	CONE SPCR A		20024		1 1EB						
				40000		1 04D						
36990	36920CD	CONE CUP		20081		2 2HA	90037	20262	5EB	ASSEMBLY	EP .0160	
X1S-36990	36920CD	CONE SPCR A		20262		1 1EB						
				20000		1 04D						
36990	36920CD	CONE CUP		30000		2 2HF	90044	30000	6EB	ASSEMBLY	EP .0040	
X1S-36990	36920CD	CONE SPCR A		30000		1 1EG	90043	30000	6EB	ASSEMBLY	EP .0060	
				0		1 04D						
36990	36920CD	CONE CUP		0		2 2HF	90042	0	6EB	ASSEMBLY	EP .0060	
X1S-36990	36920CD	CONE SPCR A		0		1 1EG						
				0		1 04D						
36990	36920CD	CONE CUP		20024		2 2HA	90039	20024	5EB	ASSEMBLY	PL .0040	
X2S-36990	36920CD	CONE SPCR A1		20024		1 1EB						
				20000		1 04D						
36990	36920D	CONE CUP		40024		4 2HA	90032	40024	5EC	ASSEMBLY	EP .0200	89 292
X1S-36990	36920D	CONE SPCR S		40024		2 1EB						
				20000		1 04E						
				20000		2 04D						
36990	36920D	CONE CUP		20024		2 2HA	90031	20024	5EB	ASSEMBLY	EP .0080	89 292
X1S-36990	36920D	CONE SPCR A		20024		1 1EB	90011	20024	5EB	ASSEMBLY	EP .0100	89 292
				20000		1 04D	90012	20024	5EB	ASSEMBLY	EP .0160	89 292
							90029	20024	5EB	ASSEMBLY	EP .0180	89 292
36990	36920D	CONE CUP		20081		2 2HA	90018	20262	5EB	ASSEMBLY	EP .0160	89 292
X1S-36990	36920D	CONE SPCR A		20262		1 1EB						
				20000		1 04D						
36990	36920D	CONE CUP		20397		2 2HA	90027	20397	5EB	ASSEMBLY	EP .0180	89 292
X1S-36990	36920D	CONE SPCR A		20397		1 1EB						
				20000		1 04D						
36990	36920D	CONE CUP		30000		2 2HF	90016	30000	6EB	ASSEMBLY	EP .0040	89 292
X1S-36990	36920D	CONE SPCR A		30000		1 1EG	90025	30000	6EB	ASSEMBLY	EP .0060	89 292
				0		1 04D						
36990	36920D	CONE CUP		40024		2 2HA	90017	40024	5EB	ASSEMBLY	EP .0010	89 292
X1S-36990	36920D	CONE SPCR A		40024		1 1EB	90026	40024	5EB	ASSEMBLY	EP .0100	89 292
				20000		1 04D	40019	40024	5EB	ASSEMBLY	EP .0120	89 292
							90013	40024	5EB	ASSEMBLY	EP .0160	89 292
							90024	40024	5EB	ASSEMBLY	EP .0200	89 292
36990	36920D	CONE CUP		20024		2 2HA	90015	20024	5EB	ASSEMBLY	EP .0120	89 292
X2S-36990	36920D	CONE SPCR A1		20024		1 1EB						
				20000		1 04D						
36990	36920D	CONE CUP		40024		2 2HA	90033	40024	5EB	ASSEMBLY	PL .0040	89 292
X2S-36990	36920D	CONE SPCR A1		40024		1 1EB						
				20000		1 04D						
36990	36920DC	CONE CUP		20024		2 2HA	90028	20024	5EB	ASSEMBLY	EP .0100	89 292
X1S-36990	36920DC	CONE SPCR A		20024		1 1EB						
				20000		1 04D						
36990	36920DC	CONE CUP		40024		2 2HA	90023	40024	5EB	ASSEMBLY	EP .0160	89 292
X1S-36990	36920DC	CONE SPCR A		40024		1 1EB	90020	40024	5EB	ASSEMBLY	EP .0200	89 292
				20000		1 04D						

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
	36990	CONE		0		2 ZHF	90022	0		6FB ASSEMBLY	EP .0060	89 292
	36920DC	CUP		0		1 1EG						
	X1S-36990	CONE SPCR A		0		1 04D						
36990-B	36990-B	CONE		00		2 ZHF	90048	00		7EB ASSEMBLY		89 186
	36920CD	CUP		00		1 1EG						
	36990-B	CONE		00		2 ZHF	90021	00		7EB ASSEMBLY		89 292
	36920D	CUP		00		1 1EG						
K36993A	09195	CUP		40024		2 1AD	90010	40024		451 TUBE ASSY		
	K36993A	TUBE				1 451						
	K52003	CLOSURE				2 411						
K36997	09195	CUP		40024		2 1AD	90010	40024		451 TUBE ASSY		
	K36997	TUBE				1 451						
	K50729	BACK RING				2 419						
JRM37049	JRM37049	CONE		U0227		1 2AA	90UA4	U0227		5AU ASSEMBLY	EP .0010	
	JRM37049-S	CONE		U0227		1 2AA						
	JRM37010	CUP		U0227		2 1AA						
	GR19	GREASE				1 090						
	XC25730FA	HUB				1 090						
	JRM37000-S	SEAL				1 090						
	JRM37000-SA	CLOSURE				1 090						
	JRM37049	CONE		U0A07		1 2AD	9MUA2	UMA07		5BH ASSEMBLY	EP .0010	
	JRM37049-S	CONE		U0A07		1 2AD						
	JRM37010	CUP		U0A07		2 1AD						
	GR19	GREASE				1 090						
	JRM37000-S	SEAL				1 090						
	JRM37000-SA	CLOSURE				1 090						
	K148887	WHEEL HUB				1 090						
	JRM37049	CONE		U0A07		1 2AD	90UA2	U0A07		5BH ASSEMBLY	EP .0010	
	JRM37049-S	CONE		U0A07		1 2AD						
	JRM37010	CUP		U0A07		2 1AD						
	GR19	GREASE				1 090						
	JRM37000-S	SEAL				1 090						
	JRM37000-SA	CLOSURE				1 090						
	K148887	WHEEL HUB				1 090						
	K148888	TONE RING				1 090						
	JRM37049	CONE		U0A07		1 2AD	90UA1	U0A07		5BH ASSEMBLY	EP .0010	
	JRM37049-S	CONE		U0A07		1 2AD						
	JRM37010	CUP		U0A07		2 1AD						
	GR19	GREASE				1 090						
	JRM37000-S	SEAL				1 090						
	JRM37000-SA	CLOSURE				1 090						
	K148887	WHEEL HUB				1 090						
	K148888	TONE RING				1 090						
	JRM37049	CONE		U0227		1 2AA	90UA3	U0227		5BH ASSEMBLY	EP .0010	
	JRM37049-S	CONE		U0227		1 2AA						
	JRM37010	CUP		U0227		2 1AA						
	GR19	GREASE				1 090						
	JRM37000-S	SEAL				1 090						
	JRM37000-SA	CLOSURE				1 090						
	K148887	WHEEL HUB				1 090						
	K148888	TONE RING				1 090						
37425	37425	CONE		0		1 2FF	90010	0		6CA ASSEMBLY		
	37625	CUP		0		1 1CF						

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
	37425	CONE		0-174	1	2FF	90012	0-174	6CA	ASSEMBLY		
	37625	CUP		0	1	1CF						
	37425	CONE		40024	2	2FL	90038	40024	5CA	ASSEMBLY	EP .0180	77 200
	37625	CUP		40024	1	1CA						
	X35-37425	CONE SPCR		20000	1	04C						
	Y35-37625	CUP SPCR		20000	1	04C						
	37425	CONE		40024	2	2FL	90044	40223	5CA	ASSEMBLY	EP .0100	77 200
	37625	CUP		40024	2	1CA						
	X55-37425	CONE SPCR		20000	1	04C						
	Y45-37625	CUP SPCR		20000	1	04C						
	37425	CONE		40024	2	2FL	90045	40024	5CA	ASSEMBLY	EP .0100	
	37625	CUP		40024	2	1CA						
	X65-37425	CONE SPCR A		20000	1	04C						
	37425	CONE		0	1	2FF	90013	0	6CA	ASSEMBLY		
	37625-B	CUP		0	1	1CH						
	37425	CONE		0	2	2FF	90027	0	6CB	ASSEMBLY		
	37626D	CUP		0	1	1CG						
	37425	CONE		20024	2	2FL	90042	20024	5CB	ASSEMBLY	EP .0000	
	37626D	CUP		20024	1	1CB	90016	20024	5CB	ASSEMBLY	EP .0080	
	X15-37425	CONE SPCR A		20000	1	04R	90017	20024	5CB	ASSEMBLY	EP .0120	
							9002A1	20024	5CB	ASSEMBLY	EP .0200	
	37425	CONE		30000	2	2FF	90014	30000	6CB	ASSEMBLY	EP .0030	
	37626D	CUP		30000	1	1CG	90015	30000	6CB	ASSEMBLY	EP .0040	
	X15-37425	CONE SPCR A		0	1	04R						
	37425	CONE		40024	2	2FL	90018	40024	5CB	ASSEMBLY	EP .0060	
	37626D	CUP		40024	1	1CB	90019	40024	5CB	ASSEMBLY	EP .0080	
	X15-37425	CONE SPCR A		20000	1	04R	90020	40024	5CB	ASSEMBLY	EP .0120	
							90022	40024	5CB	ASSEMBLY	EP .0160	
	37425	CONE		40157	2	2FL	90026	40214	5CB	ASSEMBLY	EP .0080	
	37626D	CUP		40024	1	1CB						
	X15-37425	CONE SPCR A		20000	1	04R						
	37425	CONE		40024	2	2FL	90041	40024	5CB	ASSEMBLY	EP .0080	
	37626DC	CUP		40024	1	1CB						
	X15-37425	CONE SPCR A		20000	1	04R						
	37425	CONE		40024	1	2FL	90037	40024	5DA	ASSEMBLY	EP .0120	
	67425	CONE		40024	1	2FA						
	37625	CUP		40024	1	1CA						
	67675	CUP		40024	1	1DA						
	Y25-37625	CUP SPCR Q		20000	1	04D						
37425-B	37425-B	CONE		00	1	2FF	90023	00	7CA	ASSEMBLY		
	37625	CUP		00	1	1CF						
37431	37431	CONE		0	1	2FF	90024	0	6CA	ASSEMBLY		
	37625	CUP		0	1	1CF						
	37431	CONE		0	1	2FF	90025	0	6CA	ASSEMBLY		
	37625-B	CUP		0	1	1CH						
	37431	CONE		30000	2	2FF	90030	30000	6CB	ASSEMBLY	EP .0060	
	37626D	CUP		30000	1	1CG						
	X15-37431	CONE SPCR A		0	1	04C						
	37431	CONE		40024	2	2FL	90029	40024	5CB	ASSEMBLY	EP .0080	
	37626D	CUP		40024	1	1CB	90040	40024	5CB	ASSEMBLY	EP .0100	
	X15-37431	CONE SPCR A		20000	1	04C						
	37431	CONE		40024	2	2FL	90039	40024	5CB	ASSEMBLY	EP .0080	
	37626DC	CUP		40024	1	1CB						
	X15-37431	CONE SPCR A		20000	1	04C						

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q/A	COMP SGC	ASSY CODE	ASSY INSP	SGC DESC	END PLAY PRELOAD	OR	OBSOLETE DATE
	37431 K100429 X2S-37431	CONE CUP CONE SPCR		20024 20024 20000	2 1 1	2FL 1DB 04C	90032	20024	5DB ASSEMBLY	EP .1000		72 173
37431A	37431A 37625	CONE CUP		4F024 4F024	1 1	2FA 1CA	9F4A1	4F754	5CA ASSEMBLY			
37431-B	37431-B 37626D	CONE CUP		00 00	2 1	2FF 1CG	90021	00	7CB ASSEMBLY			
K37432	K37432 T65972	CONE SPCR FLINGER			1 1	474 474	90010		474 SPCR ASSY			
K37438	K37438 K37439	AEC IMPELLER			1 1	419 474	90010		474 E.C. ASSY			
T37448A	14276 T37448A T49574	CUP TUBE CLOSURE		40024	2 1 2	1AE 454 411	90010	40024	454 TUBE ASSY			
K37493	K32070 K32077 K32078 K37493 T62002	WEARPLATE WEARPLATE L P COVER HOUSING LUG LINER			2 2 2 1 2	489 489 466 487 489	90010		486 HSG ASSY			
37625RB	37625RB K103231	CUP SNAP RING		20355	1 1	1CA 090	90034	20355	541 ASSEMBLY			
	37625RB K103231	CUP SNAP RING		40355	1 1	1CA 090	90035	40355	541 ASSEMBLY			
T37812	T37812 T37815	CONE SPCR FLINGER			1 1	474 474	90010		474 SPCR ASSY			
K37907	K32070 K32077 K32078 K37907 T62002	WEARPLATE WEARPLATE L P COVER BRG HSG LUG LINER			2 2 2 1 2	489 489 466 487 489	90010		486 HSG ASSY			
K37914	K37914 T65976	CONE SPCR FLINGER			1 1	474 474	90010		474 SPCR ASSY			
K37915	K37915 T65974	CONE SPCR FLINGER			1 1	474 474	90010		474 SPCR ASSY			
K37916	K37916 K37917 K37918 K37919	BRG HSG WEARPLATE OPC PLATE LUG LINER			1 2 2 2	487 489 469 489	90010		486 HSG ASSY			
K37938	K37938 K37958	ASSEMBLY WEARPLATE			1 2	488 489	90010		486 ASSEMBLY			
K37998	K37998 T97922	AEC IMPELLER			1 1	480 474	90010		474 AEC ASSY			
T38070	T38070 T38075	HOUSING LINER			1 2	487 489	90010		486 HSG ASSY			77 350
M38545	M38545 M38510	CONE CUP		0 0	1 1	2AF 1AF	90010	0	6AA ASSEMBLY			
M38545-B	M38545-B M38510	CONE CUP		00 00	1 1	2AF 1AF	90016	00	7AA ASSEMBLY			87 183
M38547	M38547 M38511	CONE CUP		0 0	1 1	2AF 1AF	905A1	0	6AA ASSEMBLY			

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q/A	COMP SGC	ASSY CODE	ASSY INSP	ASSY SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
M38549	M38549 M38510	CONC CUP		0 0		1 2AF 1 1AF	90011	0		6AA ASSEMBLY		
	M38549 M38510	CONE CUP		0-30 0		1 2AF 1 1AF	90012	0-30		6AA ASSEMBLY		
	M38549 M38510	CONE CUP		0-30 0-39		1 2AF 1 1AF	90013	0-33		6AA ASSEMBLY		
	M38549 M38510	CONE CUP		0-174 0		1 2AF 1 1AF	90018	0-174		6AA ASSEMBLY		
	M38549 M38510 XC1999-S XC1999-SA	CONE CUP CONE SPCR CUP SPCR		40024 40024 20000 20000		2 2AA 2 1AA 1 049 2 049	90017	40024		5AF ASSEMBLY	EP .0090	87 177
	M38549 M38510 M38510EA	CONE CUP CUP SPCR S		40024 40024 20000		2 2AA 2 1AA 1 04A	90014	40024		5AA ASSEMBLY	EP .0120	
M38549-B	M38549-B M38510	CONE CUP		00 00		1 2AF 1 1AF	90015	00		7AA ASSEMBLY		87 183
38884	38884 3C820	CONE CUP		4E525 4E525		1 2JA 1 1GA	9E4A2	4E525		5GA ASSEMBLY		
	38884 38820	CONE CUP		4F525 4F525		1 2JA 1 1GA	9F4A1	4F525		5GA ASSEMBLY		
38885	38885 38820	CONE CUP		30178 30178		1 2JA 1 1GA	903A1	30178		5GA ASSEMBLY		
38886	38886 38820 Y35-38820 X35-38886	CONE CUP CUP SPCR S CONE SPCR A		4E525 4E525 2E000 2E000		2 2JA 2 1GA 1 04G 1 04F	9E4A3 9E4A1	4E525 4E525		5GA ASSEMBLY 5GA ASSEMBLY	EP .0390 EP .0600	
	38886 38820 Y35-38820 X35-38886	CONE CUP CUP SPCR S CONE SPCR A		4F525 4F525 2F000 2F000		2 2JA 2 1GA 1 04G 1 04F	9F4A1	4F525		5GA ASSEMBLY	EP .0600	
39236	39236 39412	CONE CUP		0-H000 0		1 2BF 1 1BF	9E020	0-E000		6BA ASSEMBLY		89 079
	39236 39412	CONE CUP		0-H000 0		1 2BF 1 1BF	98020	0-8000		6BA ASSEMBLY		86 037
	39236 39412	CONE CUP		0-H030 0-227		1 2BF 1 1BF	98035	0-227		6BA ASSEMBLY		86 037
	39236 39412	CONE CUP		0 0		1 2BF 1 1BF	90020	0		6BA ASSEMBLY		
	39236 39412	CONE CUP		0-227 0-227		1 2BF 1 1BF	97035	0-227		6BA ASSEMBLY		
	39236 39412-B	CONE CUP		0-H000 0		1 2BF 1 1BH	9E5A1	0-E000		6BA ASSEMBLY		89 228
	39236 39412-B	CONE CUP		0-H000 0		1 2BF 1 1BH	9G5A1	0-G000		6BA ASSEMBLY		
	39236 39412-B	CONE CUP		0-H000 0		1 2BF 1 1BH	98010	0-8000		6BA ASSEMBLY		86 037
	39236 39412-B	CONE CUP		0-H030 0-39		1 2BF 1 1BH	98028	0-8033		6BA ASSEMBLY		86 037

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q-A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
	39236 39412-B	CONE CUP		0 0		1 2BF 1 1BH	90010	0		6BA ASSEMBLY		89 228
	39236 39412-B	CONE CUP		0-30 0-39		1 2BF 1 1BH	90028	0-33		6BA ASSEMBLY		
	39236 39433	CONE CUP		0-H000 0		1 2BF 1 1BF	98011	0-8000		6BA ASSEMBLY		86 037
	39236 39433	CONE CUP		0 0		1 2BF 1 1BF	90011	0		6BA ASSEMBLY		
39236-B	39236-B 39412	CONE CUP		0 0		1 2BF 1 1BF	90022	0		6BA ASSEMBLY		77 003
	39236-B 39412	CONE CUP		00 00		1 2BF 1 1BF	90023	00		7BA ASSEMBLY		90 127
	39236-B 39412-B	CONE CUP		00 00		1 2BF 1 1BH	90012	00		7BA ASSEMBLY		90 127
39250	39250 39412	CONE CUP		20024 20024		1 2BL 1 1BL	902A1	20024		5BA ASSEMBLY		
	39250 39412	CONE CUP		20024 20024		1 2BL 1 1BL	902A1	20024		5BA ASSEMBLY		
	39250 39412	CONE CUP		0 0		1 2BF 1 1BF	90013	0		6BA ASSEMBLY		
	39250 39412	CONE CUP		0-30 0		1 2BF 1 1BF	90024	0-30		6BA ASSEMBLY		
	39250 39412	CONE CUP		0-30 0-39		1 2BF 1 1BF	90014	0-33		6BA ASSEMBLY		
	39250 39412	CONE CUP		00 00		1 2BF 1 1BF	906A2	00		7BA ASSEMBLY		
	39250 39412 X25-39250 Y15-39412	CONE CUP CONE SPCR CUP SPCR		20024 20024 20000 20000		2 2BL 2 1BL 1 04A 1 04B	90015	20024		5BA ASSEMBLY	EP .0060	77 285
	39250 39412 X25-39250 Y35-39412	CONE CUP CONE SPCR CUP SPCR		20024 20024 20000 20000		2 2BL 2 1BL 1 04A 1 04B	90026	20024		5BA ASSEMBLY	EP .0100	77 279
	39250 39412-B	CONE CUP		0 0		1 2BF 1 1BH	90016	0		6BA ASSEMBLY		
	39250 39412-B	CONE CUP		0-30 0		1 2BF 1 1BH	90025	0-30		6BA ASSEMBLY		
	39250 39412-B	CONE CUP		0-30 0-39		1 2BF 1 1BH	90029	0-33		6BA ASSEMBLY		
	39250 39412-B X15-39250	CONE CUP CONE SPCR		20024 20024 20000		2 2BL 2 1BC 1 04A	90032	20024		5BA ASSEMBLY	EP .0100	77 279
	39250 39412-B X65-39250	CONE CUP CONE SPCR AA		20024 20024 20000		2 2BL 2 1BC 1 04P	90033	20024		5BA ASSEMBLY	EP .0120	
	39250 39433	CONE CUP		0 0		1 2BF 1 1BF	90017	0		6BA ASSEMBLY		
39250-B	39250-B 39412	CONE CUP		0 0		1 2BF 1 1BF	90034	0		6BA ASSEMBLY		77 003

ASSEMBLY PART NUMBER	COMPONENT PART NUMBER	DESC	SP TY	COMP INSP	Q/A	COMP SGC	ASSY CODE	ASSY INSP	SGC	ASSY DESC	END PLAY OR PRELOAD	OBSOLETE DATE
	39250-B 39412	CONE CUP		00 00		1 2BF 1 1BF	90018 00			78A ASSEMBLY		90 354
	39250-B 39412	CONE CUP		00-227 00-227		1 2BF 1 1BF	90027 00-227			78A ASSEMBLY		90 026
	39250-B 39412-B	CONE CUP		0 0		1 2DF 1 1BH	90021 0			68A ASSEMBLY		77 003
	39250-B 39412-B	CONE CUP		00 00		1 2BF 1 1BH	90019 00			78A ASSEMBLY		90 026
	39250-B 39422	CONE CUP		00 00		1 2BF 1 1BF	90030 00			78A ASSEMBLY		50 026
39251DE	39251DE 39412 Y8S-39412	CONE CUP CUP SPCR S		40346 40024 20000		1 2BN 2 1BL 1 04Q	90031 40346			58P ASSEMBLY EP .0120		
K39424	K39424 139425 K39426 K39461 T57857	HOUSING WEARPLATE L P COVER WEARPLATE LUG LINER				1 4J7 2 489 2 466 2 489 2 489	90010			486 HSG ASSY		
K39430	K39430 K39430 T57857 T69473	WEARPLATE LUG LINER LUG LINER WEARPLATE				1 489 1 489 2 489 2 489	90010			486 HSG ASSY		
K39462	K39462 T55103 T66747 T66748	HOUSING LUG LINER WEARPLATE WEARPLATE				1 487 2 489 2 489 2 489	90010			486 HSG ASSY		
K39493	K39492 K39493 T64509 T64510 T68320A	LUG LINER HOUSING WEARPLATE WEARPLATE STUD				2 489 1 487 2 489 2 489 2 469	90010			486 HSG ASSY		84 207
39520RB	39520RB K95582	CUP SNAP RING		20355		1 1BA 1 090	90034 20355			54I ASSEMBLY		74 081
39573	39573 39520	CONE CUP		0 0		1 2CF 1 1BF	90052 0			68A ASSEMBLY		
	39573 39520 Y2S-39520	CONE CUP CUP SPCR R		40024 40024 20000		2 2CP 2 1BL 1 04Q	90062 40024			58A ASSEMBLY PL .0100		
	39573 39520 Y3S-39520 X1S-39573	CONE CUP CUP SPCR CONE SPCR		20024 20024 20000 20000		2 2CP 2 1BL 1 04B 1 04A	90039 20024			58A ASSEMBLY EP .0100		77 200
39573-B	39573-B 39520	CONE CUP		00 00		1 2CF 1 1BF	90061 00			78A ASSEMBLY		90 124
39578	39578 39520 Y1S-39520	CONE CUP CUP SPCR S		20024 20024 20000		2 2CP 2 1BL 1 04Q	90058 20024			58A ASSEMBLY EP .0060		
39580	39580 39520	CONE CUP		0 0		1 2CF 1 1BF	90010 0			68A ASSEMBLY		
	39580 39520 Y1S-39520	CONE CUP CUP SPCR S		40024 40024 20000		2 2CP 2 1BL 1 04Q	90011 40024			58A ASSEMBLY EP .0160		